


# EUT INTERNAL PHOTO

EUT UNCOVER VIEW




EUT UNCOVER VIEW






EUT UNCOVER VIEW




EUT UNCOVER VIEW






MAIN BOARD TOP VIEW (WITH SHIELDING)




MAIN BOARD REAR VIEW (WITH SHIELDING)






MAIN BOARD TOP SIDE VIEW (WITHOUT SHIELDING)




MAIN BOARD TOP REAR (WITHOUT SHIELDING)






SUB BOARD TOP VIEW (WITH SHIELDING)




SUB BOARD REAR VIEW (WITH SHIELDING)






SUB BOARD TOP VIEW (WITHOUT SHIELDING)




SUB BOARD REAR VIEW (WITHOUT SHIELDING)






Battery Photo



Battery Photo(REAR)





# Antenna location

