

True Wireless Earphones

P/N 30878

User's Manual

Accessories

1x Pair of True Wireless Earphones  
1x Charging Box  
1x Micro USB Charging Cable  
2x Pairs of Spare Eartips (Small and Large)  
1x User's Manual

FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Product Overview

Microphone

Multi-function button (MFB)

Eartips

Charging Box

Micro USB Charging Port

Charging Base

LED Indicator

Power On & Pairing

Bluetooth

MP-TWE

Turn on the left and right earbuds by pressing and holding the MFB on both earbuds for about 3 seconds. The earphones will automatically enter pairing mode. Search the list of available Bluetooth® devices for the name "MP-TWE", then select it to connect. The earphones will give the following voice prompts: Power on -> Connected -> Left Channel (Pairing) -> Right Channel

TWS Function

The left earphone is the "Master Earphone", with the built-in microphone and hands-free functionality.

The right earphone is the "Secondary Earphone", which can be paired with the left one to get stereo sound .

Make sure the two earphones are successfully powered on. They will connect automatically.

NOTE: Do not cover the earphones with your hand or anything else. Doing so can break the Bluetooth® connection.

Single Mode

Powering On and Pairing the Left Earbud

1. After pairing both earbuds, you can put the right earbud back into the charging box for charging, then pair the left side to your device.The pairing name is still "MP-TWE". After pairing, the voice prompt will say "Connected". You can then play music and make calls using only the left earbud.

2. If the left earbud powers off, turn it on by pressing and holding its MFB for about 3 seconds, then single-click the MFB. The earbud will go into pairing mode and the voice prompt will say "Pairing, Pairing" The pairing name is still "MP-TWE". After pairing, the voice prompt will say "Pairing successful. Connected". You can then play music and make calls using only the left earbud.

Charging

LED Indicator

Charging Your Charge Box

The blue LED turns off when the earphones are fully charged.  
The initial charging time is around 4 hours.

Micro USB Charging Port

Connect the micro USB cable to the charging box until the blue LED indicator flashes.

P/N 30878

Made in China

FCC

FCC ID: 2ADDD-MP30878  
CAN ICES-3 (B) / NMB-3(B)

Specifications

Model	30878
Bluetooth® Version	V5.0
Supported Profiles	HSP/HFP/A2DP/AVRCP
Wireless Range	up to 32 feet (10 meters)
Earphone Batteries	50mAh x2
Charging Box Battery	500mAh
Talk Time	up to 3 hours
Playing Time	3 to 4.5 hours
Charging Time	about 2 hours
Standby Time	150 hours
Earphone Dimensions (each)	0.8"x0.6"x 0.6" (20x16x15mm)
Earphone Weight (each)	0.1 oz. (3.5g)
Charging Box Dimensions	2.9"x1.3"x1.3" (73x32x32mm)
Charging Box Weight	1.8 oz. (50g)

LED Indicator

LED Indicator Status	
Blue & white flashing alternately	Pairing mode
Blue flashing once every 7 seconds	Connected/Playing music
White flashing twice every 2 seconds	Disconnected
Blue & white flashing twice every 3 seconds	Incoming call (Master Earbud)
Blue flashing once every 3 seconds	In call (Master Earphone)
White flashing once every 5 seconds	Low battery
White	Charging
LED off (after charging)	Fully charged

Tips

● Ensure that the earphones are fully charged.

● Ensure both the left and right earphones are within 1 foot.

● Turn on both earphones simultaneously by pressing and holding the MFB on both the left and right earphones for about 4 seconds until the LEDs flash blue and white alternately.

● The left and right earphones will be paired with each other.

● When pairing is successful, you will hear the voice prompt "connected Left channel/Right channel", the LED indicators on the eaphones with flash blue every 7 seconds.

● Turn on the Bluetooth® function of your device and select "MP-TWE" from the device list, then click connect. When Bluetooth is connected successfully, you will hear the voice prompt say "Second device connected".

Music and Call Control

Streaming Audio

Once paired, you can wirelessly stream audio from your device to your earphones. Music will automatically pause when you receive an incoming phone call and will resume once the call has ended.

Play / Pause	Press the multi-function button once
Next Track	Double-press the multi-function button
Volume Control	You may adjust the volume through your cell phone

Making Calls

Once paired with your smartphone, making and answering phone calls can be managed via the multi-function button.

Answer / End a Call	Press the multi-function button once
Reject an Incoming Call	Double-press the multi-function button
Voice Switch	Double-press the multi-function button during a call to switch between the earphones and your phone for talking

Remark: Phone functions are only activated on the master earphone.

FAQ

Q: My earphones will not turn on.  
A: Please recharge them and make sure they have enough power.

Q: Why can I only hear music from one of the earphones?  
A: Make sure the earphones are synced together:  
1.Hold the multi-function button of both units until the LED flashes blue and white alternately.  
2.Wait until you hear a voice prompt telling you the two devices are connected.  
Q: What if the right earphone cuts out, but the left one is fine?  
A: Please try the reset procedure with both earphones, and then try the Stereo Pairing again.  
Q: The earphones cannot be found or pairing fails.  
A: 1. The earphones do not enter the pairing mode, please enable the earphones to enter pairing mode.

2.The Bluetooth® application of the smartphone or device is not operating. Please restart the smartphone or device and restart the pairing process with the earphones.  
Q: What if the sound is unclear?  
A: 1.Please try changing the position of your device nearer to the earphones. A direct line of sight is best.  
2. Please try the reset procedure on the earphones, you will need to pair them again. We also recommend deleting the pairing with your phone, and then perform the pairing again.

Product Care & Use

Please keep away from liquids and extreme heat.  
Do not use earbuds at high volume for extended periods, as this may cause permanent hearing damage or loss.

Warranty & Customer Support

For questions, support, or warranty claims, contact us by email at support@monoprice.com

The Bluetooth® word mark and logos are registered trademarks of Bluetooth SIG, Inc.