





<div><div>EUASOO</div><div>Wireless Transmitter& Receiver</div><div></div><div>Model : KH-26</div><div>User Manual</div></div>	<div>Contents</div> <div><div>1.Product Overview</div><div>2.Package contents</div><div>3.Product Specification</div><div>4.Basic Operation</div><div>4.1 Use as Transmitter</div><div>4.2 Use as Receiver</div><div>5.How to use</div><div>6.How to pairing</div><div>6.1 Pair in TX mode:</div><div>6.2 Pair in RX Mode</div><div>7.Pair with two devices at the same time</div><div>7.1 In TX mode</div><div>7.2 In RX mode</div><div>8.Care and maintenance</div></div>
---	---

<div><div>5.How to use</div><div><div>Charging</div><div>1.Connected the micro-USB end of the cable to the charging port of the bluetooth receiver.</div><div>2.Plug the USB end of charging cable to a USB charging port or any active USB port.</div><div>3.LED indicator will turn red when charging and will automatically turn off when fully charged.</div><div></div><div><div>Charging with Micro USB</div><div>Charging with PC</div></div><div>Note: 1.Pls don't turn it on before fully charged, and we don't advise you use it when it is charging, it may affect the battery life. 2.We recommend charging the unit for at least 2 hours before using it for the first time.</div></div></div>	<div><div>6. How to pairing</div><div><div>6.1 Pair in TX mode:</div><div>1.Set the BT1-016 to TX mode and connect it to your audio transmitting device.</div><div>2.Place your bluetooth audio receiving device within a 3 feet/1 meter range and set it to pairing mode.</div><div>3.Press and hold the power button for 3 seconds and tap twice to enter pairing mode (If BT1-016 do not connect any device before it will auto in pairing mode after power on).</div><div></div></div></div>	<div><div>6.2 Pair in RX Mode</div><div>Press and hold the power button of the adapter for 3 seconds, it will start pairing.</div><div>1.Activate the bluetooth function on your phone and search for the nearby Bluetooth devices: For iOS: Setting > Bluetooth > On For Android: Settings > Wireless & Networks > Bluetooth:On > Scan for devices</div><div>2.Find "BT1-016" in the search results and tap on it to connect. Once connected, the LED indicator will turn solid blue.</div><div></div><div>Note: The adapter enters pairing mode automatically when powered on for the first time. The original pairing memory will be cleared after a mode switch. It will automatically start pairing each time when powered on. If a PIN code is required for pairing, try 0000, 8888, 1111 or 1234. The adapter can remember two recently paired devices and will automatically, without going into pairing mode.</div></div>	<div><div>7. Pair with two devices at the same time</div><div><div>7.1 In TX mode:</div><div>The adapter is able to pair with two bluetooth stereo earphones/speaker at the same time.</div><div>1. Follow the previous instructions in the "Pairing" selection to pair the BT1-016 with your first device.</div><div>2. Turn off the "Bluetooth" function on your first device, tap the power button twice to pair and connect to your second device.</div><div>3. Turn on the bluetooth function on your first device. In approximately 12 seconds, the first device will automatically connect in.</div><div><div>Notes:</div><div>When you pair with two devices, both can play music at the same time. The adapter will automatically re-pair when powered on.</div></div></div></div>	<div><div>7.2 In RX mode:</div><div>The adapter is able to pair with two bluetooth devices at the same time.</div><div>1. Follow previous instructions in the "pairing" section to pair the BT1-016 with your first device. Disable the Bluetooth function on your first device. Tap the power button twice to pair and connect the second device.</div><div>2. Turn on the bluetooth of the first device, now BT1-016 adapter is successfully paired with both two devices.</div><div><div>Notes:</div><div>Only one device can play music at any time. You have to stop the music on one device to play on the other.</div><div>The adapter will automatically re-pair when powered on.</div><div>When connecting a phone, the Bluetooth receiver cannot be used when answering and making a call.</div></div></div>	<div><div>8. Care and maintenance</div><div>Keep the adapter away from heat and humidity. Do not expose the adapter to direct sunlight or extreme heat. Do not try to take the adapter apart. It may cause serious damage. Do not drop or knock the adapter on hard surfaces as it damages the interior circuit. Do not use chemicals or detergents to clean the product. Do not scrape the surface with sharp objects.</div><div><div>FCC STATEMENT :</div><div>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2)This device must accept any interference received, including interference that may cause undesired operation.</div><div>Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</div><div>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interferencein a residential installation.</div></div><div>This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.</div><div><div>FCC Radiation Exposure Statement:</div><div>This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.</div></div></div>
--	---	---	---	--	---