


USB-C

















SIZE:85X63MM

128克双铜纸双面4C印刷  
中间打一颗钉

封面



Pairing AirFly USB-C with AirPods	1
Pairing AirFly USB-C with Wireless Headphones	6
Pairing AirFly USB-C with a Second Set of Wireless Headphones	10
Turning AirFly USB-C On & Off	14
Reconnecting Headphones to iPhone	15
Charging	16
Tips & Tricks	17
Status Light Guide	18



Status Light Guide		FCC Statement	Notes
	Power On	White LED flashes twice	
	Pairing Mode	White & Amber LED flash alternately	
	Unconnected Standby Mode	White LED flashes twice every 5 seconds	
	Connected Standby Mode	Solid White LED	
	Low Power	Amber LED flashes 3 times	
	Charging	Solid Amber	
	Fully Charged	Amber LED turns off	

Have questions?

Visit [twelvesouth.com](https://twelvesouth.com) or contact [support@twelvesouth.com](mailto:support@twelvesouth.com)

© 2019 Twelve South, LLC. All rights reserved.

封底