

# Galanz

Model# GLAP40WEEA11A  
Miya, Miya 2.0, Max, Max2.0,  
WLAP40WEEA11A, Mage, Mage2.0  
PRO AIR PURIFIER



Thank you for purchasing a Galanz product. Please read this manual carefully for correct usage and safety, and keep for future reference. For service, support and warranty information, call 1-800-562-0738.

© 2022 Galanz Americas Limited Company

# CONTENTS

Safety Warnings.....	1
FCC Notice.....	2
Air Purifier Overview.....	3
Getting Started.....	4
Instructions For Usage .....	5
Specifications.....	7
Maintenance and Cleaning.....	8
Packaging List.....	8
Trouble Shooting.....	9
Limited Warranty.....	10
Warranty Registration.....	11

# Safety Warnings

## READ ALL INSTRUCTIONS BEFORE USING YOUR GALANZ PRO AIR PURIFIER

- Person with physical or mental disability, or without relevant experiences and skills (including children) should use it under guiding and instructing.
- This product can not replace normal ventilation, daily dust collection or oil pumping when cooking.
- Be sure to place and use the product on a firm, flat and horizontal surface. Do not place any items above the product.
- Leave at least 12 inches of space on the back and sides of the product, and at least 20 inches of space above the product when using.
- To prevent condensation from getting into or onto the product, do not place under an air conditioner.
- Do not use this product when you are using an indoor spray repellent, or in a place filled with grease, flammable gas or chemical fumes.
- Ensure both the filter and the back cover are properly installed before connecting to the power source.
- Ensure the product socket is well connected to the plug when using. If not, the plug will be hot.
- Please stop using if the plug, power cord or product is damaged. In order to avoid danger, the power cord must be replaced by a professional staff.
- To prevent physical damage, do not inset fingers or foreign things into the product.
- Keep the air inlet/outlet free from being blocked.
- Do not spray any flammable materials such as pesticides or perfumes around the product. Do not use hard objects to strike the product. Especially the air outlet and air inlet.
- Please use the filter designed for this product.
- Ensure the product is unplugged before moving, cleaning, maintaining and replacing the filter.
- Do not pull the wire to move the machine.
- To avoid electrical shock and fire, do not allow water or any other flammable liquid to get into the product.

## SAFETY WARNING

- Before connecting the power supply, please check whether the voltage of the product is consistent with the local power supply voltage.

**HOUSEHOLD USE ONLY**  
**SAVE THESE INSTRUCTIONS**



# FCC Notice

FCC-ID: 2ATIZ-WEEA11A

**Warning:** Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
  - (2) this device must accept any interference received, including interference that may cause undesired operation.
- The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 7.9 inches between the radiator & your body.

Galanz Americas Ltd., Co

55 Challenger Road, Suite 503, Ridgefield Park, NJ 07660  
1-800-562-0738

# Air Purifier Overview



# Getting Started

## REMOVE THE PACKAGING FROM THE FILTER BEFORE USING

- Press the switch shown in the red circle to take out the back cover.



- Pull the filter down and out to remove it from the machine, then remove the packaging from it.




- Once the packaging is removed from the filter, place the filter back into the air purifier and put on the back cover.



## PLACE AND START CORRECTLY

- Place the product on a firm, flat and horizontal surface, and leave at least 12 inches of space on the back and sides of the product, and at least 20 inches of space above the product.



- Check the plug and the power cord to ensure that the voltage of the product is compatible with the local power supply voltage.



This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. **Do not** attempt to defeat this safety feature.

-- WARNING: Unplug or disconnect the appliance from the power supply before servicing.







# Instructions For Usage

Connect the device to the power source. All of the indicator lights will flash once and all of the lights will be off except the power button. Once this happens, the machine will be in standby mode.

## CONTROL PANEL



 Mode Button      Power Button  
 Light Button      Time Button

## BUTTON OPERATION

### ■ Mode Button

When using the device, press the Mode Button to adjust the wind speed among the circulation of Auto-L-H mode. Every time you press the Mode Button, the machine will ring once.

\*Press the Mode Button for 7 seconds to complete the filter reset.

### ■ Power Button

Every time you press the Power Button, the machine will beep once and then it will turn off or on.

\*The background light will display the corresponding color according to the PM2.5 detection value. See sheet below:

Number(PM2.5)	Air Quality	Light	Air Quality
$\leq 75 \text{ ug/m}^3$	Good	BLUE	Good
$75 \sim 150 \text{ ug/m}^3$	Mildly polluted	YELLOW	Mildly polluted
$\geq 150 \text{ ug/m}^3$	Seriously polluted	RED	Seriously polluted

**\*Note: If the machine is turned off without unplugging the power plug and then turned on again, the machine will work in the state before turning off by default.**

### ■ Light Button

In the condition of working, press the Light Button to adjust the light among the circulation of Standard-Soft-Off. Every time you press the Light Button, the machine will beep once.

# Instructions For Usage

## ■ Time Button

When using the appliance, press the Time Button to set the time among the circulation of 2H, 4H, and 8H. Each time you press the Time Button the machine will beep.


\*Press the Time Button for 5 seconds to set up and reset the network.

## MORE INSTRUCTIONS

### Filter Replacement Reminder

When the air purifier detects that the filter reaches the saturation value, the filter indicator light flashes in red. After replacing the new filter, you need to press the Mode Button for about 7 seconds to cancel the alarm reminder.

### Add A Device

Pressing the Time Button for 5 seconds causes the  icon to start flashing, which means you can start connecting the product to the APP.

## MORE INSTRUCTIONS

### ■ Download & Registration

1. Scan the QR code to download the "Smart Life" APP. You can also search "Smart Life" in either the APP store or Google Play to install the APP. Open the "Smart Life" APP, tap "Register" to register a "Smart Life" account with your phone number or E-mail. Then log into the APP.



### ■ Add Device

- 1.) Connect the mobile phone to the home wireless network, and turn on the mobile phone bluetooth (please select 2.4GHz WiFi network).
- 2.) Open the "Smart Life" APP.



# Specifications

3.)Enter the homepage of the "Smart Life" APP. Click "+" to select to add a device, the APP will display manual addition and automatic discovery.

4.)Automatic discovery: When the corresponding authority is turned on, the device can be automatically discovered, and the device needs to be in the network configuration state and turned on.

5.)Manually add: select the name corresponding to the product, WIFI+Bluetooth mode.

## ①Bluetooth configuration:

When confirming that the WIFI indicator of the device is flashing quickly, click OK, and then wait for the connection. When "Successfully add 1 device" appears, it means the connection has been completed and your device will be listed in your APP list.

## ② Hotspot configuration network:

Click on the WIFI quick connection in the upper right corner to select the hotspot distribution network (compatibility mode). Confirm that the WIFI indicator of the device flashes slowly, click OK, and enter your home WIFI and WIFI password.

Next, click to connect to go to the WLAN setting interface of the phone, and then select the Wi-Fi network "SmartLife\_XXXX" to connect it.

Your device will be listed in your APP list. Now you can control your smart device through the mobile APP anytime and anywhere.

\*Make sure your mobile phone and smart device are connected to the same network at the time of first connecting. And make sure your smart device is under a network at the time of controlling.

## SPECIFICATIONS

Product Name	Pro Air Purifier		
Product Size	W10.7"*D11.9"*H20.9	Noise	≤60 dB
Rated Voltage	AC 120V 60Hz	Type Of Filter	Primary Filter+ Carbon+HEPA
Rated Power	50 W	Applicable Area	Up To 875 Sq.Ft.
Net Weight	11.29 lbs	CADR	400 m <sup>3</sup> /h (235 CFM)

# Maintenance & Packaging List

## MAINTENANCE

---

When the Filter Replacement Reminder light is flashing red light, it is indicated that the filter needs to be replaced. Please use the filter designed for this product.

- Clean the filter regularly. Do not wash or reuse the filter.
- Ensure the machine is unplugged before replacing the filter.
- Please sterilize the filter under sunlight regularly.
- Do not use a vacuum cleaner to clean the filter or wash it directly.

## CLEANING & STORAGE

---

- Ensure the machine is powered-off and unplugged before cleaning.
- Do not immerse the air purifier into water or any liquid.
- Do not use abrasive, corrosive or flammable cleansers (such as bleach or alcohol) to clean any part of the unit.
- Do not use a vacuum cleaner to clean the filter or wash it directly.

- Use a soft cloth with neutral cleanser to clean away any dust or debris from the surface of the machine.
- If you do not use the machine for a long time, ensure the machine is dry, store in a plastic bag and place in a cool and well-ventilated place.

**Notice: Please don't drop any water into the machine when cleaning the air outlet.**

**⚠ WARNING:** This equipment should be inspected frequently and collected dirt should be removed from it regularly to prevent excessive accumulation that may result in flashover or a risk of fire .

## PACKAGING LIST

---

- 1 x Pro Air Purifier
- 1 x True HEPA Original 3-Layered Filter
- 1 x Power Cord
- 1 x User Manual
- 1 x Quick Start Guide



# Trouble Shooting

SITUATION	REASON
Not working	Is it plugged into a power socket? Is there a power outage? Is the fuse cut off? Is there any dust on the surface of the primary filter?
Poor performance	Is there any dust on the surface of the primary filter? Is there any obstacle blocking the air inlet/outlet.
Significant noise	Is there anything stuck in the fan in the air outlet? Is the machine tilted? Please set a lower grade of wind speed if the noise is too loud , or set low grade of wind speed when using in bedroom at night.
Foul odor coming from the machine	It is the normal phenomenon that the machine emits the smell of plastic for the first time. The machine will emit an unpleasant smell if the filter is dusty, so in this situation, please clean or replace the filter. If the burning smell emits from the machine, please unplug the power socket and contact customer service.
The Filter Replacement Reminder light is still flashing after replacing the filter	Please press the Wind Speed Button for 7s to reset the machine and the life counter of the filter will start.



# Limited Warranty

This warranty applies to products sold by Galanz Americas in the U.S. This warranty is in lieu of any other warranty and expressly applies to the individual product only.

Galanz product is warrantied for one year following purchase for defects in material and workmanship. **Please save your receipt as proof of purchase is required to make a warranty claim.** During this period, we will provide the purchase price of this product, a replacement or the equivalent, or repair per our discretion.

The warranty cannot be transferred through resale, including the resale through a 3rd party unauthorized retailer and is only bestowed up on the original consumer purchaser upon purchase from an authorized retailer.

**•This warranty does not cover and excludes damage or defects caused by:**

- Consumer misuse
- Abuse
- Neglect including the failure to clean and/or provide adequate regular maintenance as outlined in the user manual
- Commercial use
- Subjecting the product to any voltage outside the specified range
- Loss of parts
- The affixing of any attachments not provided with the product
- Accident, or
- Use in a manner not intended and outlined in the user manual.

Any subsequent damages caused by the above listed exclusions will not be covered and any claims determined to meet the above exclusions will be denied. All liability is limited to the purchase price and does not include any:

- Retail offered extended warranties
  - Tax
  - Other charges(including postage to send required materials)
- Incidental and/or consequential damages associated with the product in question.

Every implied warranty, including any statutory warranty of merchantability or fitness for a particular purpose is disclaimed except to the extent prohibited by law, in which case such warranty is limited to the duration of this written warranty. This warranty gives you specific legal rights. You may have other legal rights that vary depending on where you live. Some states do not allow limitations on implied warranties or special, incidental, or consequential damaged, so the above limitations may not apply to you.

If you have a claim under this warranty, please call our Customer Service number: 1-800-562-0738.

For faster service, please have the model number, serial number, and receipt ready for the operator to assist you.

# Warranty Registration

Warranty registration

Please mail this warranty card to the address below within 30 days of purchase. Or you can register your product on line by going to [www.galanz.com/us](http://www.galanz.com/us)

**Galanz Americas, 55 Challenger Road, Suite 503, Ridgefield Park, NJ 07660**

PLEASE PRINT CLEARLY.

Name \_\_\_\_\_

Address \_\_\_\_\_

City \_\_\_\_\_ State \_\_\_\_\_ ZIP \_\_\_\_\_

Phone \_\_\_\_\_ Email \_\_\_\_\_

Model Number \_\_\_\_\_ Serial Number \_\_\_\_\_

Purchase Location \_\_\_\_\_

**You must attach a copy of your purchase receipt to validate your registration**