


正面

Projection size and distance			🚺 wowoto	POWERING ON/OFF	FCC Statement
Projection size dista Projection distance (m) 0.50 1.00 1.50 2.00 2.50 3.00	ance table (withou Screen width (m) 0.417 0.833 1.250 1.667 2.083 2.500	t keystone correction Screen height (m) 0.260 0.519 0.779 1.039 1.298 1.558	n) Diagonal screen size (inches) 19 39 58 78 97 116	<ul> <li>Power on:         <ol> <li>Ensure the AC adapter is connected with your projector (Please use the standard AC adapter), the red indicator will be on.</li> <li>Press " () "on projector &gt; 2 seconds to turn it on; If charging, the indicator light is red . If the charging is completed, the indicator light is purple.</li> </ol> </li> <li>Power off :         <ol> <li>Press " () "on the projector or on the remote control to power off the projector.</li> <li>Dialog will appear by pressing the " () " on the projector, users can make choices using projector panel or " &lt; " and " &gt; " on the remote control and then click on the panel or press " OK " again</li> </ol> </li> </ul>	This device complies with Part 15 of the FCc Rules. Operation is subject tothe following two conditions: (1) this device may not cause harmfulinterference, and (2)this device must accept any interference received including interference that may cause undesired operation. <b>Note:</b> This equipment has been tested and found to comply with the limitsfor a Class B digital device, pursuant to part 15 of the FCC Rules. Theselimits are designed to provide reasonable protection against harmfulinterference- in a residential installation.
Projection distance	reference image	58" 78"	97" 116"	<ul> <li>to confirm it</li> <li>1.2 When you choose Power off and press " <sup>(1)</sup> " again, the projector will be turn off, and its cooling system will be shut down at the same time.</li> <li>2. Unplug AC adapter of the projector.</li> <li>Warning indicator: When the warning indicator (as follows) lights up, the projector will power off automatically ;</li> <li>&gt; " Abnormal temperature ", indicator light turns to red and hin a slow flash, meaning that the projector is overheated. Please check whether the air filter is clogged and clean it in time.</li> <li>&gt; " Abnormal fan " indicator light turns to red and blicking rapidly meaning that the fan is working.</li> </ul>	This equipment generates, usesand can radiate radio frequency energy and, if not installed and used inaccordance with the instructions, may cause harmful interference toradio communications. However, there is no guarantee that interferencewill not occur in a particular installation. If this equipment does causeharmful interference to radio or television reception, which can bedetermined by turning the equipment off and on, the user is encouragedto try to correct the interference by one or more of the followingmeasure s: - Reorient or relocate the receiving antenna.



反面

## T9S系列 窝窝头中英文双面 折页说明书 六页三折双面印 尺寸:折前(315×190mm);折后(105×190mm) 材质:157g铜版纸 白色

