

刀模线  
折线  
出血线

型号:WLSP003  
尺寸:180x95mm

#### ⚠WARNINGS

- Only use the charging cable provided and a good quality USB power source.
- Charge the product in a well-ventilated area and avoid charging under pillows, blankets, or on flammable surfaces. Do not leave unattended while charging.
- To avoid damaging the headphones, please keep it away from direct streams of splashes and do not submerge into water.
- Do not expose this product to sources of heat. Do not expose to temperatures above 40°C, such as in a car on a hot day, or in direct sunlight.
- Prevent objects and debris from entering the device ports.
- To protect your hearing, keep the volume at a safe level and take regular breaks.
- Refer all servicing to qualified service personnel, which is required if this product is damaged in any way / is exposed to liquid, or does not operate normally.
- Children under age of 5 year must be supervised when using or handling this product.
- The battery is unreplaceable. If the battery is expanded, stop using and keep it away from children.

#### SPECIFICATIONS

Wireless version: V5.3  
Connection distance: 10 meters (barrier-free)  
Speaker: 3W  
Built-in Battery: 450mAh  
Input USB-C: DC 5V 1A Max  
Play time: 2 hours (at 100% volume)  
Charge time: Approx 1 hr  
Product Net: 53g  
Speaker frequency: 20-20KHz  
Frequency: 2.402-2.48 GHz  
Max EIRP:  
Working Temperature: 0-40°C




#### QUICK START GUIDE

##### WHAT'S INCLUDED:



##### 1. CHARGE YOUR BOOMA PULSE SPEAKER

Before using the speaker for the first time, fully charge it using the supplied cable. The light under the speaker's charging port will turn on to indicate that the speaker is charging and will switch off once it is fully charged.




前面

##### 2.CONNECT YOUR BOOMA PULSE SPEAKER


When the speaker is fully charged, press and hold the power button for 3 seconds. You will hear the sound "It's JellieMons". The LED indicator will then turn on to signal that the speaker is ON and ready to pair.



To connect, turn on Wireless in your phone settings and select BOOMA PULSE from the list of available devices. Once paired, you will hear a sound, "You are connected" to confirm a successful connection.



##### 3. USE YOUR BOOMA PULSE SPEAKER



##### Speaker

Turn ON/OFF	Press power switch for 3 seconds
Play/pause song	Press power switch
Answer phone call	Press power switch
Hang up phone call	Press power switch for 2 seconds
TWS twins connect	Press power switch twice
TWS twins disconnect	Press power switch twice

##### 4. CONNECTING TWO SPEAKERS

If you have two compatible BOOMA PULSE speakers, you can link them to create a stereo pair. Begin by connecting the first speaker to your phone or other device using Wireless as usual.

Then, turn on the second speaker and wait a few seconds. Double-press the power button on the second speaker, and you will hear a tone indicating the speakers are now linked.

Your audio will play through both speakers for a richer sound experience. To unlink the speakers, simply double press the power button on either speaker.

##### 5.PRODUCT SUPPORT

For the latest assistance, simply scan this QR code to access product support.



CHECK OUT OUR WHOLE RANGE AT  
[JELLIEMONS.COM](http://JELLIEMONS.COM)

JellieMons

背面