


正面



Screen display Smart  
Bluetooth earphonesc  
User Manual


Thank you for purchasing this product. It has a stylish appearance and high-quality sound quality, hoping to enrich your life. Please carefully read and strictly follow the instructions and precautions before using this product, and keep it properly for future reference.  
Kind reminder: After receiving this product, please charge it before the first use.

#### Product diagram



- 1 Full touch color display screen
- 2 Earphone compartment operation button
- 3 Type-C charging interface
- 4 Horn hole
- 5 Mic
- 6 Earphone charging contact point

#### Screen touch operation



- Up slide: shortcut button
- Right swipe: shortcut function
- Right swipe: shortcut function
- Downward: Message notifications

#### Charge mode

Please fully charge the earphones together with the charging case before first use, supporting wireless charging of the earphone compartment.

#### Hearing Protection

- Do not use at high volume for a long time to prevent damage to hearing.
- Do not adjust the sound too loud to prevent not hearing the surrounding sound.
- Do not use while driving.

#### Function Parameter

Bluetooth name	M5 Pro+	Bluetooth version	V5.3
Earphone battery capacity	25mAh*2	Earphone compartment battery capacity	400mAh
Standby time	5-7day	Bluetooth transmission distance	>10m
Music duration	3-3.5h		
Charging duration	Headphones for about 1 hour; Charging case takes about 1.5 hours		
Charger	Applicable to 5V/1A		

#### Headphone function usage

You can use multifunctional buttons to obtain one of the following functions:

##### Connecting Bluetooth

Search for Bluetooth name M5 Pro+for pairing connection for the first time.

##### Automatic reconnection

Open the headphone compartment and Bluetooth will automatically reconnect.

##### play/pause

In music playback mode, click pause playback and then click resume playback again.

##### Previous/Next

When playing music, double-click the left ear (L) multifunction button to switch to the previous track; Double click the right ear (R) multifunction button to switch to the next track.

##### Volume increase/decrease

long press the left ear (L) multifunction key to decrease the volume, and long press the right ear (R) multifunction key to increase the volume.

##### Launch voice assistant

In Bluetooth connection mode, click the multifunction button (L or R) three times in a row to start the voice assistant.

##### Answer/End call

When there is an incoming call, click the (L or R) multifunction button to answer the call, and click again to hang up the call.

##### Reject incoming calls

When there is an incoming call, long press the multifunction button on any earphone for about 3 seconds to reject the call.

#### Headphone compartment function usage

- After the device is turned on, enter the menu to find the download app, scan and download the QR code, download the app on your phone and install it, or scan the GS Fit QR code on the right or packaging box to connect and download (browser, WeChat, etc. can be scanned).
- Connected Device

- Scan code connection: After the device is turned on, enter the menu, find the download app, slide down to scan the "Scan code pairing" QR code, and directly scan the code connection in the app.
- Manual connection: After enabling Bluetooth on the phone, enter the APP and directly search for the Bluetooth name M5 Pro to manually connect.

Address book: Connect to the phone to synchronize the contacts on the mobile end; Dialing: Connect to a mobile phone to make a call, which can be made on the device; Call records: Connecting to a mobile phone can synchronize call records on the mobile end;

Record daily exercise data, including calories, activity time, steps taken, and distance.


Download music on your mobile phone and synchronize it to the headphone compartment on the app to play local music.

Connect the device and open the sensory game on the APP, where you can control and operate the game on the device.

Synchronize your phone album to view on your device.

You can search for devices in the app.

You can set 5 alarm reminders.



Scan the code to download the app

#### Headphone compartment function usage

Connecting the device allows remote control of the phone for taking photos.

Uploading and adding payment/receipt QR codes allows for offline payment collection;

Connect your phone and voice wake up the mobile app

Slide up to access the shortcut button, open the noise control, and choose between transparent mode or noise reduction mode.

(After connecting the headphone compartment, you can also set it by selecting "mode" on the APP.)

Includes notifications (volume adjustment, mute mode, vibration mode,) general (about the phone, call settings, language settings, time settings, restart, shutdown, factory restore, connect new phone) sound and vibration, focus mode (all day no disturbance, timed no disturbance) display and brightness (brightness adjustment, default brightness, screen display, screen off time, constant on time), battery, health reminder, and user guide.

#### Tips

- \*Please read the following content carefully before using this product. Incorrect usage methods or incompatible devices may damage your product or cause damage to this product;
- \*Please do not use sharp objects to scratch the surface of the outer shell of this product. Do not throw, shake, press or attempt to disassemble the product;
- \*When not in use for a long time, please ensure that this product is fully charged at least once within 3 months;
- \*Do not use chemicals or strong cleaning agents to clean this product;
- \*After charging your digital product, please unplug the connection cable in a timely manner to avoid consuming some of the battery of this product.

#### Note

- \*Be sure to carefully check whether the voltage of the charged product is compatible with that of this product when using it;
- \*Do not place in water, fire, high or low temperature environments;
- \*Do not let children touch or play with this product;
- \*Do not forcefully disassemble or modify the product to avoid damaging the protective device of the product, causing the battery to heat up, catch fire or explode;
- \*If there is any abnormal odor, high temperature (normal use generates heat but should not be hot to the hands), or shape change during use, charging, or storage of the product, it should be stopped immediately and the dealer should be contacted;
- \*The responsibility arising from the user's uncertainty about the use or incorrect placement of this product, which leads to a shortened or even damaged lifespan of this product, does not fall under warranty or manufacturer responsibility. We apologize for any inconvenience caused.

#### Warranty Statement

- Welcome to choose our company's products. If the product malfunctions or is damaged due to quality issues, please promptly send it back to the designated repair point or distributor. From the date of purchase, it is guaranteed to be refunded within 7 days and comes with a one-year warranty.
- If the malfunction or damage is caused by self disassembly or improper use, it is not covered by the warranty.
- Please keep this card properly. With this card, the warranty cannot be altered in any way.

#### Warranty scope

Quality issues that occur under normal use, not damage caused by external forces. But unauthorized disassembly, entry of foreign objects, dampness, tampering or tearing of labels on products, and any other visible human damage, as well as natural factors. Earthquakes, fires, floods, hurricanes, or wars are not covered by the warranty.

#### Warranty card

User Name: \_\_\_\_\_ Telephone: \_\_\_\_\_

Contact address: \_\_\_\_\_

Product name: \_\_\_\_\_ Model: \_\_\_\_\_

Purchasing date: \_\_\_\_\_ Y \_\_\_\_\_ M \_\_\_\_\_ D

#### Problem description:

\_\_\_\_\_

Date: \_\_\_\_\_

#### Certificate of conformity

Inspector: \_\_\_\_\_ Date of manufacture: \_\_\_\_\_ See product seal

88\*88MM


反面



智能屏显无线蓝牙耳机  
使用说明


感谢您购买本产品,本产品拥有时尚的外观与高品质的音质,希望能丰富您的生活.使用本产品前,请仔细阅读并严格遵守使用说明书和注意事项并妥善保管,以备查阅。  
温馨提示:当您收到本产品后,请在首次使用前先充电。

#### 产品图解



- 1 全触摸彩屏显示屏
- 2 耳机仓操作按键
- 3 Type-C充电接口
- 4 喇叭孔
- 5 Mic
- 6 耳机充电触点

#### 屏幕触摸操作



- 上滑:快捷按钮
- 右滑:快捷功能
- 左滑:快捷功能
- 下滑:消息通知

#### 充电模式

请于首次使用前将耳机同充电盒一起充满电,支持耳机仓无线充电。

#### 听力保护

- 请勿长时间在高音量状态下使用,以防损害听力。
- 请勿将声音调整过大以防听不到周围声音。
- 请勿开车时使用。

#### 功能参数

蓝牙名	M5 Pro+	蓝牙版本	V5.3
耳机电池容量	25mAh*2	充电盒电池容量	400mAh
待机时长	5-7天	蓝牙传输距离	>10米
音乐时长	3-3.5小时		
充电时长	耳机约1小时; 充电盒约1.5小时		
充电盒充电器	通用5V/1A		

#### 耳机功能使用

可使用多功能按键获得以下某种功能:

##### 连接蓝牙

首次连接搜索蓝牙名M5 Pro+进行配对连接。

##### 自动回连

打开耳机仓, 蓝牙自动回连。

##### 播放/暂停

音乐播放状态下, 单击暂停播放, 再次单击恢复播放。

##### 上一曲/下一曲

播放音乐时, 双击左耳 (L) 多功能按键切换至上一曲; 双击右耳 (R) 多功能按键可切换至下一曲。

##### 音量加/减

长按左耳 (L) 多功能键减音量, 长按右耳 (R) 多功能键加音量。

##### 启动语音助手

蓝牙连接状态下, 连续单击三次多功能按键 (L或R), 启动语音助手。

##### 接听来电/结束通话

当有来电时, 单击 (L或R) 多功能按键可接听来电, 再次单击可挂断来电。

##### 拒接来电

当有来电时, 长按任意耳机的多功能按键约3秒可拒接来电。

#### 耳机仓功能使用

- 设备开机后, 进入菜单找到下载APP, 扫描下载二维码, 下载APP到手机上并安装, 也可扫描右侧或包装盒上GS Fit二维码跳转下载(浏览器、微信等都可扫描)。
- 连接设备

- 扫码连接: 设备开机后进入菜单, 找到下载APP, 下滑扫描“扫码配对”二维码, 在APP内可直接进行扫码连接。
- 手动连接: 手机开启蓝牙后, 进入APP直接搜索蓝牙名M5 Pro进行手动连接。

记录当天的运动数据, 包括卡路里、活动时间、步数以及距离。

手机上下载音乐, APP端同步到耳机仓实现本地音乐播放。

连接设备在APP端打开体感游戏, 即可用设备控制操作游戏。

同步手机相册在设备上查看。

可以在APP查找设备。

可以设置5个闹钟提醒。



扫码下载APP

#### 耳机仓功能使用

连接设备可以进行AI对话。

连接设备可以遥控手机拍照。

上传添加收款二维码可以进行离线收款;

连接手机, 语音唤醒手机APP。

上传进入快捷按钮, 打开语音控制, 可选择通透模式或降噪模式。(连接耳机仓后也可在APP端“模式选择”进行设置)

包含通知 (音量调节、静音模式、振动模式,) 通用 (关于本机、通话设置、语音设置、时间设置、重启、关机、恢复出厂、连接新手机) 声音与振动、专注模式 (全天候、定时勿扰) 显示与亮度 (亮度调节、默认亮度、屏幕显示、熄屏时长、常亮时刻)、电池、健康提醒、使用指南。

#### 温馨提示

- \*请仔细阅读以下内容再使用本产品, 错误的使用方法或者不兼容的设备有可能损坏您的产品, 或导致本产品受损;
- \*请不要用尖锐物体刮擦本产品外壳表面, 请勿抛掷、摇晃或试图拆卸产品;
- \*长期不使用时, 请确保3个月内至少为本产品充满电一次;
- \*请勿使用化学物品或者强效清洁剂清洁本产品;
- \*在给您的数码产品充电工作完成后, 请及时拔出连接线, 以免连接线消耗本产品的部分电量。

#### 注意事项

- \*使用时务必认真核对被充电产品与本产品的电压是否兼容;
- \*请勿置于水中、火中、过高或过低温度环境中;
- \*请勿给儿童接触或玩耍本产品;
- \*请勿强拆、改装产品以免损坏产品的保护装置, 导致电池发热、起火或爆炸;
- \*产品在使用、充电或存放时, 如出现异常气味、温度过高 (正常使用会产生热量但不应该烫手), 或形状改变等异常现象应当立即停止使用并与经销商联系;
- \*用户不确定使用或不正确放置本产品导致本产品寿命缩短甚至损坏而带来的责任, 不属于保修责任或厂家责任, 敬请谅解。

#### 保修说明

- 欢迎您选用本公司产品, 若改产品因质量问题而引起的故障或损坏, 请及时送回指定维修点或经销商处。自购买之日起/天内包退, 1年内保修。
- 若发生自行拆卸或使用不当人为原因而引起的故障或损坏, 不在保修范围内。
- 请妥善保管此卡, 凭此卡保修, 不得有任何涂改。

#### 保修范围

在正常使用状态下出现的品质问题, 非外力破坏造成的损坏, 但擅自拆装、异物进入、受潮、产品上的标签被涂改或撕毁, 以及其他任何可见之人为损坏, 及自然因素, 如地震、火灾、水灾飓风或战争等, 均不在保修范围之内。

#### 保 修 卡

用户姓名: \_\_\_\_\_ 联系电话: \_\_\_\_\_

联系地址: \_\_\_\_\_

产品名称: \_\_\_\_\_ 规格型号: \_\_\_\_\_

购买日期: \_\_\_\_\_ 年 \_\_\_\_\_ 月 \_\_\_\_\_ 日

#### 问题描述:

\_\_\_\_\_

日期: \_\_\_\_\_

#### 合 格 证

检验员: \_\_\_\_\_ 生产日期: \_\_\_\_\_ 见产品封套

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.