## 80mm How to use the bracket Packing list How to use 1 x Magnetic Wireless Charger 1.Plug the charging cable into the appropriate adapter and then into Magnetic Wireless Charger 1 x Type-C to USB charging cable a wall outlet. 1 xUser Manual **User Manual** 2.Place the back of the phone with magnetic attraction function on the front of the product, it will be attracted to each other and automatically Compatible Models aligned with the charging position to start charging. 1. Magnetic wireless charging For iPhone: iPhone 15, iPhone 15 Plus, iPhone 15 Pro, Phone 15 Pro Max, iPhone 14,iPhone 14 Plus,iPhone 14 Pro,iPhone 14 Pro Max,iPhone 13mini, iPhone 13,iPhone 13pro,iPhone 13pro maxiPhone 12mini,iPhone 12, iPhone 12pro,iPhone 12pro max ① Open up to the right angle (2) Attach the product Specification yield Model: Y103 15W/10W/7.5W/5W Output Phone: Input: 5V-3A,9V-2A E =\_\_\_ ③ Completion of the bracket

<section-header><section-header><section-header></section-header></section-header></section-header>	About the FCC   This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shauld be installed and operated with minimum distance 20cm between the radiator & your body.   This device complies with part 15 of the FCC rules operationis subject to the following two conditions:   (1)this device may not cause harmful interference.   (2)this device must accept any interference received including. interference that may cause undesired operation.	FCC Warning:   Any Changes or modifications not expressly approved by the party responsible for compliance couldvoid the user's authority to operate the equipment.   Note: This equipment has been tested and foundto comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in aresidential installation. This equipment generates uses and can radiateradio frequency energy and if not installed and used in accordance with the instructions may cause harmful interference to radio communications.   However there is no quarantee that interference willnot occur ina particular installationIf this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:   -Reorient or relocate the receiving antenna.   -Increase the separation between the equipment and receiver.   -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.   -Consult the dealer or an experienced radio/TV technician for help.	If you are not satisfied, please contact us.
---	--	---	---

尺寸: 80\*105mm 材质: 128g双铜过哑膜

105mm