

**ZTE CORPO**

ZTE A37

GSM Dual-ba

User Manual

Copyright © 2006 by ZTE

All rights reserved.

No part of this publication

any form or by any means,

microfilm, without the prior writ

ZTE operates a policy of

the technical specifications in t

Edition: 1<sup>st</sup> edition, May., 2006

SW Edition: P103B2SWDV1.0.

## **1 GENERAL INFORMATION**

- 1.1 WELCOME .....
- 1.2 SECURITY .....
- 1.3 SAFETY PRECAUTIONS .....

## **2 GETTING STARTED**

- 2.1 KEY DEFINITIONS .....
- 2.2 DISPLAY SYMBOLS .....
- 2.3 TECHNICAL PARAMETERS .....
- 2.4 BATTERY .....

*2.4.1 Removing the battery*

*2.4.2 Charging the battery*

2.5 CONNECTIONS .....

2.5.1 *SIM Card.*

2.5.2 *Inserting &*

2.5.3 *Power on/o*

2.5.4 *Unlocking*

2.5.5 *Connecting*

### **3 BASIC OPERATION**

3.1 MAKING A CALL

3.2 ANSWERING A C

3.3 CALL MENU .....

### **4 FUNCTION MENU**

4.1 USAGE AND STR

4.2 PHONE MENUS.

4.2.1 *Call Histor*

4.2.2 *Call Di*

|       |                    |
|-------|--------------------|
| 4.2.3 | <i>Call Fire</i>   |
| 4.2.4 | <i>Call Setti</i>  |
| 4.3   | PROFILES .....     |
| 4.4   | MY FAVORITES ..... |
| 4.5   | SETTINGS .....     |
| 4.5.1 | <i>Phone Se</i>    |
| 4.5.2 | <i>Clock Set</i>   |
| 4.5.3 | <i>Display S</i>   |
| 4.5.4 | <i>Security S</i>  |
| 4.5.5 | <i>Fact. Sett</i>  |
| 4.6   | MESSAGES .....     |
| 4.6.1 | <i>Messages</i>    |
| 4.6.2 | <i>MMS.....</i>    |
| 4.7   | CAMERA .....       |
| 4.8   | TOOLKIT .....      |

|        |                     |
|--------|---------------------|
| 4.8.2  | <i>Full-screen</i>  |
| 4.8.3  | <i>Calculator</i>   |
| 4.8.4  | <i>Stopwatch</i>    |
| 4.8.5  | <i>World Clock</i>  |
| 4.8.6  | <i>Games.....</i>   |
| 4.9    | WAP .....           |
| 4.10   | STK (SIM TOOL)      |
| 4.11   | NAMES.....          |
| 4.11.1 | <i>Adding New</i>   |
| 4.11.2 | <i>Searching...</i> |
| 4.11.3 | <i>Editing.....</i> |
| 4.11.4 | <i>Deleting...</i>  |
| 4.11.5 | <i>Making an</i>    |
| 4.11.6 | <i>Detail.....</i>  |
| 4.11.7 | <i>Add New N</i>    |

*4.11.9 Settings...*

*4.11.10 Batch Op*

*4.11.11 Adding to*

## **5 TEXT INPUT .....**

5.1 OVERVIEW .....

5.2 ABC AND ABC

5.3 123 MODE .....

5.4 PREDICTIVE TE

5.5 CHARACTER C

## **6 TROUBLESHOO**





## 1.1 Welcome

Thank you for using ZTE A37

To guarantee the mobile phone's quality, please read the manual carefully and keep it for further reference.

The pictures, symbols and contents of this manual may not be completely identical with the actual product.

## 1.2 Security

- If your mobile phone is lost or stolen, please contact the relevant agencies to ban the use of the phone to avoid any losses resulted from unauthorized use.
- To protect your mobile phone's security, please do not use the phone in the following situations:

- Set PIN code of the SIM card
- Set handset lock code
- Take it with you as you travel

## 1.3 Safety Precautions

This section includes some important information that you should read this information before using the phone.

### Operational Precautions

- Please use your phone properly. Do not use the phone as holding a wireless device (within 15 centimeters) from your body.
- Do not touch the antenna. This may affect call quality and may require a restart of the phone.
- Keep the phone out of the reach of children. Do not use as a toy.

### **Precautions While Driving**

- Please pay attention to the location of your phone in the area of the vehicle while driving.
- Pull off the road and park the vehicle before using the phone.

### **Precautions for Medical Devices**

- When using your phone, keep it at least 8 inches (20 centimeters) away from your body. Do not carry the phone in your pockets or bags to minimize the potential for interference. If necessary, use a hands-free device.
- Some phones may interfere with medical devices. If you experience interference, you may want to use alternative methods of communication.
- If you use any other personal electronic device, consult the user manual for your device to determine if it may interfere with your medical device.

please pay attention to the  
phone if required.

### **Mobile phone**

- Please use original accessories from the manufacturer. Using any other accessories may affect the performance, hurt your health, or violate related national regulations.
- Turn off your phone before charging. Do not use a charger with a chemical or abrasive cleaning agent.
- As your mobile phone contains a battery, keep it away from magnetic items such as credit cards.
- Using the phone near a strong magnetic field or personal computer can cause data loss.
- Do not expose your mobile phone to high temperatures.

- Prevent liquid from leaking into the phone.
- Do not drop, knock or hit the phone or its internal circuit boards.
- Do not connect the phone to a power source.
- Do not attempt to disassemble the phone.
- Do not store the phone in a hot or cold environment.
- Do not charge the mobile phone while it is in use.

#### **Precautions for Potentially Explosive Environments**

- Switch off your phone when in a potentially explosive atmosphere, such as a gas or dust atmosphere.
- Do not remove, install, or repair the phone in a potentially explosive atmosphere. Failure to do so may result in injury or even death.
- To avoid possible interference with other electronic equipment, you are near electrical equipment, or you are in a potentially explosive atmosphere, do not use the phone.

### **Precautions for Electronic Devices**

- Some electronic devices such as mobile phone if inadequate use may affect the operation of the vehicle. Please consult the manual for details.

### **Safety and General Use in Vehicles**

- Safety airbag, brake, speed sensor, etc. may be affected by wireless transmission. Please refer to your automobile provider for details. The airbag deployment and the airbag deployment are not guaranteed with great force and cause injury or death.
- Please turn off your mobile phone when driving where the use of 2-way radio is prohibited.

### **Aircraft Safety**

- Please turn off your mobile phone when flying.

mobile phone when it is in use.  
You should get aircrew's permission before using a mobile phone when it is in use.

- If the mobile phone has a low battery, set your alarm setting to ensure you wake up during flight.

### **Battery use**

- Do not short-circuit the battery.
- Do not store battery in a fire or explosion.
- Do not disassemble or damage the battery, overheating, explosion.
- Please store the battery in a safe place.
- The battery can be recharged. When the operating time is short, it is normal, it is time to replace the battery.

evidence of aging.

- Return the wear-out bat  
environment regulations.

### Exposure to radio frequency

#### Radio wave exposure and Spe

- The handset is designed  
waves. This requirement  
margins designed to ass
- The radio wave exposure  
Specific Absorption Ra  
standardized method with  
in all used frequency ban
- While there may be diff  
models, they are all desi  
waves.
- The SAR limit recommen
- The highest SAR value fo  
is 1.492 W/kg(1g)
- The highest SAR value fo



- [SAR compliance for b](#)  
[similar accessories tha](#)  
[provide at least 1.5 cm](#)  
[the users body](#)

**Warning:** If the battery is damaged or comes into contact with the eyes or skin, seek medical attention immediately and consult with a doctor.

## 2.1 Key Definition



**Left Soft key**

Execute functions of the in



**Right Soft key**

Execute functions of the in



**Dial key**

Make and answer calls. Br



**End key**

Finish or refuse a call. Pow



**Up/Down/ Left/Right key**

**Up/Down key:** Roll the p  
down when editing. The  
direction keys in games.

**Left/Right key:** Roll the  
shortcut keys in standby

**OK key:** The middle ke  
operation.





~



**0~9 Number**

Enter numbers and chara

They could be set as dire




**\* key and**

**Note:** In this manual **press**  
**holding a key** means you


## 2.2 Display Symbols

 ☐ Signal strength

 ☐ New message; No

 ☐ Bar all calls

 ☐ Bar black list

 ☐ Only friends' call

 ☐ Indicate battery l

 ☐ Activate call dive

 ☐ Enable mute mo

 ☐ Keypad is locked

 ☐ Indicates the ph



☐ GPRS online



☐ Roaming

## 2.3 Technical Parameters

### Handset

Type

Dimensions ☐ W×L×H ☐

Weight

### Battery

Continuous standby time

Continuous talk time

For other parameters about

## 2.4 Battery

unpacking. A new battery pack should be recharged three times.

#### **2.4.1 Removing & Installing the Battery Pack**

- Remove: Push down the release button on the bottom of the battery and then lift the battery away from the device.
- Install: Place the bottom of the battery into the device until it clicks into place.










#### 2.4.2 Charging the Battery

- Connect the handset and the power adapter (see Figure 2-10 with arrow.) Then plug the power adapter into a power outlet.
- A charge indicator icon  appears on the battery icon. The battery is charged in the animation.
- When the battery level indicator shows 100%, it means charge has been completed. After the stop of charge animation, the whole charge process needs to be repeated for the first three times. After the third time, the charger may become hot.
- Please disconnect the charger after the battery is fully charged.



**Warning:**

- Please put the phone  
40°. Please use cha

- Please charge the battery before using the phone. When the battery is low, the phone displays a warning “Low Battery”.
- The phone’s talking time is limited by the signal strength and the use of features in different environments. In practice, the actual talking time may vary. In poor signal conditions, work environments, or when using features, the actual talking time may be shorter.

## **2.5 Connecting to the Internet**

### **2.5.1 SIM Card**

Please insert a valid SIM card into the phone. The phone can only be used by any GSM mobile phone network. Don’t touch the metal surface of the SIM card. The SIM card can be lost or destroyed. Keep it safe.

**Warning:** Please power off the phone before removing the SIM card. Removing the SIM card while the phone is powered on may damage the SIM card.

### **2.5.2 Inserting & Removing the SIM Card**

battery.

- Pull the SIM card cover out of the battery compartment.
- Put SIM card into the cover.
- Insert the SIM card cover into the battery compartment.





### 2.5.3 Power on/off Your Phone

Hold **End key** to power on or off the phone.

The mobile phone will automatically power on after power off. If the PIN is not valid after power on, then the phone will enter the PIN code.

**Enter PIN Code** ——if SIM card is not set.

**Enter lock Code**——if hardware lock is set.

**Searching** ——search for network.

### 2.5.4 Unlocking the SIM Card

By setting PIN (personal identification number) or PUK (personal unlock key) code, you can protect your SIM card.

- Method to unlock the SIM card:  
Press **End key** to power on the phone, then press **OK** soft key [OK].

If you enter an incorrect PIN code, the phone will be locked by the network and the phone will display "SIM card locked".

Note: When the phone is locked, you can only make emergency calls.



SIM card; please change

- Method to unlock the  
or Left soft key [OK].

**Note:** If you forget your h  
authorized local customer

### **2.5.5 Connecting to t**

After the SIM card and the  
search for the network.

After a few seconds, the han  
standby mode. Besides rec

- Press Right Soft key
- Press Left Soft key o

**Note:** If “Insert SIM card  
calls.

### 3.1 Making a Call

You can make or answer calls from the top right corner of the screen shown below.

- Making DDD: Enter telephone number, then press the End key.
- Dialing extension number:  
Method 1: Dial the telephone number, then enter the extension number, and the extension automatically after going to the extension.

Area code    Exchange

- Making IDD: Hold \* key, then dial the preset symbol of an international phone number and then dial the phone number and then press the call key.
- Dialing the number in the phonebook: Press the call key, then press the saved in a list of the phonebook. Press Calls and Missed Calls. Press the call key to view all the call logs. When you press the call key, you can check the list by pressing the call key.
  - View **All calls** by pressing the call key.
  - View full screen **Call logs** by pressing the call key.
  - View **Names** by pressing the call key.
  - All the numbers in the phonebook.

**Note:** Up/Down/Left/Right

**Settings-Fastkey Settings.**

## 3.2 Answering a Call

If **Anykey Answer** is activated, you can press any key (any key) to answer a call in call waiting mode.

## 3.3 Call Menu

When in in-call mode, you can press the **Call Menu** key to access the call menu. The methods are the same as for the call menu in the process of communication. Multiparty need network to support. Please contact your network service provider.

If you couldn't answer the call, you can do the following operations:

- Hold/ Retrieve: Keep the call on hold and retrieve the call.
- Names: Display information about the call.
- Earpiece Volume: Adjust the earpiece volume.

■ DTMF On/Off ☐ Enable

■ **Multiparty**

- **Answer:** Hang on the line.
- **Join All Calls:** Add all calls to the conference.
- **Hold All Calls:** Hang up all calls.
- **Private:** Converse with one party at a time.
- **Exclude:** Keep one party out of the conference.
- **Busy:** Send busy tone to all parties.
- **End All Calls:** End all calls.

**Note:** Some menu items may not be available.

**Swap** will appear only when two parties are in the same time.

## 4.1 Usage and Structure

- Scrolling search function  
key in standby
- In function menu, you can  
Right Soft key according

## 4.2 Phone Menus

In standby mode, press  
access the PhoneMenus interface

#### 4.2.1 Call History

- View calls list

Select **All Calls** to view all calls.

Select **Missed Calls** to view missed calls.

Select **Received Calls** to view received calls.

Select **Dialled Calls** to view dialled calls.

In the calls list interface,

to delete all call records.

detailed submenus:

- Send Message: Send messages as creating messages.
- IP Dial: Dial an IP call if the number has been set before.
- Detail: View the detail of the call.
- Save Number: Save the number.
- Add to Blacklist: Add the number to the blacklist.

- Call Duration: You can view the approximate total duration of the call. You can clear all call duration records.

- All Calls Info:

- Cost Setting: In the menu, you can read or set the line cost.

**Note:** This function needs



SIM card, all numbers in

#### **4.2.2 Call Diverting**

This service enables yo

Please contact your serv

##### ■ Set Diverts: Set diverts

- All Calls: Divert all c
- When Busy: Divert c
- No Answer: Divert c
- Unreachable: Divert

network.

When you have set com

chosen:

- On: Only registered
- Off: Delete the diver
- Status Check: Que

After choosing one of the a  
the following options, you c

- All Services:
- Voice Calls: C
- Data: Only di
- Fax: Only div
- Messages: O
- All Except Ms

➤ Cancel All

Enter the divert interface,  
services.

### **4.2.3 Call Firewall**

#### **4.2.3.1 Incoming Calls**

- Current Settings: Press S

- Black List: Press **Select**
  - If you have not added any contacts to the Black List, press **Option-Add** to add the contacts.
  - If you have added some contacts to the Black List, press **Option-Add** to select such options: **Black List**.
- Friend List: Press **Select**
  - If you have not added any contacts to the Friend List, press **Option-Add** to add the contacts.
  - If you have added some contacts to the Friend List, press **Option-Add** to select such options: **Friend List**.

#### 4.2.3.2 Outgoing Calls

Before entering the function, the phone password is 1234.

- Current Settings:

- Bar All: Bar all outgoing
  - Bar in List: Bar all numbers  
any number in the barred list
  - Cancel All: Cancel the bar
  - Barred List: Directly enter the numbers you want to bar
- All.** If you have not added any numbers to the barred list, press **Add** to select **Add**, and then press **OK**.

#### 4.2.4 Call Settings

- Anykey Answer: If **On** except End key, and Right
- Minute Minder: Choose minute when answering t
- Connected Minder: Select
- DTMF Tones: Select **On/**
- Call Waiting: Select **On/**

the current status of this  
call if a third person c  
provider for detailed us

- IP Settings: You can se  
the Names or the calls  
the phone number that

## **4.3 Profiles**

In standby mode, press F  
profiles interface.

- Select Profile: You can select a profile for the phone. The options are: Normal, Message, and Emergency. You can select a profile before leaving factory. You can select a profile after leaving factory.
- Edit Profile: Change the profile settings.
  - Alert Type: Select the alert type.
  - Ringing Tone: Many phone tones.
  - Ringing Volume: Adjust the ringing volume.
  - Speaker Volume: Adjust the speaker volume.
  - Key Tone: Select to turn on or off the key tone.
  - Warn Tone: Select to turn on or off the warn tone.
  - Missed Alert: Select to turn on or off the missed alert call.
  - Message Alert: Select to turn on or off the message alert. You can select to turn off the alert.
  - Power on/off Ring: Select to turn on or off the power on/off ring.

## 4.4 My Favorites

In standby mode, press **Menu** to enter the My Favorites interface.

- **Photos:** Press left soft key to enter the camera.
- **Pictures:** Press left soft key to enter the from a browser or from
- **Ringtones:** press left

Press Up/Down key to select  
the following submenu:

- Play: Play the selected message
- Set ringtone: Set the selected message as ringtone
- Information: View the attributes of the selected message
- Delete: Delete the selected message
- Delete All: Delete the all messages
- **Others:** press left soft key to view the messages sent or received from attachments
- **Space Usage:** check the space usage

## 4.5 Settings



setting interface.

#### **4.5.1 Phone Settings**

Select and enter the **Phone**

- Language: Select the language
- Own Number: Edit/view own number
- Fastkey Settings: Set the fastkey.  
key.
- Auto Lock Keypad ☐ Set the keypad to lock automatically. If you select this option, the screen is switched to sleep mode when the keypad is locked. A prompt on the interface

#### **4.5.2 Clock Settings**

You can set date and time

Use Scroll key to switch

correctly inputting the date

### 4.5.3 Display Settings

- Wallpaper: Select your favorite wallpaper.
- Contrast: Adjust the screen contrast.
- Brightness: Adjust the screen brightness.

### 4.5.4 Security Settings

Security features protect your data.

**Note:** You need to input handset lock code as soon as possible.

- PIN code: SIM password.  
Select **On/Off** to enable or disable PIN code.  
set a new PIN code.

**Note:** Three consecutive failed attempts will lock the handset.

code may be provided to  
your network service pro  
soon as possible.

- Handset Lock: Handset  
Select **On/Off** to enable  
to set a new handset loc

**Note:** The default hands

- Network Call Bar: You ca  
to improve security lev  
detailed use. The netwo  
enable your call restricti

- International Call: Ba
- All Except Home: Ba
- Incoming Calls: Bar
- Incoming if Abroad:

After choosing one of the a  
services:

- All Services: Restr
- Voice Calls: Only
- Data: Only restric
- Fax: Only restrict
- Messages: Only r
- All Except Msgs: I

When you have set types

- On: The restriction
- Off: Delete the res
- Status: Query if th

➤ **Cancel All:** Select Ca

**Note:** You need to input

Three consecutive times

#### **4.5.5 Fact. Settings**

In this menu, you can s  
settings.

### **4.6 Messages**

If the network supports  
receive text short messa  
receive voicemail. Please  
In standby mode, press  
the message menu inter

---

#### **4.6.1 Messages**

- New message

Please confirm message  
messages.

- In message interface  
message input interface  
Input".)

- When you finish enter

select **Send to One, Send**

- Select **Save** to save the destination number according to the select number in the list of the opposite party's number. Select **Save** select number. Select **Save** numbers from the Name list. prompt information on the screen.

**Note:** The SMS centers can support more than 70 Chinese characters.

#### ■ Inbox/Outbox

- Select **Inbox** to check the messages saved in SIM.
- In the message list, select the message to do the following operations:

- Forward: Transfer
- Voice Call: Call the

messages in the Inbox.)

- Send (The menu
- Extract Number.:

the screen. If you select or  
editing or dialing.

➤ Delete All: Delete all t

## ■ Message Settings

You must set up necess

Access **Msg Settings** sub

➤ **Msg Centre:** Input th  
this number from your se

➤ Msg Validity: In the pe  
message till it is received



- Templates: When you press the **Template** key. In this menu, you can select a template to use for your messages.
- Status Report: If the network is not working, you can select this option to inform you after the service is restored. This option is only available if you need the network to send messages.
- Save Edit: Select when you are editing a message to save the changes.
- Msg Firewall:
  - Current Settings: Select this option to view the current settings for all short messages, send and receive. You can select to block or allow numbers in the message. You can also select to block or allow messages.
  - Msg Black List: Select this option to view the current settings for all short messages, send and receive. You can select to block or allow numbers in the message. You can also select to block or allow messages.

Select and Access **Voice Mail**

➤ Select **Get Voice Mail** message.

➤ **Voice Mail Num.:** Set

■ Cell Information

➤ You can view

➤ Select **Setting**

#### 4.6.2 MMS

If your SIM card supports

■ New Message

Press **MMS-New Message**

following submenu:

➤ **Edit Text:** Select to e

Press left soft key [OK] to

enter the following subme

◆ **Done:** Press done to

- **Send later:** Save

next time you send the message

- **Subject:** Write a

- **To:** One or more

send the message

- **CC:** Phone number

copy of the message

Press **More** to check

- **BCC:** phone number

carbon copy of the message

other addresses)

- **Priority:** Set the

- **Lifetime:** Select

server while trying to de

- ◆ **Edit Text:** Go back to edit the text of the selected object
- ◆ **Add Picture:** Select to add a picture to the selected object
- ◆ **Add Sound:** Add a sound to the selected object
- ◆ **Delete Object:** Delete the selected object
- ◆ **Preview:** Select to preview the selected object

Press **More** to check the full list of actions

- ◆ **Add Page** □ Add a new page to the presentation
- ◆ **Object Properties:** Display the properties of the selected object
- ◆ **Page Properties:** Display the properties of the selected page

- **Inbox**
- **Sent**
- **Outbox**
- **Drafts**
- **Templates**
- **Settings**

➤ **Read Reports:**

- **Send Report:** Send a report for a message.
- **Request Report**

message.

➤ **Deliver Receipts**

- **Send Receipt:** Send a receipt for a message.
- **Request Receipt**

MMS.

➤ **Lifetime:** Set the maximum lifetime for a message.

➤ **Advanced:**

- **Message Center**
- **WAP Profile:** Set the WAP profile for a message.
- **MMS Download**

or download MMS after

- **Span Filter:** Set the span filter for a message.

## 4.7 Camera

The phone has a built-in camera.

In standby mode, press **Menu** to access the camera interface.

The following icons appear on

 Brightness

 Zoom

 Frame

- key to adjust its parameter
- Frame: Press Left/Right key to adjust its parameter  
Up/Down key to adjust its parameter
- Face: Press Left/Right key to adjust its parameter  
Up/Down key to adjust its parameter
- Large: Press Up/Down key to adjust its parameter
- Multiply Normal/Multiply Large: Press Up/Down key to select its parameter
- Press OK key to catch the parameter  
press Right soft key [back]

## 4.8 Toolkit

In standby mode, press **Menu** key to enter the interface

#### 4.8.1 Alarm Clock

Your phone can set up to

- Set Alarm: Select **Set Ala**  
to instructions: alarm typ  
ring tone.

The alarm clock is valid only wh  
will powered on automatically  
automatically if you select “no



- List Alarms: Select **List** to view the alarm clocks settings. Press **C** to enter the alarm clock settings. Press **E** to enable/disable it.
- Define Rest Day: Select **Rest Day**. Workday alarm will not ring on the Rest Day. then press **Select/Cancel**.
- Clear All: Select **Clear All**.

#### 4.8.2 Full-screen Calendar

Use **Scroll** key to select the date from January 1, 1901 to December 31, 2099.

#### 4.8.3 Calculator

- Press 0~9 Number key to input the number.
- Press Up/Down/Left/Right key to move the cursor.

calculator. Press **Left soft**

**Note:** This calculator has 1  
in long division.

#### 4.8.4 Stopwatch

You can measure time and take

- Press **OK key** to start time
- Press **OK key** to stop the
- Press **Left soft key** or **O**

#### 4.8.5 World Clock

The world Clock function provid

- You can view the time o
- navigation screen of Wor
- Press **Left soft key** [**Sav**
- Press **End key** to quit.

#### 4.8.6 Games

- Tetris: The options are
  - New Game: Start a new game
  - Set Lines: Select the number of lines to delete
  - Help: Check the rules
- Push Box: The options are
  - New Game: Start a new game
  - Load Game: Read the saved game
  - Help: Check the rules

#### 4.9 WAP

- **Home:** Press to go into the home screen
- **Resume:** Press to enter the resume screen

up/down key to choose the  
address and delete.

- **Empty Temp.:** Delete the  
page.
- **Enter address:** Input the  
page.
- **Settings:**

➤ **Connection Settings**

edit, change name or delete

Press edit to enter the

- **Homepage:** Edit the
- **Image Settings:**
- **Connection Type**
- **Connection Opti**
- **Gateway Setting**
- **Bearer:** Set Data

➤ **Security Cert.:** Press

➤ **Push Security:** Sel

■ **Push Messages:** Enter  
the information, load th

■ **GPRS Info:** Press to cl

■ **Fastkey operation:** in  
And then press **OK key**

➤ **Stop:** Stop web brow

➤ **Go back:** Move to th

➤ **Bookmarks:** Press

➤ **Add bookmark:** Ad

➤ **Enter address:** Ent

➤ **Home:** Move to the

➤ **Top:** Move to the top

➤ **Refresh:** Refresh th

page. Select to enter the image  
it.

## 4.10 STK (SIM Tool)

In standby mode, press **Me**  
interface.

This service needs the ne  
the network service provid  
For more information, plea

## 4.11 Names

In standby mode, access t  
It shows **List empty** when  
pressing Left Soft key. Sav  
the first character of the n

- In the names list interface, the available options are as follows:

- Search
- Edit
- Delete
- IP Dial
- Detail
- Add New Name
- Settings
- Batch Operation

- In the names list interface, press the soft key [**Option**] to access the following options:

- Send Message
- Edit
- Delete

- Add to Speed
- Copy to MS
- Move to MS
- Add to Blacklist
- Add to Friendlist

- Press Left/Right key to switch

be seen. Press End key to

Whether saved in SIM card

number. Number types co

Office, Fax or Pager.

Records saved in the SIM

doesn't appoint the record

Besides, there are six gro

Society and VIP.



#### 4.11.1 Adding New Name

In the names list interface, press the **+** key to save new number into the phone memory.

If **SIM Card** is selected:

- Enter the name of the number.
- Enter the phone number.

If **Phone Memory** is selected:

- Press OK key, enter the name.
- Select the group.
- Enter the phone number.
- Select Caller Icon.

If the name is saved into the phone memory, at least the name and one icon must be chosen, the default is **m** and the default group is the current group.

#### **4.11.2 Searching**

- In the names list interface, click on the search icon to open the search dialog box. Enter the name you want to search.
- Quick-search: In the Name list interface, click on the search icon to open the search dialog box. Enter the name of the record of the name with s.
- Sort principle: Sort by AS.
- Match principle: If match.

#### **4.11.3 Editing**

In the names list interface, click on the edit icon to open the edit dialog box. Enter the Name record.

#### **4.11.4 Deleting**

In the names list interface, click on the delete icon to open the delete dialog box. Enter the information of the current record.

#### **4.11.5 Making an IP Call**

In the names list interface, press the **Call** button to the current chosen number.

#### **4.11.6 Detail**

In the names list interface, press the **Detail** button to the interface. You can press the **Call** button to make a call.

#### **4.11.7 Add New Name**

Add a new record.

#### **4.11.8 Sending Message**

In the names list interface, press the **Message** button to the interface of editing messages. You can press the **Call** button to create messages.

#### **4.11.9 Settings**

- Ringing Tone: You can select a ring tone from the list.
- Save Nos. to: You can select a destination to save the numbers.
- Used Space: You can view the used space of the phone memory, records in SIM card and the used space of the SIM card.
- Copy/Move to MEM/SIM: You can copy or move the numbers from the phone memory or SIM card. When copying or moving, if the destination space is full, the operation will fail.
- Speed Dial List: List the speed dial numbers.

#### **4.11.10 Batch Operation**

This function provides you to batch copy or move the numbers from the SIM card or phone memory. Note: Please be careful to use this function.

#### **4.11.11 Adding to Speed**

Dial List. You can set at  
standby mode, if you ho  
automatically. Press **Del**

## 5.1 Overview

Your mobile phone provides the numeric input and predictive text input. When you are in a field that allows numeric input, a numeric mode indicator in the upper right corner of the field indicates the different input modes.

## 5.2 ABC and abc modes

- Use the number key from 1 to 9 to enter a digit.
- Press the key labeled with ABC or abc to switch between the two modes.
  - Once for the first letter.

- And so on

- To insert a space, press the space key on the display.
- Press \* key to open a list of words, and press Ok key to select a word.

### **5.3 123 mode**

- The 123 mode enables you to enter numbers and symbols.
- Press the keys corresponding to the numbers and symbols you want to enter.

### **5.4 Predictive text**

You can enter any letter with a predictive text dictionary.

- To write the desired word, press the key corresponding to one letter. For example, to write the word K.

word is not correct, press  
found.

## 5.5 Character Cha

Refer to the table below for mo

| key |    |
|-----|----|
| 1   | 1  |
| 2   | Al |
| 3   | D  |
| 4   | G  |
| 5   | JK |
| 6   | M  |
| 7   | P  |
| 8   | TU |
| 9   | W  |
|     |    |



|                |  |
|----------------|--|
| * key          |  |
| # key          |  |
| Up/Down key    |  |
| Left/Right key |  |
| End key        |  |

Check the following reference information for more details.  
Contact your distributor if you cannot find the information.

1. “Enter PIN code” is shown on the screen.  
Input the PIN or input the default PIN (1234) if you have not  
set “off” if you do not want to set a PIN.
2. “Insert SIM” is shown on the screen.  
Turn off your phone and make sure the SIM card is inserted correctly.
3. “Unlock” is shown on the screen.  
Press Unlock and then enter the PIN.
4. No key tone volume.  
Check the keypad setting in the Settings app.
5. No incoming ring tone.  
Check the ringing tone and volume in the Settings app.

6. No alarm tone when

Check the profile setting

7. A phone number

Check whether call restri

8. A phone call can't

Check whether call restri

9. Short message ca

Check the Msg centre se

10. Some menus rela

Check the profile settings