


User Manual

V4 Bluetooth Stereo Headphone With Local Player Function (Internal Memory 32GB)



Special Features

- Open-Ears design, this headphone that leaves your ears open for awareness of surroundings for a safe and connected listening.
- Wireless connection Bluetooth Audio Playback function to enjoy the Bluetooth Audio music from your mobile device.
- Local Player Audio playback function which supporting MP3, WMA, WAV, APE and FLAC audio file formats.
- IPX5 water resistant designed that it can be used in the rain and for intense workouts



Cautions

- Do not place naked flames, such as lighted candles on or near the product.
- Do not use or store this product in a place where it is subject to direct sunlight, heat, excessive dust or vibration.
- Do not clean this product with other liquids.
- Do not push foreign objects into the slots or holes in the product.
- Do not attempt to open this product yourself. There are no user serviceable parts inside.
- Do not allow children access to plastic bags.

Safety Warnings

- Before using this product, read and follow all warnings and instructions.
- This product is not intended for use by young children. Young children should be properly supervised.
- This product is intended for household use only and not for commercial or industrial use.
- No naked flame sources, such as lighted candles, should be placed on the product.
- Ventilation should not be impeded by covering ventilation openings with items such as newspapers, table cloths, curtains and the like.
- Make sure the unit is adjusted to a stable position. Damage caused by using this product in an unstable position or by failure to follow any other warning or precaution contained within this user manual will not be covered by warranty.

We, suggest retaining the packaging in case for future transport of the product.

If at any time in the future, you should need to dispose of this product please note that: All batteries and accumulators need to be removed from this product (Removal of Waste Batteries and Accumulators).


 WARNING:	<ul style="list-style-type: none"> • When participating in the traffic listening to a personal music player can make the listener less aware of potential dangers such as approaching cars.
---------------------	--



WARNING:


- Prolonged exposure to loud sounds from personal music players may lead to temporary or permanent hearing loss.

1. What's in the Box




2. Headphone Buttons Control

Back View



Right View



3. About Headphone's battery

- The device has an internal non-user-replaceable rechargeable lithium battery.
- For the first time use the device, let it charging for about 1 ~ 2 hours or until the [Status LED] indicator light from solid red turned to light off.
- The lithium battery of electronic devices is sensitive to long periods of inactivity. It is important to recharge it at least once a month to keep it functioning properly.

4. Terminals for charge and upload music

Important: Headphone is equipped with terminals which let you connect for charge and **upload music files**. To avoid performance matter, make sure the headphone's terminals and terminals plug of USB cable are completely dry and without dirty before to use for connection.

To charge:

- **Note:** The headphone will shut-down other operating function automatically when you have connected Headphone with USB Power Adapter or Computer for charging or **upload music functions**.
- Use the Magnetic Terminals Plugs of the provided USB Charging Cable attach onto the Headphone's Terminals. And make sure that the magnetic terminal plug and terminals are proper placed. Please see illustrated for in below:



- Then, connect the Type-A plug of the USB Charging Cable to a USB port of your computer or USB Power Adapter.
- The [Status LED] indicator will light solid red when the device is in charging.

- The [Status LED] indicator will light off from solid red when fully charged.
- Disconnect the USB Charging Cable from Headphone and Computer/Adapter once battery fully charged.

To upload music:

Note: Headphone is supports only for MP3, WAV, WMA, FLAC, APE audio file formats.

- Before you use the headphone **Local Player** function, connect the Headphone's terminals to a USB port of your computer by the provided USB Charging Cable for upload the desired music onto it internal memory;
- Once connected, a hard drive named **"V4"** will be detected and appeared in "This PC" on your computer;
- On your computer, use the **"Copy-and-Paste/Drag-and-drop"** functions to selects your desired audio file(s) or folder(s) drop them onto the root-directory of the V4's drive.
- On a Windows computer, disconnect the V4's drive by using the "Safely remove hardware" function.
- On a Mac computer, disconnect the V4's drive by dragging the icon to the trash can.
- Disconnect the USB Charging Cable once upload music is completed.
- Or, leave it for charge the lithium battery.

5. How to wear

Note: If wearing your headphones not the right way could cause discomfort and degraded the listening performance.

- When wearing the Headphone, bring it behind the back of the base of your neck and position the ear-hooks on your ears. Please see illustrated in below:



- This guarantees that the headphone's speaker sets send sound/music with best performance to your ears.