160*70MM 80书写纸 正反面单色印刷 风琴折 再对折

正

反

1

物品清单

耳机

便携充电仓

快速指南

Type-C数据线

产品介绍

LED灯

Type-C接口

开机配对

打开充电仓的盖子把耳机取出，当LED灯闪烁时耳机将进入自动配对模式。

充电操作

耳机充电中LED灯：充电中，蓝灯亮。
充满电，灯灭。
电池仓充电LED灯：充电中，红灯闪。
充满电，红灯亮。

List of items

Earbuds

Charging case

User manual

Type-C Charging cable

Product introduction

LED display lamp



Type-C Interface

Power on pairing

Open the cover of the charging case and remove the earbuds.When the LED lights flash alternately, the earbuds will enter automatic pairing mode.

Charging operation

During charging, the blue light is constantly on
Fully charged, the charging case light is off, and the earphones lights are off
Charging LED indicator for the charging case: During charging, red light flashing. Fully charged, red light on.

2

蓝牙配对


⊗取出

左右耳机分别从充电仓取出

在耳机开机状态下

确保手机蓝牙打开，在设备中搜索T670进行配对

配对成功

⊗放入

充电仓自动为耳机充电
耳机进入关机状态

首次需打开手机界面手动搜索连接，之后每次打开充电仓拿出耳机，耳机即将自动与设备配对连接

Bluetooth pairing


⊗ Take out

Open the charging case and take out the wireless earphone

When the wireless earphone is turned on

Mobile Bluetooth is turned on, and the device name is searched for T670 for pairing

Pairing succeeded

⊗ Put into

The charging case automatically charges the wireless earphone, and thewireless earphone is turned off

For the first time, you need to open the mobile phone interface to manually search for connections. After that, each time you open the charging case and take out the wireless earphone, the wireless earphone will automatically pair and connect with the device.

3

使用操作

对耳模式

插放/复停：单击L/R
接听/挂断电话：单击L/R
拒接电话:长按L/R1.5秒

对耳模式

上一曲：双击左耳

下一曲：双击右耳

对耳模式

音量+：三击左耳

音量-：三击右耳

对耳模式

开机：取出耳机自动开机 /长按3秒
关机：关闭充电仓自动关机 / 长按5秒/
在未连接状态下耳机5分钟自动关机
召唤语音助手：长按2秒L/R

Operation

Binaural mode

Play/Pause: Single click L/R
Answer/end a call: Single click L/R
Reject a Call: Long press L/R for 1.5 seconds

Binaural mode

Previous Track: Double-click the L earbud
Double-click the R earbud

Binaural mode

Volume Up: Triple-click the L earbud
Volume Down: Triple-click the R earbud

Binaural mode

Power On: Take out earbuds to power on / long press 3S
Power Off: Put earbuds back to charging case/ long press 5S/ Earbuds automatically power off after 5 mins in disconnected state
Activate Voice Assistant: Long press the L/R for 2S

4

耳机佩戴



1、拿出耳机　2、戴着耳后佩戴　3、调整耳机罩舒适位置　4、耳机准备就绪

Wireless earphone wearing



1. Take out the wireless earphone　2. Wear along the back of the ear　3. Adjust the headset to a comfortable position　4. Headphones ready

5

产品参数

产品型号	T670
蓝牙版本	蓝牙5.3
耳机电池	25MAH
充电仓电池	300MAH
充电接口	Type-C 连接口
充电时长	1.5H
蓝牙连接输送距离	10M
待机时间	100天
音乐时间	3小时

注意事项

- 长时间使用耳机可能会造成听力损害，请合理安排使用时间
- 请勿使用不合格充电器和高电压电流充电
- 请勿丢掷，避免损坏造成产品损坏
- 请勿自行拆解，修理或改造本产品
- 请勿使用化学溶剂擦拭本产品

Product parameters

Product Model	T670
Bluetooth version	Bluetooth5.3
Earphone battery	25MAH
Charging case battery	300MAH
Charging interface	Type-C connector
charging time	1.5H
Bluetooth transmission distance	10M
Standby time	100Days
Music time	3H

Matters needing attention

- Long time use of earphones may cause hearing damage, please arrange your time reasonably
- Do not use unqualified chargers and high-voltage current for charging
- Do not throw to avoid product damage due to falling
- Do not disassemble, repair or modify this product by yourself
- Do not use chemical solvents to wipe this product

6

产品中有害物质名称及含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
印刷电路组件	○	○	○	○	○	○
外壳部分使用件	○	○	○	○	○	○

本表格依据SJ/T11364的规定编制
○:表示该有害物质在该部件的所有均质材料中的含量低于GB/T26572规定的限量要求以下。
×:表示该有害物质至少在该部件的某一均质材料中的含量超出GB/26572规定的限量要求。
备注:除了"全球limit"的项目外，其它全球技术发展水平限制而无法实现有害物质的替代。

三包凭证

本产品售后服务承诺严格依据《中华人民共和国消费者权益保护法》、《中华人民共和国产品质量法》和《三包规定》制定，服务内容如下：


2. 在不违反以下"退换条件"以及本产品在正常使用情况下的任何其他条款下，自购买之日起7日内，如因产品质量问题发生故障，您可以选择免费退货。
3. 在三包有效期内，进行下列情况之一的，应当提供维修或者更换服务，由此产生的费用及运输费用由销售者负担：
退换条件
1. 未经许可擅自拆机、改动过机板——；
2. 认证标志不齐全（即下面这四个标志：3C自己的那四个圈圈认证公司认可的认证标志，CE认证，FCC认证，ROHS认证）或者伪造、涂改、严重的标志的，即产品的认证标志不齐全的；
3. 进行过非授权维修或拆机，改动过程序或软件的；
4. 保修卡超过有效期限，且无法提供购机发票、维修记录或者其他证明材料的；
5. 因不可抗力（如地震、火灾、洪水等）造成损坏的；
6. 其他非产品质量问题的情况。

三包有效期：T670
执行标准：GB4943.1-2022
检验员：OK
检验日期：

FCC ID: 2A2BN-K00035

The name and content of harmful substances in the earbuds

Part Names	Hazardous Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as case	○	○	○	○	○	○

This form is compliance with SJ/T11364.
○: Indicates that the hazardous substance contained in each of homogeneous materials of the part is below the limit required by GB/T26572.
×: Indicates that the hazardous substance contained in each of homogeneous materials of the part exceeds the limit requirements specified in GB/T 26572.
The parts marked with "X" on the form are all not fault due to the technology of GB/T 26572 limitations. Substitution of substances.

Product and its components
In addition to batteries and their annex electronic components, all parts dependent on the product manufacturers contracts has purchased and not marked with the above components.

Electronic and electrical products sold in the People's Republic of China must mark this 10000 the number in the logo represents the product under normal use.Environmental protection use period.

Warranty certificate

After-sales service card Intent of this product to strict accordance with the law of the People's Republic of China on the Protection of Consumer Rights and Interests and the Law of the People's Republic of China on Product Quality, after-sales service is as follows: 1. Within 7 days from the next day after you sign for the product, if the fault situation described in the warranty regulations occurs and is confirmed by maintenance center, you can handle the item exchange or repair services free of charge according to the following:
2. Within 12 months from the next day when you sign for it, the product will be repaired free of charge the freight buyer will pay) after the fault conditions described in the warranty repair regulations is confirmed by the after-sales service center.

Warranty regulations

1. This product have the entry of any human, outpage gun warranty for one year.
2. The warranty service is only valid under normal use. If the products not used properly, or if the product is damaged due to improper handling or installation without our company's approval, wrong use or negligence, or the damage caused by natural disasters, the products is not covered by the warranty of this brand.
3. Please take the original card with you during maintenance and provide it to the seller together with the product. Otherwise, the warranty service will not be available.
4. The warranty period for the main unit of the product is one year from the date of purchase.
5. Functional faults caused by various damages, unless classified as minor quality problems are the appearance of the product can only be repaired, not replaced or returned.
6. If the warranty service does not comply with the above warranty regulations, the Company shall have the right to interpret the above regulations.

Product warranty card	Purchased date: year month date
Warranty given	☐ Non-warranty replacement ☐ 1-day replacement ☐ 1-year warranty
Buyer information	Contact person: Telephone: Contact address:

Certificate of qualification

Product model: T670
Implementation standard: GB4943.1-2022
Test results: Pass
Inspector: OK
Inspection date:

FCC ID: 2A2BN-K00035

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
--Increase the separation between the device and receiver.
--Connect the device into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment