



The diagram illustrates the components of the Galaxy Buds2 Pro. It shows the open charging case with two buds inside, highlighting the LED light. The Type-C charging port is shown on the back of the case. The MFB (Touch Control) and LED light are shown on the side of the bud. The Magnetic charging connectors, L/R logo, and Talking mic are shown on the bottom of the bud.

Mode 1

LED

ON

Mode 2

LED

2s

ON

2. En el estado de apagado, y cuando los auriculares no estén en el estuche de carga, presione y mantenga presionado el botón MFB en los auriculares derecho e izquierdo durante 2 segundos para encenderlo con la luz LED blanca parpadeando.

2. Se non mettere gli auricolari nella custodia, basta premere il pulsante MFB per 5 secondi sull'auricolare R/L per spegnerli.

Note: The earbud will reconnect to the paired device by priority. If you want to pair to the second smartphone, please disconnect Bluetooth on the paired smartphone.

Nota: l'auricolare si riconnetterà al dispositivo accoppiato per priorità. Se si desidera associare il secondo smartphone, disabilitare Bluetooth sullo smartphone associato.

www.xmpow.com | support@xmpow.com
MPOW TECHNOLOGY CO., LTD
 Copyright © MPOW Inc. All rights reserved