


1.6 User Manual

CP0104_BTstereoMan_LabTest_0.ai

COVER PAGE



INSIDE PATTERN



CP0104_BTstereoMan_LabTest_1.ai

16

01

Product Specifications

Bluetooth Specification:	Version 1.2
Bluetooth Profile Supported:	Headset, Handsfree and A2DP Profiles
Range of Frequency:	2.4GHz Spectrum
Dimensions:	53.5mm (L) x 25.5mm (W) x 26mm (H)
Nominal Charging Time:	Within 3 hours
Talk Time*:	Up to 6 hours
Stereo Playback Time*:	Up to 6 hours
Standby Time*:	Up to 150 hours
Weight:	27 grams

* may vary due to users' operation mode and mobile phone settings


Contents

Getting to Know Your Bluetooth Stereo Clip Headset.....	2
Wearing Your Bluetooth Stereo Clip Headset as a Mono Headset.....	3
Charging Your Headset.....	4-5
Nominal Charging Time.....	5
Talk, Standby and Stereo Playback Time.....	5
Low Battery.....	5
Turning Your Headset On and Off.....	5
Turning the Built-in Buzzer On and Off.....	5
Pairing Your Headset.....	7-8
Using Your Headset.....	9-10
Answering a Call.....	9
Answering a Call when Listening to Stereo Audio.....	9
Ending a Call.....	9
Rejecting a Call.....	9
Dialling from Your Mobile Handset.....	9
Voice Dialling from Your Headset.....	10
Last Number Redialling from Your Headset.....	10
Listening to Stereo Audio from Your PC.....	10
Adjusting the Volume.....	11
Removing the Pairing.....	11
Troubleshooting.....	12
Safety Information.....	13
Care and Maintenance.....	14-15
Product Specifications.....	16

02

15

Getting to Know Your Bluetooth Stereo Clip Headset



Getting Started

To use your Bluetooth Stereo Clip Headset ("headset"), please follow these simple steps

- Charge your headset
- Pair your headset with a Bluetooth-enabled mobile handset

Built-in Battery

- Do not attempt to replace the headset's battery yourself as it is in-built and is not changeable.
- Charge the battery in accordance with the instruction supplied with this user guide.
- Only use the manufacturer supplied charger when charging the headset.

Charging

- Only use the manufacturer supplied charger when charging the headset.
- Do not disassemble the charger as it may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the headset is subsequently used.
- Do not use the charger outdoors or in damp areas.
- Only charge the headset's built-in battery in accordance with the instructions of this user guide.
- Avoid charging the headset in extremely high or low temperatures.

CP0104_BTstereoMan_LabTest_2.ai

14


03

Care and Maintenance

Headset

- Consider turning your headset off before placing it in your pocket or bag. If the MFB is accidentally depressed, your mobile handset may place an unintended call.
- Do not expose the headset to liquid, moisture or humidity as it is not waterproof.
- Do not use abrasive cleaning solvents to clean the headset.
- Do not expose the headset to extremely high or low temperatures.
- Do not dispose of the headset in a fire as it will result in an explosion.
- Do not expose your headset to contact with sharp objects as this will cause scratches and damage.
- Do not stick anything inside the headset as this may damage internal components.
- Do not attempt to disassemble the headset as it does not contain serviceable components.
- If you do not use the headset for long periods, be sure to store it in a dry place, free from extreme temperatures and dust.


Wearing Your Bluetooth Stereo Clip Headset as a Mono Headset



04

13

Charging Your Headset



(fig.4)

The Bluetooth Stereo Clip Headset comes with a built-in rechargeable battery. Prior to using the headset, it is recommendable to charge the battery fully for the first time.

Safety Information

- Check local laws regarding use of a mobile handset and headset while driving. If you use the headset while driving, ensure your attention and focus remains on your responsibility of driving safely.
- Never allow children to play with the headset – small parts may be a choking hazard.
- Observe all signs that require an electrical device or RF radio product to be switched off in designated areas. These could include hospitals, blasting areas, and potentially explosive atmospheres.
- Turn off your headset prior to boarding an aircraft. Do not use your headset in an aircraft.
- Never mount or store your headset over any air bag deployment area as serious injury may result when an air bag deploys.
- Do not open or mutilate the built-in battery.
- Dispose of batteries according to local regulations. Do not dispose as household waste.

CP0104_BTstereoMan_LabTest_3.ai

12

05

Troubleshooting

If you are unable to connect your headset and mobile handset, please try the following:

- Ensure your headset is turned on and is properly charged.
- Ensure the headset is paired with your mobile handset.
- Ensure your mobile handset's Bluetooth feature is activated. Please refer to your mobile handset user guide for specific instruction.
- Ensure the headset is within a maximum of 10 meters of your mobile handset and there are no obstructions, such as walls or other electronic devices in between.
- If you are unable to receive stereo audio from your mobile device, please ensure your mobile device is capable of providing stereo audio.

If the above steps do not resolve your problem, please recharge the headset and remove your mobile handset battery for a while.

If there is no reaction when pressing the buttons, press the Reset Key (fig.1) to return to factory default setting. The headset is turned on again and all pairings are cleared.

The Bluetooth Stereo Clip Headset is compliant with and adopts the Bluetooth Specification 1.2. However, interoperability between the device and other Bluetooth-enabled products is not guaranteed because it depends on compatibility. For more information on the compatibility between the device with other Bluetooth-enabled products, please check with the manufacturer.

Charging Your Headset

Connect the charger to an AC wall outlet and the Charger Plug to the headset's Charging Socket (fig.4). The LED will be red while charging.

NOTE Charging indication will be delayed for a few minutes if the headset has not been used for a long time or if the battery is drained.

Nominal Charging Time

Charging the battery fully is normally within 3 hours. When the battery is fully charged, the LED will turn blue and remains on for 30 minutes. Disconnect the charger from the AC wall outlet and the headset. Press and hold the MFB (fig.1) for 2 seconds to turn the headset on, please refer to "Turning Your Headset On and Off" on the next page.

Talk, Standby and Stereo Playback Time

The fully charged battery offers up to 6 hours talk time; up to 150 hours standby time and up to 6 hours stereo playback time. When no calls are in progress, the headset remains ON in standby mode.

Low Battery

When the headset is ON and the battery becomes low, the LED flashes red and the headset emits a beep every 1 minute. Please recharge the battery as described above.

06

11

Turning Your Headset On and Off

Turning On the Headset

Press and hold the **MFB** for 2 seconds until you hear a short beep. The LED will flash blue.

NOTE Press the MFB again each time you turn on the headset to reactivate pairing so that the connection between the headset and the mobile handset is resumed. For pairing, please refer to "Pairing Your Headset" on pages 7-8.

Turning Off the Headset

Press and hold the **MFB** for 3 seconds until you hear a long beep. The LED flashing stops.

Turning the Built-in Buzzer On and Off

Turning On the Built-in Buzzer

Press and hold the **Volume +** for 2 seconds until you hear a long beep. The LED flashes blue.


NOTE The built-in buzzer is set to "ON" when shipped.

Turning off the Built-in Buzzer

Press and hold the **Volume -** for 2 seconds until you hear 2 short beeps. The LED flashes red. Now, when there is an incoming call, the ringing tone can be heard through the earphone only.

Adjusting the Volume

Press the **Volume Key** repeatedly until you reach the desired volume level.



Removing the Pairing

You may want to reset the headset to its original settings. This also clears all current pairings.

1. Ensure the headset is OFF.
2. Press and hold the Volume Key until the LED alternately flashes blue and red rapidly.
3. Release the Volume Key.
4. Press and hold the Volume Key again until you hear 2 beeps.
5. Recharge the headset for a few seconds.

The headset is now turned off and returns to the original settings. All current pairings are cleared.

CP0104_BTstereoMan_LabTest_4.ai

10 |

07 |

Using Your Headset

Voice Dialling from Your Headset

If your mobile handset is equipped with a voice dialling function, simply press the MFB on your headset and when you hear a beep, say the voice tag.

NOTE Please make sure to record voice tag into the mobile handset first before using voice dialling function.

Last Number Redialling from Your Headset


Short press the MFB on your headset twice.

NOTE The above functions are only applicable to mobile handsets with Bluetooth Handsfree Profile. Functionality varies depending on the mobile handset model you have. Please refer to your mobile handset user guide for additional information.

Listening to Stereo Audio from Your PC

By connecting your headset to your PC through i.Tech's Mini Bluetooth USB Dongle v1.2, you can listen to stereo audio from your PC (please refer to "Bluetooth Audio Connection through Mini Bluetooth USB Dongle v1.2 Quick User Guide").

Pairing Your Headset



Prior to using your Bluetooth Stereo Clip Headset for the first time, you must pair it with a Bluetooth-enabled mobile handset.

The information on the next page describes pairing instruction for a typical Bluetooth-enabled mobile handset. Headset pairing procedure is subject to different models of mobile handsets.

10

7

08 |

09 |

Pairing Your Headset

1. Place the headset and the mobile handset no more than 1 meter apart and ensure there is nothing in between.
2. Ensure the headset is Off.
3. Press and hold the MFB until the headset LED alternately flashes blue and red.
4. Activate your mobile handset's Bluetooth function by referring to your mobile handset user guide for details.
5. Set the mobile handset to search for Bluetooth devices within about 1 meter as instructed in the mobile handset user guide and select "i.Tech" from the list.
6. Enter the preprogrammed passkey "0000" and press "OK" to pair your headset and mobile handset. When the pairing is complete, the headset LED will flash blue rapidly for 5 times followed by a long beep.
7. Press "Return" to go back to your mobile handset's main menu. For certain mobile handset models, a headset icon will be shown on the screen. You should now be able to make and receive calls using your headset.

NOTE If the pairing cannot be completed within 2 minutes while the pairing mode is activated, the headset LED flashes purple with 3 beeps and the headset is turned off. Please repeat the above pairing procedures.

Using Your Headset

Answering a Call

When there is an incoming call, you will hear ringing through the earphone and the built-in buzzer. Press the MFB to accept the call or answer the call via your mobile handset in the normal way.

If you want to stop the buzzer from ringing, press the Volume Key once. You now only hear the ringing tone through the earphone.

Answering a Call when Listening to Stereo Audio

Press the MFB once to answer the call and when finished, press the MFB once to resume stereo audio.

If the other party you are speaking to ends the call, stereo audio will automatically resume without having to pressing the MFB.

NOTE To receive stereo audio from your mobile handset or PDA, please make sure they support the Bluetooth A2DP profile.

Ending a Call

Press the MFB to end your call or end the call via your mobile handset in the normal way.

Rejecting a Call

To reject an incoming call during ringing of the headset, press and hold the Volume Key for 2 seconds until you hear 2 beeps.

Dialling from Your Mobile Handset

Simply make calls on your mobile handset in the normal way.

8

9