
品牌:ozzie	备注:
型号:H200CL	第一版 ,
设计项目:说明书	
文件名称:H200C_ozzie_OZ-H200C_说明书_折页_01	
说明书尺寸:60mm X 90mm(展开尺寸:300mm X 90mm)	
工艺说明:105g铜板纸,单色正反面印刷,折页(折扇形).	
制作版本:01	



正面

TECHNICAL PARAMETERS TWS DISCONNECTION NOTES BEFORE USE NOTE 1. Press and hold the Play/Pause-button on one of the speakers for about 2 seconds until you hear a "beep"sound This product is designed with full attention for safety performance To ensure safe operation, please follow the following rules: del: H20 ent has been tested and found to cor Bluetooth: V5.1 for a Class B digital device, pursuant to Part 15 of the FCC Rules. Recharge vour speaker. Bluetooth: V5.1 Speaker: ØSzmm 4Q 6W*2 Built-in rechargeable battery: Li-on, 3.7V, 3600mAh Charging time: 3 hours Playing time: 6 hours Input: 5.0V ==4.0A Product Size: 77*81*191mm Product Weight: 4500 1. Place the speakers in a stable position avoid fall and cause These limits are designed to provide reasonabl harmful interference in a residential installatio Prace the speakers in a stable position avoid fail and cat damage or personal injury. Do not drop, disassemble, open, crush, bend, puncture, FAULT AND MAINTENANCE This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio First fault: connection failed burn speaker. 3. Do not close to any heat source (such as radiators, heating (1) Please check whether the multifunction indicator light flashes equipment, stoves, or other heat-generating equipment) where munications Please power on your speakers if the light isn't on. Product Weight: 450g the use of speakers. However, there is no guarantee that interference will not occur in a Range: Up to 10mWaterproof level: IPX7 Please charge the speaker if the light is still not on 4. Please send professional maintenance staff to repair for any particular installation (2) Please turn off the other Bluetooth devices, if there are many reason damage . If this equipment does cause harmful interference to radio o If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. Before wiping with a dry cloth to clean the speakers, set the power switch to the off position and unplug the power cord from the power outlet. Health considerations, please adjust the sound to a suitable level. (2) rease can be due to be bound out of the barres of the b PACKAGE INCLUDING 1pcs* H200CL wireless sp 1pcs* Product manual 1pcs* Type-C USB cable FCC STATEMENT: Second problem: The music player appears sound breaks. - Connect the equipment into an outlet on a circuit different TWS CONNECTION device complies with Part 15 of the FCC Rules. from that to which the receiver is connected This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation. (1) View the distance between the player and the speaker has not - Consult the dealer or an experienced radio/TV technician for 2: Press and hold the Play/Pause-button on one of the speakers for n exceeded offective Bluetooth connection distance about 2 seconds until you hear a "beep" sound. The default is t primary speaker that you operated the Play/Pause-button of th 8-12meters. (2) Ensure there is not any obstacle between the play device and FCC Radiation Exposure Statement: spaker for pairing initially. 3: Release play/Pause button. It can take a few more seconds ies with FCC radia (10 m). WARNING: forth for an uncontrolled environment (3) Check the playback device or whether the speaker is in a low before speakers connect to each other. Check the indicator lights power state anges or modifications not expressly approved by the party to distinguish L/R channel: The white light on one speaker is responsible for compliance could void the user's authority to to distinguish L/R channel: The white light on one speaker is flashing white for every 3 seconds that should be the left channel (the primary speaker); the white light on the other speaker is solid white that should be the right channel 4: Go into the Bluetooth menu on your smartphone and pair the speakers with your phone by selecting the speaker model number (it will only display 1 number which is both combined into one) perate the equipment.

PDF

TROUBLESHOOTING The speaker does not turn on ?

The speaker does not turn off or does not respond? set your speaker. hold the power button for tomatically reset the speaker and turn it off

There is no sound?

Make sure that your Bluetooth device is within range Ensure there is no obstacles in the way that can block/disturb the eck via the device's Bluetooth connection if the speaker is

There is poor sound quality? vice closer to the speaker or try removing obstacles between them.

Cannot connect the device with the speaker? connect other connected devices and then try again. u can force a disconnection by moving out of Bluetooth range

In order to avoid harming the product performance, please do charge your device each 3 months at least.