


SOUNDSTREAM

USER GUIDE



www.hoxx.hk

Structural Schematic Diagram

Speaker Mesh

Indicator Light

Pick up/ Hang Off Button

ON/OFF

Product Parameters

Name	SOUNDSTREAM
Model	SOUNDSTREAM
Battery type	3.7V/500mAh Li-Polymer
Play time	4 hours
Specification	60*60*62mm
Charging voltage	5V/1A (MAX)
Transmission distance	≤10M
Bluetooth specification	Bluetooth V5.0

In order to correctly use the Cannon blue-tooth speaker for users, it ensures that the performance of the Cannon blue-tooth speaker is good, please read carefully and comply with the matters.

FCCCERoHS

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

needing attention

- Be sure not to impact the host seriously.
- Be sure not to contact chemical drugs such as benzene and thinner, etc.
- Please don't get close to strong magnetic field and electric field.
- Please keep away from direct light or heating apparatus.
- Be sure not to disassembly, repair and conduct transformation by oneself.
- Electricity shortages will auect blue-tooth distance or will cause bluetooth disconnect easily. Please charge in time.
- As to waste packaging, batteries and old electronic products, please properly handle them through classifying.
- When finish using the speaker,please turn it ou to avoid loss of power.

Consumers shall be solely responsible for all the consequences as a result of violating said warning and inappropriate use that leads to personal and property damages, for which the Company shall not be held liable.

User Guide

- Use USB-Micro cable contained in the package to connect USB power adapter or insert into standard USB port on computer etc. When charging, the red indicator light are on. After the batteries are charged fully, the red indicator light off.
- Long press the button and the back, you will here" DI", then the LED flash, open the phone bluetooth find the name of " SOUNDSTREAM" , then connect, will here "DIDO" it will stop flash and connect with stay white color.
- Connect bluetooth to play music, white light flashing, side switch music when playing short press pause/play.
- In Bluetooth mode,the ring tone will come from the mobile phone and speakers at the same time.Short press the side button to answer calls, short press it again to hang up on the phone.Double-click can call back ,long press can decline calls.
- In order to keep a good results, please make the phone call under 30min the Bluetooth If you don't want to use Bluetooth answer, you can switch by mobile phone.

After-sale Services

Thank you for purchasing Cannon Bluetooth speaker.

1.Warranty period:

1 year for Power Bank, and 6 months for charging cable.

2.Warranty range:

a.Product without label is out of warranty.

b.Original package and accessories are required.

c.Warranty service is only used for product quality problems,

the following does not belong to the warranty scope:

- improper electrical wiring and connections.
- Attempted repairs or modifications by unauthorized engineers.
- Equipment, components have exceeded the warranty period.
- Natural disaster, such as earthquakes or fire.
- Fail to provide warranty card and related sales receipts.

Warranty Card

Name	
Place of purchase	
Tel	
Model	
User	
Seller	
Time of purchase	

Manufacture:

Address:

QC PASS

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.