

The Instruction for RC3053707/01BR & RC3053708/01BR



Manual Pairing (Manual RF Activation)

1. Install the remote with batteries and approach it to the STB.

Note: The batteries are not installed in the remote when it's sold

2. Press & Hold MUTE & ENTER keys until the green LED stop blink.

Manual UnPairing (Manual RF Deactivation)

1. Press & Hold MUTE & SELECT keys. Release the keys until the LED blinks twice.
2. Key in 9 - 8 - 7.

The statement is as below:

This device complies with Part 15 of the FCC Rules. Its operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.