




Quick Start Guide



tracker
+ Safe & Found

Thank you for purchasing Tracker + Safe & Found! Please follow these simple but important instructions for optimal use of your new tracker.

1. Getting to Know Your Tracker



- Power key:** Press and hold the Power key to turn the device on/off. Quickly press 3 times to activate a Family Alert.
- Speaker:** Alert the user with a beep sound when the light sensor detects changes, or when the Find My Device feature is enabled.
- Light sensor:** Ability to detect changes in light.
- Magnetic charging terminals:** Charge your device via the included USB cable and travel adapter.
- LED indicator:** Display the current status.
- | | |
|-----------------------|---------------------------------|
| ● Solid yellow: | Battery charging |
| ● Solid green: | Battery fully charged |
| ● (●) Blinking red: | Low battery or alert |
| ● (●) Blinking green: | Pairing mode |
| ● Solid green for 2s: | Paired |
| ● Solid red: | Received Find My Device command |
| ● No light: | Standby |

2. Charging the Battery

- Unplug the USB cable from the back of the device. The magnetic charging terminals on the back of the device. They will be automatically aligned.
- Once those are aligned, connect the USB end to the travel adapter.
- Connect the travel adapter to an electrical outlet to fully charge the device.
- The LED indicator will light up when charging.




Power Tracker On & Off

- To turn the device on, press and hold the **Power key** until the LED indicator blinks.
- To turn the device off, press and hold the **Power key** until the LED indicator blinks.

3. Installing the Safe & Found App and Creating A Tracker Account

If you already have the Sprint Safe & Found app, skip to step 4. If you don't have the Sprint Safe & Found app yet, visit Google Play or App Store to download and install Safe & Found app.



Note: Once Safe & Found is installed, follow the instructions on screen to set up your Safe & Found account.

4. Connecting Your Tracker to Your Safe & Found Account

Follow these steps to connect one or more trackers to your Safe & Found account by following these simple steps:

- Click the top-left **Menu**.
- Tap **Connect New Tracker** option.
- Tap **Tracker**.
- Confirm that your tracker is powered on with the green light blinking and tap **Continue**.
- Give a name to your tracker and add a personalized photo if desired.
- Scan the QR code on the back of the tracker, or manually type in the IMEI.
- Tap **Continue**.

Your tracker should now be successfully paired with your Safe & Found account.



5. More Information

- For more information on device features, how to access advanced app services and personalize your overall experience, visit www.sprint.com/tracker or www.coolpad.us. Additional information may also be found at www.coolpad.us.
- For coverage maps check www.coverage.sprint.com.

Trademarks and Copyrights

©2019 Coolpad Technologies Inc. Coolpad and the Coolpad logo are registered trademarks of Yulong Computer Telecommunication Scientific (Shenzhen) Co., Ltd. All rights reserved. Other trademarks and trade names are the property of their respective owners. The trademarks of other companies are used herein for identification purposes only and are subject to change. Reproduction, transfer, distribution of the contents herein in any manner without the prior written permission of Coolpad Technologies, Inc. is prohibited. Coolpad Technologies, Inc. reserves the right to add, modify or delete any of the contents herein or withdraw the documents at any time without prior notice and without assigning any reason therefor.

©2019 Sprint. All rights reserved. Sprint and the logo are trademarks of Sprint. Other marks are trademarks of their respective owners.