

EUT SETUP PHOTOS

BLE CE-Front View(POE)




BLE CE-Side View(POE)






BLE CE-Front View(Adapter)

BLE CE-Side View(Adapter)





RE View(9kHz~30MHz)(POE)

BLE RE-Front View(30MHz~1GHz)(Adapter)





BLE RE-Back View(30MHz~1GHz)(Adapter)

BLE RE-Front View(30MHz~1GHz)(POE)






BLE RE-Back View(30MHz~1GHz)(POE)

RE-Front View(1 GHz~18GHz)






RE-Back View(1 GHz~18 GHz)

RE-FrontView (18 GHz~25 GHz)





RE-Back View (18 GHz~25 GHz)