

microlab



MAGICUP
BLUETOOTH
SPEAKER



Prior to initial use, please read the manual carefully

Important Safety Instructions

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions – All the safety and operating instructions should be read before this product is operated.
2. Keep these instructions – The safety and operating instructions should be retained for future reference.
3. Heed all warnings – All warnings on the apparatus and in the operating instructions should be adhered to.
4. Follow all instructions – All operating and use instructions should be followed.
5. Do not use this apparatus near water – The appliance should never be used near water or moisture – for example, in a wet basement or near a swimming pool, and the like.
6. Do not plug with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including appliances) that produce heat.
9. Only use attachments/accessories
10. Use only with the cat, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cord or rack is used, use caution when moving the cart/appliances combination to avoid injury from tip-over.
11. Unplug the apparatus during lightning storms or when unused for long periods of time.
12. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
13. **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects



Important Safety Instructions

filled with liquids, such as vases, shall not be placed on apparatus.

14. **CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
15. **WARNING:** The battery (battery or batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.



16. This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

Warning: To reduce the risk of electric shock, do not remove cover (or back) as there are no user-serviceable parts inside. Refer servicing to qualified

personnel.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.

17. Correct Disposal of this product. This marking indicates that this product should not be disposed with other household waste throughout the EU.
- 
- To prevent possible harm to the environment, human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.
18. No naked flame sources, such as lighted candles, should be placed on the apparatus.



return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling. No naked flame sources, such as lighted candles, should be placed on the apparatus.	Disclaimer: All symbols and logos belong to the respective brand holder or registered holder. All specifications and information are subject to changes without further notice. Slight variations and differences might appear between the printed photos and actual product due to product enhancement. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Minivola Electronics Co., Ltd is under license. Other trademarks and trade names are those of their respective owners.
---	---

Important Safety Instructions

Introduction

19. Replacement parts - When replacement parts are required, ensure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.
20. Try to install the product near a wall socket or extension cord and shall be easily accessible.
21. The highest environmental temperature suitable for this product is 0°C to 35°C for indoor use only.

Remove all packaging from the unit. Retain the packaging. If you dispose it please do so according to local regulations.

The following items are included:



MAGICUP SPEAKER



User Manua



USB Cable

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.


Features

Specifications

- Portable outdoor speaker with high quality sound
- Bluetooth® 4.1 wireless technology for free music entertainment
- Rechargeable battery and Micro USB powered
- Built-in microphone
- IP66 Water proof dust proof
- Link 2 for true stereo sound

Output power	2.5 Watt RMS
Harmonic distortion	< 0.5% 1W 1KHz
Frequency response	180Hz-20KHz
Signal/ Noise ratio	>70dB
Dimension	Φ79xH73xW226mm

Illustrations



+ -	Answer / Hang Up / Reject Phone Tap + to answer / Hold - 3 seconds to Hang up Tap - 3 seconds to Reject
+ -	Factory Reset Hold buttons 8 seconds simultaneously

	Power On/Off Hold 3 Second
---	--------------------------------------

	Bluetooth Pair Automatically Engages with Power On
---	--

+	Play/ Pause Tap buttons simultaneously
----------	--

+ -	Volume Up / Down Tap button
-----	--------------------------------

+	-	Track Back / Track Forward 2 Seconds hold
---	---	--

	Link 2 Magicup 8 Second Hold on Both Sp to Power On
---	--

Frequently Asked Questions (FAQs)

Questions	Solutions
Speaker will not turn on (battery power)	Battery may be in low level or discharged. please recharge it at least half an hour before using.
No Sound	Check if the media player is correctly connected. Check if the Bluetooth connection is correctly paired and connected.
Pairing failed	Please remove previously paired devices from your audio devices, and then "search for devices" again. Reconnect and try again.
Sound is distorted	Check if the source file is not corrupted, play a different song and test.
Reset	If the speaker makes a noise or buttons are ineffective, please long press  and  button to reset the speaker.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV

technician for help.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.