


<Photographs of EUT>

Refer to the EUT external photographs.


<Antenna Location>



The separation distance for antenna to edge:

Antenna	Overall Diagonal (mm)	Display Diagonal (mm)	To Left Side (mm)	To Right Side (mm)	To Top Side (mm)	To Bottom Side (mm)
WWAN Ant-0	155	137	34	0	130	0
WLAN / BT			0	50	0	132

<Photographs of SAR Setup>



Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: 16/F, Block A, Building 6, Baoneng Science and Technology Park, Qingxiang Road No.1, Longhua New District, Shenzhen, China
 Tel: +86-755-28230888 Fax: +86-755-28230886 E-mail: info@uttlab.com <http://www.uttlab.com>



