Saramonic Sound.Remarkable, Illi

Noisewall

SR-BH600

Wireless Active Noise-Cancelling Headphones 无线主动降噪立体声耳机

This manual is for reference only. Please refer to the actual product for the specific functions and appearance of the product. Please read it carefully before using this product and keep it in a safe place for future reference.



Contents






Plug Adaptor for In-flight Use





User Manual

Product Overview




Specifications

Model	SR-BH600
Bluetooth Version	V5.0
Range	approx.30ft(10m)
Frequency Response	20-20KHz
Profile	A2DP, AVRCP, HSP, HFP, CVC
Supported Audio Format(s)	SBC, AAC
Input	5V-12V
Impedance	32 Ω
Driver	Ф40mm
Battery Capacity	400mAh
Charge Time (hours)	approx. 2.5
Playtime (hours)	approx.16 (Bluetooth with ANC off) approx.12 (Bluetooth with ANC on)
ANC Mode Standby Time (hours)	40




specifiction are subject to change without notice

How to Wear




Open and wear the headphones, adjust the headphones to a comfortable position in the direction shown by the above picture.



Power On Press and hold for 3 seconds Flashing red and blue alternately

Power Off Press and hold for 3 seconds Flashing red

Pairing



- Press and hold for 5 seconds
- Flashing red and blue alternately
- Select "Saramonic BH600" on your device
- Voice prompts "connected"

Notes: The pairing mode will be lasted for 10 minutes. If there is no Bluetooth connection with any device for more than 10 minutes, the headphone will automatically turn off.

Button Controls


 \blacksquare

Activate Siri

J			
►II	Play / Pause	Press ×1	
>> -	Next Tack	Press and hold for 3 seconds	
+44	Previous track	Press and hold for 3 seconds	
+44	Volume up	Press ×1	
>> -	Volume down	Press ×1	
		(a)	
►II	Answer / End a c	all Press ×1	
►II	Reject a call	Press ×2	
►II	Call the latest nu	mber Press ×2	
		0	

Press ×3


Aux-in



Switching to AUX mode once plugging in an audio cable, and Bluetooth mode will automatically turn off.

When using AUX mode, control audio playback, volume and call via the connected device.


ANC On / Off



ANC On Slide the switch to ON Steady green(NC LED indicator)


ANC Off Slide the switch to OFF NC LED indicator off

Connect an Additional Bluetooth Devices



- 1. Make sure the headphones are connected to the first Bluetooth device successfully and music is not playing.
- 2. Hold the Multi-function Button until the headphones re-enter pairing mode (the indicator light will flash red and blue alternately).
- 3. Pair the headphones with the second device according to "Easy Pairing" steps.

Charge the headphones



*	Blinking red (LED indicator) with a voice p	prompt "du-du"	Low battery
- \\ -	Flashing red and blue for 1 second	Low batt	ery shutdown
•	Solid red (LED indicator)		Charging
•	Off (LED indicator)		Fully charged

O&A

Q: Failed to connect devices with headphones?

A: Please ensure your headphones in pairing mode. Then delete the pairing record on the Bluetooth devices and reconnect with headphones.

Q: Failed to turn on the headphones?

A: Please check the battery status of your headphones.

Q: Can I replace the battery in the headphones?

A: No. These headphones use a built-in non-detachable Li-Polymer battery which can not be replaced.

Q: Can I use the headphones while driving?

A: For your safety, we strongly recommend you do not use headphones while driving in order to avoid distractions.

Q: Why is the connection sometimes disconnected within 10 meters? A: If there are many WiFi routers, 4G signals, high-power electrical appliances and etc when using, it may be interfering with the Bluetooth connection. It can be solved by changing the environment or reconnecting.

Q: No sound from my computer or mobile phone?

A: Please check if the output channel of your computer supports the A2DP profile. Also check the volume settings on your headphones and computer/mobile phone.

Q: Why am I unable control the volume of a track playing on my mobile phone's APPs?

A: The configurations of various application softwares are different, the headphones may not be completely compatible with some APPs.

Q: What should I do if the Bluetooth connecting function cannot close or open? A: Please reset the Bluetooth function of the headphones by inserting an audio cable into the audio port and removing it.

Q: Why does Bluetooth turn off when I connect an audio cable?

A: This is one of BH600 special features. When the user inserts an audio cable into the audio port, all Bluetooth feature buttons temporary stop working and Bluetooth turns off

The Bluetooth will be available again when pulling out the audio cable.

Q: Failed to turn the headphones on/off?

A: Please noted that ANC and Bluetooth are indicated by the same indicator light, with a green light for ANC and a blue light for Bluetooth. If you need to turn Bluetooth on/off, please make sure you already turn off the ANC.

FCC WARNING This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful

interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party

responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits

for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not

installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more

of the following measures: -- Reori ent or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure.

requirement. The device can be used in portable exposure condition without restriction

Safety Instructions

- 1. Read, follow and keep these instructions.
- 2. For the best possible experience, always use the product as described by the manufacturer
- 3. Always handle your headphones with care and protect them from external damage.
- 4. Clean your headphones using a soft dry cloth. Never use water, cleaning detergent, leather polish or other substances as they may damage your headphones permanently.
- 5. Avoid exposure to extreme conditions such as very cold or hot temperatures, mahnetic fields or damp environments.
- 6. Listening to music at high volume for prolonged periods of time can cause permanent damage to your hearing.
- 7. Contains small parts and are not suitable for children age three (3) and below.
- 8. The headphones contain magnetic material.
- 9. The headphones contain a Lithium battery. If misused or damaged it can become a hazard and is at risk of explosion.
- 10. Should a battery cell leak, do not allow the liquid to come in contact with skin or eves.
- 11. The headphones must be switched off before boarding an aircraft.
- 12. The headphones must not be disposed of with regular household waste. Please dispose of in accordance with local regulations.
- 13. Do not use your headphones in the immediate proximity (10 cm) of a pacemaker.
- 14. Do not subject the product and included accessories to abnormal wear and tear

- 15. Do not expose the headphones to temperatures below -20°C or above +45°C.
- 16. Do not charge the headphones in temperatures below 0°C or above +45°C.
- 17. Do not attempt to burn the headphones. The battery could explode causing injury and death.
- 18. Do not attempt to open, modify, disassemble, repair or in other way access the internal structure of the headphones. They are not user serviceable.
- 19. Do not use or store the headphones near to a vehicle airbag due to risk of injury.
- 20. Do not use headphones while driving, jogging or walking through traffic areas. Headphones effectively isolate external sound and noise, which means that when in use, you might not be able to hear your surroundings.
- 21. Do not drop, sit on or cause other unusual impact to the headphones.
- 22. Do not expose to fire, water or high voltage equipment.

liquids or moist areas.

23. Do not expose the product to rain or moisture.
24. Do not use the headphones near water, bathtubs, sinks, saunas, pools, other

包装清单








Micro USB 充电线 说明书

产品结构




参数

型号	Saramonic SR-BH600
蓝牙版本	V5.0
操作距离	10m
频率响应	20-20KHz
支持协议	A2DP, AVRCP, HSP, HFP, CVC
支持音频格式	SBC, AAC
输出电压	5V-12V
阻抗	32 Ω
驱动单元	Φ 40mm
电池容量	400mAh
充电时长	approx. 2.5
播放时长	16 小时(正常模式) 12 小时(ANC 自动降噪模式)
ANC 模式下待机时长	40




规格如有更改,恕不另行通知

如何佩戴



展开并戴上耳机,将耳机按上图所示方向调整至舒适位置。

电源开启 / 关闭



电源开启




▶ 长按住3秒以上

红蓝交替闪烁



红灯闪烁




- 长按住配对键5秒
- 红蓝灯交替闪烁
- 选择名称为 "Saramonic BH600" 蓝牙设备
- 语音提示 "已连接"

注意: 配对模式将持续 10 分钟。如果与任何设备没有蓝牙连接超过 10 分钟,耳机将自动关机。

按键介绍


	_	
	F	
▶ ∥	开始/暂停	短按一次
>> -	下一曲	长按住3秒
+44	上一曲	长按住3秒
+	增加音量	短按一次
>> -	降低音量	短按一次
	(a)	
▶ ∥	接听/挂断电话	短按一次
▶ II	拒接电话	短按两次
►II	回拨最近通话	短按两次
	Ŷ	
▶ ∥	激活语音助手	短按三次

有线连接设备



切换到 AUX 模式,一旦插入音频线,蓝牙模式将自动关闭。 使用 AUX 模式时,通过连接的设备控制音频播放、音量和呼叫。

ANC开关(自动降噪功能)



ANC 开

开关拨至 ON


绿灯常亮

ANC 关

开关拨至 OFF

灯熄灭

多连接设备(无线连接)



- 1. 确保耳机与第一设备连接成功,并确保设备中没有音乐播放。
- 2. 长按住多功能键,直到耳机重新进入配对模式 (指示灯红蓝交替闪烁)。
- 3. 按照"快速配对"步骤将耳机与第二设备配对。

耳机充电



*	红灯闪烁,语音提示"嘟嘟"	低电量
- *	红蓝灯交替闪烁	电量不足关机
•	红灯常亮	充电中
•	灯熄灭	充满电量

Q&A

问:无法将设备与耳机连接?

答:请确保您的耳机处于配对模式。然后删除蓝牙设备上的配对记录,并重新配对 耳机。

问:无法打开耳机?

答:请检查耳机的电池状态。

问:我可以更换耳机的电池吗?

答:不可以。耳机使用的是不可拆卸的内置锂电池,无法自行更换。

问: 我可以在驾驶的时候使用耳机吗?

答: 为了您的安全, 我们强烈建议您开车时不要佩戴耳机, 以免分心。

问: 为什么耳机连接会突然断开?

答:如果使用环境中存在较多 WiFi 信号、4G 信号、大功率电器等信号源,可能会于抗蓝牙连接。可以通过改变环境或重新连接来解决。

问: 我的电脑或手机没有声音?请检查您计算机的输出通道是否支持 A2DP 配置文

件。

答: 还要检查你的耳机和电脑 / 手机的音量设置。

问:为什么我无法在手机应用程序中控制播放曲目的音量?

答:不同的应用软件设定不同,有些应用可能无法完全兼容耳机。

问:如果蓝牙连接功能无法打开或关闭怎么办?

答:请将配置的音频线插入耳机的音频端口,并将其取下,重新设置耳机的蓝牙功能。

问:为什么插上音频线时,蓝牙功能会关闭?

答: 这是 BH600 的特色之一。当您将音频线插入音频端口时,所有蓝牙功能按钮暂时停止工作,蓝牙暂时关闭,拔出音频线时,蓝牙再次可用。

问:耳机打开/关闭失败?

答:请注意 ANC(自动降噪功能)和蓝牙是使用同一个指示灯表示状态,ANC(自动降噪功能)表示为绿灯,蓝牙表示为蓝光。

如果您需要开启/关闭蓝牙,请确保您已经关闭了ANC(自动降噪功能)。

安全指南

- 1. 在操作产品前,请仔细阅读并遵守这些说明。
- 2. 为了获得最好的体验,请始终按照说明书描述的方式进行使用。
- 3. 小心使用耳机, 保护它们不受外部干扰损害。
- 4. 用柔软干布擦拭耳机。不要用水,清洁剂,抛光剂等直接清洗,可能会对你的耳机造成不可逆的损坏。
- 5. 避免暴露在极冷或高温的环境中,以及磁场或潮湿环境。
- 6. 请勿长时间高音量听音乐,可能会对你的听力造成永久性伤害。
- 7. 产品配置小零件,不适合3岁及以下儿童使用。
- 8. 耳机含有磁性材料。
- 9. 耳机内置锂电池。如果使用不当或损坏,可能存在安全隐患,并有爆炸的危险。
- 10. 若电池发生泄漏,禁止液体接触皮肤或眼睛。
- 11. 在登机前必须关掉耳机。
- 12. 耳机不可与日常生活垃圾一起处置。请按照当地规定处理。
- 13. 不要在离起搏器近 10 厘米的地方使用耳机。
- 14. 请勿非正常使用或损耗产品及附件。
- 15 不要将耳机暴露在 -20℃以下或以上的温度下 + 45° C。
- 16. 不要在 0℃以下或 45℃以上的温度下充电。
- 17. 不要试图烧毁耳机。电池可能会爆炸受伤和死亡。
- 18. 请勿擅自打开、修改、拆卸、修理或以其他方式打开耳机内部结构。
- 19. 不要将耳机使用或存放于车辆安全气囊附近,以免造成下列危险受伤。
- 20 开车,慢跑可步行穿过车流时不要戴耳机区域,且机有效隔离外部声音和噪音。
- ZU. 开车、慢跑或步行穿过车流的不要戴耳机区域。耳机有效隔离外部声音和噪音, 这意味着在使用时,你可能听不到周围的声音。
- 21. 请勿跌落、坐压或对耳机造成其他不寻常的冲击。
- 22. 请勿暴露于火,水或高压设备中。
- 23. 不要将产品暴露在雨中或潮湿处。
- 24. 不要在靠近水、浴缸、水槽、桑拿、游泳池等潮湿的地方使用耳机。



Please follow our WeChat account for more details. 扫描二维码关注枫笛Saramonic微信公众号。

www.saramonic.com

Saramonic is a trademark registered and owned by Shenzhen DSQN Investment CO., LTD. COPYRIGHT 2011-2021 SARAMONIC INTERNATIONAL (A brand of DSQN) Room 2009, Shenzhou Bairuida Bldg, Banxuegang Road, Bantian Street, Longgang District Shenzhen, China 518129 Tel: 400-613-1096 Emall: info@saramonic.com

深圳市大盛青牛投资有限公司

广东省深圳市龙岗区坂雪岗大道百瑞达大厦A栋2009室

全国服务热线: 400-613-1096

中国制造 Made in China