

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Figure 1 illustrates the top and side views of the proposed device. The top view shows a circular device with an LED of Charging Case at the bottom. The side view shows a vertical device with a Touch Button - MFB at the top and a Microphone at the bottom.



T61 TWS Earbuds  
Type-C USB Charging Cable  
Quick Guide



Bluetooth: V5.3  
Frequency Range: 2400~2485 MHz  
Sensitivity: 105 ± 3dB  
Impedance: 16 ohm ± 15%  
Input: DC 5V / 500mA  
Earphones Battery Capacity: 30 mAh x 2  
Charging Pod Battery Capacity: 300mAh  
Charge Time: 2 hours

Fully charge the battery for 2 hours before using the earbuds for the first time, or when they have been unused for extended periods.

Put the earbuds into the charging case, close the lid and they will charge automatically. The indicator of charging case will flash once then stay in white for 4 seconds and be off.

When the charging case is connected with charger (or computer USB port) by charging cable, the indicator will flash in orange slowly. When the charging case is fully charged, the indicator will be lit-in orange.

When the charging case is out of battery, the earbuds will not turn on/off automatically when removed from or placed back into the charging case. In this case, turn the earbuds on/off manually.

Take the earbuds out of the charging case, the earbuds will automatically power on and enter into pairing mode.

Touch the MFB for 2 secs on both earbuds to turn on the earbuds. (You will hear the prompt tone). The earbuds will automatically enter pairing mode.





Diagram illustrating the Bluetooth settings on a smartphone. The screen shows the 'BLUETOOTH' section with a toggle switch turned on. A list of devices is displayed, including 'T61' which is marked as 'Connected'. A red box highlights the 'T61' entry.

Turn on the device's Bluetooth setting .  
Search for and choose **T61** to pair, your  
device will show "connected" .

A diagram of a closed container, possibly a pill bottle or a small box, with two internal compartments. Each compartment contains a small, light-colored, pill-shaped object. A grey arrow points to the left from the top left corner of the container.

1. Touch the MFB for 10 secs on both earbuds to power off the earbuds.
2. The earbuds will automatically turn off when without pairing for 10 mins.



Insert the earphones directed towards your ear canal. Twist gently until the earbuds fit comfortably and get better sound experience.


The diagram illustrates the touch gestures for the back of the AirPods Max. A hand is shown interacting with the touch sensor. The gestures are categorized into three main functions:

- Calls:**
  - Tap Once: Answer Call
  - Tap Twice: End Call
  - Touch for 1s: Reject Call
- Music:**
  - Tap Twice: Play / Pause
  - Tap Once: Earbud R- Volume Up, Earbud L- Volume Down
  - Touch for 2s: Earbud R- Next Track, Earbud L- Previous Track
- Voice Assistant:**
  - Tap 3 times: Siri / Voice assistant

If you have problem to connect the earphones with your device, don't worry about it, please follow the step as below:

1. Make sure all devices have turned off Bluetooth Function and pairing record have been cleaned.
2. Take the earphones out of the case, tap each earbuds by 5 times quickly , prompt sound will be activated, then follow the pairing step as instruction.

## Model: T61



# Quick Guide