
USER GUIDE

2.4G wireless combo
KB313W+MA105W+RG10-P







Set Wireless Connection

The 2.4GHz wireless combo(keyboard, mouse, and USB receiver) is pre-paired before packing. Users can use the wireless combo after installing the battery.

- 1. Turn on the computer.
- Plug the USB receiver into an available USB port on your computer.
- 3. Install the battery into the keyboard and mouse. Press any key to start.

Keyboard Use Guide

Multimedia keys	1	2	3	4	5	6	7	8	9	10	11	12
8 • •		F2	Ä	R	Ê		7		Idd P0	PIO PIO	Fii	P12

12 multimedia keys

	-		
	Keys		
	key	•	mute
	key	•	Volume down
	key	4 0)	Volume up
1	Fn + F1	⊕ F1	Internet
2	Fn + F2	⊠ F2	Email
3	Fn + F3	★ F3	Favourite
4	Fn + F4	□ F4	My computer
5	Fn + F5	Ç F5	Search
6	Fn + F6	9 O	Share
7	Fn + F7	F7	Device
8	Fn + F8	₽ F8	Setting
9	Fn + F9	14 4 F9	Previous track
10	Fn + F10	F10	Next track
11	Fn + F11	⊳∎ F11	Pause/play
12	Fn + F12	□ F12	Stop

Technical data

Mouse Sensor

PAW3204LU-TJDU by Pixart, optical sensor

Resolution 1000DPI±15%

Operating Range

10 meter (Max). (No noise, at line of sight)

Frequency Range 2402MHz~2479MHz

Modulation GFSK

Channel

Total: 78 channels

Channel Space: 1MHz (Remark: Center frequency gap between one consecutive channel)

Report Frame Rate

Max. 125rps, self-adjusting

Maximum moving speed 30 Inch/Second

Maximum acceleration

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.