





Restrict Band NVNT ac40 5190MHz Ant1 Peak




Restrict Band NVNT ac40 5190MHz Ant1 Average






Restrict Band NVNT ac40 5230MHz Ant1 Peak



Restrict Band NVNT ac40 5230MHz Ant1 Average





B.5 Frequency Stability

Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	n40	5190	Ant1	5190	0	0	25	Pass
NVNT	n40	5230	Ant1	5229.96	-40000	-7.65	25	Pass
NVNT	ac20	5180	Ant1	5179.98	-20000	-3.86	25	Pass
NVNT	ac20	5200	Ant1	5199.96	-40000	-7.69	25	Pass
NVNT	ac20	5240	Ant1	5240	0	0	25	Pass
NVNT	ac40	5190	Ant1	5190	0	0	25	Pass
NVNT	ac40	5230	Ant1	5229.96	-40000	-7.65	25	Pass




Shenzhen LCS Compliance Testing Laboratory Ltd.
Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China
Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com
Scan code to check authenticity




Test Graphs

Freq. Stability NVNT n40 5190MHz Ant1




Freq. Stability NVNT n40 5230MHz Ant1






Freq. Stability NVNT ac20 5180MHz Ant1




Freq. Stability NVNT ac20 5200MHz Ant1







Freq. Stability NVNT ac20 5240MHz Ant1



Freq. Stability NVNT ac40 5190MHz Ant1







B.6 Duty Cycle


Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5180	Ant1	87.03	0.6	0.71
NVNT	a	5200	Ant1	38.08	4.19	0.71
NVNT	a	5240	Ant1	89.52	0.48	0.71
NVNT	n20	5180	Ant1	88.33	0.54	0.76
NVNT	n20	5200	Ant1	88.8	0.52	0.76
NVNT	n20	5240	Ant1	89.34	0.49	0.76
NVNT	n40	5190	Ant1	59.93	2.22	1.53
NVNT	n40	5230	Ant1	68.02	1.67	1.53
NVNT	ac20	5180	Ant1	84.49	0.73	0.75
NVNT	ac20	5200	Ant1	91.89	0.37	0.75
NVNT	ac20	5240	Ant1	87.45	0.58	0.76
NVNT	ac40	5190	Ant1	52.96	2.76	1.51
NVNT	ac40	5230	Ant1	55.74	2.54	1.52






Test Graphs

Duty Cycle NVNT a 5180MHz Ant1




Duty Cycle NVNT a 5200MHz Ant1






Duty Cycle NVNT a 5240MHz Ant1




Duty Cycle NVNT n20 5180MHz Ant1






Duty Cycle NVNT n20 5200MHz Ant1




Duty Cycle NVNT n20 5240MHz Ant1






Duty Cycle NVNT n40 5190MHz Ant1




Duty Cycle NVNT n40 5230MHz Ant1






Duty Cycle NVNT ac20 5180MHz Ant1




Duty Cycle NVNT ac20 5200MHz Ant1





Duty Cycle NVNT ac20 5240MHz Ant1



Duty Cycle NVNT ac40 5190MHz Ant1

