



User Manual CAD-6057

We're here to help! Call us at this number (833) 227-3274 Or email us support@cddashcams.com



#### **FCC Statement**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouragetry to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

## **Important Safety Instructions**

- SAVE THESE INSTRUCTIONS- This manual contains important safety and operating instructions for CAD6057.
- Before using CAD4057, read all instructions and cautionary markings on Vehicle Battery Adapters.
- 3. Do not expose charger to rain, moisture, or snow.
- When replacing an old fuse, use a new fuse with the same type and rating to prevent fire or electric shock.
- Make sure the cord is located where it will not be stepped on, tripped over, or otherwise subjected to damage or stress.
- Do not operate the charger if it has a damaged cord or power connector. Replace it immediately.
- Do not operate charger if it has received a sharp blow, been dropped, or otherwise damaged in any way. Take it to a qualified serviceperson.
- Do not disassemble the charger; take it to a qualified serviceperson when service or repair is required. Incorrect reassembly may result in a risk of electric shock or fire.
- To reduce risk of electric shock, unplug the charger before attempting any maintenance or cleaning. Turning off controls will not reduce this risk.



# 1 Introduction

#### Specifications

Frequency: 2.402 ~ 2.480 GHz

Working Current: 45mA (Max)

· Stand-by Current: 25mA (Max)

Effective Range: 5m

• Frequency: 88MHz - 108.0MHZ

Input: DC12-24V

Output: DC 5V 2.4A + PD30W

Power: 122w max

## Features

- Stream music from your Bluetooth enabled device to a car's stereo via FM signal
- LED display that shows the car's voltage when connected to power
- Allows you to answer calls and speak hands-free
- Built-in microphone for phone calls
- Two charging ports: USB and Type C ports
- Two 12V charging sockets

# Siri/Google activation 2 Getting Started

# Power-on

The device turns on automatically when plugged into a car cigarette lighter.

# ■ Trequency and Volume Adjustment

- This device supports frequencies of 88-108 MHz. Press and hold the hold the button and then press to adjust the FM frequency.
- Adjust the volume with the and buttons.

## Using Bluetooth

- Plug the device into one of the 12V charging sockets (the device will power on after you plug it in).
- Check your smartphone to make sure Bluetooth is turned on, then search for/select your FM transmitter. It will show up as "CAD-6057."
- Tune the car's FM radio frequency to an unused FM station.
- · Tune the FM transmitter to the same frequency.
- You will now be able to stream content from your device to your car speakers.

#### NOTES:

When powered on, the device will automatically connect to the most recently used device. To avoid this, turn Bluetooth off on the devices you aren't streaming music from.

The FM transmitter signal can be affected by other radio stations or similar frequencies. This is normal, but if the problem persists, try streaming through another FM frequency.

# ■ L Making & Answering Calls

The transmitter can make or answer a call after it is successfully connected to your phone via Bluetooth.

- Redial the last number: double-click the button
- Reject a call: press and hold down i i i i for about 3 seconds
- Answer a call: press I lonce
- Hang up a call: press [ F once

### ■ Activating Siri/Google

· Double press the Forward button to activate the voice

- command system
- · Make requests like "Call mom" or "Call Dad"

## I Replacing the Fuse

- If your device is not charging properly, it is possible that the fuse needs to be replaced.
- To replace the fuse, grip the charging tip (labeled in the diagram as "the positive power supply") and twist left. It will unscrew.
- Replace the fuse with the extra included in the package, then screw the device closed.

#### SUMMIT OF GROUP ONE YEAR LIMITED WARRANTY

SUMMIT CE GROUP LIMITED WARRANTY ("Warranty") — For Product Categories Listed in Chart Below (as applicable, "Product") Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully. If you are still having trouble with your Product, please contact Technical Support at support@cddashcams.com

Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children.

Subject to the terms and conditions herein, SUMMIT CE GROUP LLC (hereinafter called "SUMMIT CE GROUP") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects"). Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period for one year, to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, SUMMIT CE GROUP will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable) either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified

Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and SUMMIT CE GROUP's sole liability for breach of the limited warranty contained herein.

This warranty specifically excludes any Product (or, as applicable, any

component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification of repair to Product (or, as applicable, any component thereof) by any party other than SUMMIT CE GROUP or a party authorized in writing by SUMMIT CE GROUP; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions; or (g) any acts of God. Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use.

In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. SUMMIT CE GROUP disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify SUMMIT CE GROUP for any damages claimed against SUMMIT CE GROUP for such uses. EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS". AND SUMMIT CE GROUP DISCLAIMS ALL OTHER WARRANTIES. INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (I) OF MERCHANTABILITY. (II) OF FITNESS FOR A PARTICULAR PURPOSE, OR (III) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. IN NO EVENT WILL SUMMIT CE GROUP BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL. EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF SUMMIT CE GROUP HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, SUMMIT CE GROUP'S AGGREGATE LIABILITY TO CLISTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CALISE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCT CAUSING THE DAMAGES, IF ANY, This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. To obtain Warranty service. Customer must email

SUMMIT CE GROUP Technical Support prior to making a Product return. Customer must include with Product return the following items (failure to enclose any of these items may result in a delay in the processing of your Warranty claim); (i) a dated sales receipt that indicates the place of purchase, model number of Product, and amount paid; (ii) a detailed description of Customer's problem with Product: (iii) Customer's full name, phone number, and return address, and; (iv) a money order made out to SUMMIT CE GROUP Electronics Corporation to cover return shipping charges to US destinations only, for the applicable dollar amount shown for the Product in the table above. SUMMIT CE GROUP will not make return. shipments to a P.O. Box. For shipping to international addresses. actual freight will be charged to Customer. Return your Product freight-prepaid in its original packaging, or packaging that affords an equal measure of protection. Please allow 4 to 6 weeks for the processing of your claim (6 to 8 weeks from November to February).

SHIPPING COSTS: The original consumer is responsible for any shipping charges incurred to ship the Product or part(s) to the authorized service provider, for diagnosis, repair or replacement.

You must email support@cddashcams.com prior to making a return.

\*US destinations only.

Contact Us at <u>support@cddashcams.com</u> or call us toll free at 833-227-3274

if you have any questions or regarding return information.