

## DOUBLE SIDE PRINT

## BODY GLOVE QUICK START GUIDE


## WATER-RESISTANT WIRELESS SPEAKER

## CHARGING THE SPEAKER

⚡ Charge the speaker before using it for the first time.

🕒 Plug in the cable to the micro USB port and charge for at least 1.5 hours.

Connect the charging cable to charging port.



## PAIRING YOUR SPEAKER

Your speaker will work best if it is within 30 ft. of your smart device. You may experience sound briefly cutting off if you are out of range or if your wireless connection is weak. Make sure Bluetooth is enabled on your smart phone or tablet before starting the pairing process.

## BODY GLOVE QUICK START GUIDE


## WATER-RESISTANT WIRELESS SPEAKER

## PAIRING YOUR SPEAKER (continued)

Make sure the speaker is turned off before attempting to pair it with a smart phone or tablet. Press the "OFF/ON" button to turn on the speaker.



Your wireless speaker will automatically turn on and enter Bluetooth pairing mode.



From your smart phone or tablet, find a list of nearby devices and choose "BDY-1311". Enter "0000" if asked. The speaker will "beep" when pairing is complete!

## BODY GLOVE QUICK START GUIDE

## WATER-RESISTANT WIRELESS SPEAKER

## CONNECTION LOST?

- If pairing the speaker does not work, turn off the speaker and repeat the steps again in "Pairing your Speaker."
- Make sure your speaker is within range of your smart device.
- When charging your speakers, only use the enclosed USB cable.

## MEDIA KEY FUNCTIONS



- |  |                                     |                                    |
|--|-------------------------------------|------------------------------------|
|  | Press & Hold - Turn device on/off   | Press & Hold to Turn Device on/off |
|  | Press Once-Play/Pause music         | Press Once-Play/Pause music        |
|  | Press & Hold - Increase volume      | Press Once - Next Track            |
|  | Press & Hold - Decrease volume      | Press Once - Previous Track        |
|  | Press & Hold - Reject Incoming Call | Press Once - Answer / End Call     |
|  |                                     | Press Twice - Redial last number   |

## BODY GLOVE QUICK START GUIDE

## WATER-RESISTANT WIRELESS SPEAKER

## SPECIFICATIONS

Bluetooth Version: 4.2  
 Operation Range: Up to 33ft (10m)  
 Play Time: Up to 3 hours  
 Standby Time: Up to 75 Hours  
 Battery Capacity: 300mAh  
 Charging Time: Up to 1.5 Hours  
 BT ID: D039149  
 FCC ID: 2AANZ1311

## WARRANTY

This product is covered by a 3 month limited manufacturer's warranty. Contact us if you have any problems at support@dglusa.com.

## WARNING

Keep away from water and moisture.  
 Keep away from heat sources.  
 Do not disassemble.

## BODY GLOVE QUICK START GUIDE

## WATER-RESISTANT WIRELESS SPEAKER

## FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and

## BODY GLOVE QUICK START GUIDE

## WATER-RESISTANT WIRELESS SPEAKER

used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.