

材质：80G书纸+胶装
尺寸：86*98mm













封底





















封面



简中



	EN In The Box  Headphones × 1 Pair  Charging Case × 1  Type-C Charging Cable × 1  Silicone Ear Tip × 3 Pairs (XS/S/L)  User Guide × 1  Warranty Card × 1  1MORE Bear Sticker × 1
EN Product Overview  Charging Contacts  Silicone Ear Tip  Infrared Sensor  Voice Mic / LED  Pairing Button  LED Indicator  Charging Case	EN Placement  XS S M L  EN Power  Power On: Open the charging case (with charge), the headphones will turn on automatically.  Power Off: Put the headphones back into the correct slot of the charging case and close the lid, they will automatically turn off and start charging. * Above functions are available for either earbud in individual or Stereo mode.
EN Headphones Pairing  The Left and Right headphones will automatically pair to each other after the lid is open when they are in the case (with charge). Bluetooth Pairing To The Device To connect to your device for the first time, turn the headphones on to enter the pairing mode, the Right headphone will flash in white alternatively. Headphones will enter a standby mode if not paired to a device within 3 minutes. * After the first successful pairing, headphones will automatically connect to your device. * Above functions are available for either earbud in individual or Stereo mode. To pair the headphones to a new device, simply place them into the charging case and triple tap the pairing button. Then click "1MORE ComfoBuds Mini" in the new device pairing list to connect.	EN Charging ① To charge the case with Type-C cable.  A full charge will take around 85 minutes.  The LED light of the charging case will indicate different battery statuses. * The headphones are certified by Qi wireless charging, please use a Qi certified charging pad to ensure charging safety and efficiency. ② To charge the headphones with the case.  Put headphones in correct slot until it locks in via the magnet. The white light of headphones will indicate headphones are charging.  A full charge will take around 70 minutes. The red light on the headphones turning off indicates the charging is complete.
EN Battery Status Display in 1MORE MUSIC APP Battery status of headphones and charging case will be displayed in 1MORE MUSIC APP.  首页 1MORE ComfoBuds Mini 100% 100% 80% Battery Notification  LED indicator for low battery: when there is 25-30 minutes of use left, you will hear a voice prompt.  When the charge is too low on the case battery, the LED indicator will flash red.	EN Touch Controls Switch the Listening Modes The default setting of the headphones is "ANC Off". touch and hold on the outside of the headphone to switch between "ANC Off", "ANC On" and "Pass-through". The brand new QuietMax Adaptive Noise Cancellation technology is included which dynamically detects the real-time noise levels outside and intelligently reduce the noise immediately. Phonecalls and music can be controlled by tapping the outside of the earbuds.  Phone Call  Touch area  Answer: Double tap  End call: Double tap  Voice control on cellphone: Triple tap (Bluetooth on and no phone calls)  Playback  Play/Pause: Double-tap * Above functions are available for either earbud in individual or stereo mode. * To decline a call, change a song or control volume, please operate on 1MORE MUSIC APP, paired mobile phone or device. * Above functions may vary with different devices.
EN Smart Playback An IR Sensor automatically detects when you take out your headphones to stop playback intuitively and resumes playback when you put them back in. To turn off Auto-Play, connect the headphones to the 1MORE MUSIC App and change in the settings. 	EN Switch Listening Modes via APP Enter the 1MORE ComfoBuds Mini home page in 1MORE MUSIC APP after pairing to your cellphone, then you can switch listening modes between "Music" and "Soothing". 
EN Soothing Sounds Click the "Soothing Sounds" to enter the playlist.  Click "+" to select the sound to be downloaded to your headphones for listening. 	EN  Click the timer icon in song page to set up the playtime. 
EN 1MORE (1) Year Limited Warranty 1MORE warrants to the original retail purchaser that this product is to be free from defective materials and workmanship for a period of one year from the date of purchase if it is properly used and maintained. If this product proves defective in either material or workmanship, 1MORE, at its option, will (a) repair the product with new or refurbished parts, or (b) replace the product with an equivalent new or refurbished product, at no charge for parts or labor. If the product model is no longer available and cannot be repaired effectively or replaced with an identical model, 1MORE at its sole option may replace the unit with a current model of equal or greater value. In some cases, modification to the mounting surface may be required where a new model is substituted. 1MORE assumes no responsibility or liability for such modification. TO OBTAIN A REPAIR OR REPLACEMENT UNDER THE TERMS OF THIS WARRANTY, PLEASE RETURN TO THE ORIGINAL DEALER FIRST AND THE ORIGINAL DEALER SHALL REPAIR THE PRODUCT WITH NEW OR REFURBISHED PARTS OR REPLACE THE PRODUCT WITH AN EQUIVALENT NEW OR REFURBISHED PRODUCT. You will be required to submit a proof of purchasing details, including but not limited to a receipt or sales invoice. Return shipping for exchanges/repairs is the sole responsibility of the original retail purchaser. Limitations: • This limited warranty does not cover the failure of the product resulting from improper installation, misuse, abuse, accident, neglect, mishandling, or wear from ordinary use or environmental deterioration. • This limited warranty does not cover cosmetic damage, including paint damage, or consequential damage to other components or premises which may result for any reason from the failure of the product. • This limited warranty is null and void for products not used in accordance with 1MORE's instructions. • This limited warranty is null and void for products with altered or missing serial numbers and for products not purchased from an AUTHORIZED dealer. • This limited warranty terminates if you sell or otherwise transfer this product to another party.	EN We Appreciate Your Business We know you will enjoy new 1MORE headphones as much as we do. At 1MORE, we value your satisfaction. If you would like more details on this product or any of our other products, please visit us online by scanning the QR code. Go to www.1more.com and sign up for VIP, and 1MORE will treat you like one. Tips 1. Please read this instruction manual carefully and retain for future reference. 2. Please fully charge the battery before first use. 3. If the headphones have been unused for more than 3 months, we recommend that you charge them. This will improve battery capacity. 4. Only use charging cables and adapters that are FCC (Federal Communications Commission) approved. 5. In dry environments, static electricity may numb your ear. This is not related to the quality of the product. Safety Information 1. Never disassemble the headphones. There are no user-serviceable parts inside. 2. Do not expose the headphones to temperatures below 32 °F (0 °C) or to temperatures above 113 °F (45 °C). 3. Do not use the headphones in a thunderstorm storm. This could prevent the headphones from working properly, and also increase your chance of being electrically shocked. 4. Do not use oil or any volatile liquid to clean this product. 5. Do not listen at high volumes for extended periods of time. 6. Do not use the headphones in traffic. Do not use the headphones any time it would be dangerous to be unaware of noises around you. 7. Adult supervision is required for children of age 6 and under. 8. If you don't feel comfortable after wearing the headphones, please refer to an aurist for advice on whether in-ear headphones are suitable for you.
EN FAQ 1. Why the headphones cannot be turned on? Check if your headphones have enough battery life. If not, please charge them for at least 30 minutes. 2. Why the headphones cannot connect to my cellphone, or take a long time to connect? 1) If headphones cannot pair normally when power on. Open the case, triple tap the pairing button to initial searching for Left & Right pairing, and then click "1MORE ComfoBuds Mini" in the device pairing list. 2) To pair the headphones to a new device, simply place them into the charging case and triple tap the pairing button. Then click "1MORE ComfoBuds Mini" in the new device pairing list to connect. 3. Why the headphones cannot play music after successfully connecting to my Android device? After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Media Audio" option is on. 4. Why there is no sound from the headphones while making phone calls after successfully connecting to my Android device? After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Phone Audio" option is on. 5. Why the Bluetooth connection is not stable and causes some interruptions? 1) Try shortening the distance between your headphones and device. Avoid solid barriers in between. 2) Please keep away from strong interference sources, such as Wi-Fi and GPRS. 3) Please make sure the Bluetooth antenna of your device is not blocked. 6. Why some control functions do not match those in the manual while using third party music/video player Apps? Your operating system and the third party music/video player apps may have different settings for the in-line remote control functions. We recommend that you use the music/video player apps that your device has originally provided. * For more detailed product FAQs, please visit the product support section under www.1more.com	EN WEEE Electrical and electronic equipment, parts and batteries marked with this symbol must not be disposed of with normal household wastage, it must be collected and disposed of separately to protect the environment. Your 1MORE retailer will advise you of the correct way of disposal in your country. Safety Caution Do not expose batteries or battery packs to excessive heat such as sunshine, fire or the like. CE Declaration of Conformity Hereby, Tinlab Corporation Limited declares that the radio equipment type 1MORE ComfoBuds Mini of ES603 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.1more.com RF exposure information: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable equipment condition without restriction. Radiation Exposure Statement Power is so low that no RF exposure calculation is needed. Declaration for EU Compliance Operation Frequency/Max. EIRP:2402-2480MHz, Max. EIRP is 5dBm.
EN Warning Replacement of a battery with an incorrect type that can defeat a safeguard (such as catching fire, explosion, leakage of corrosive electrolyte etc); Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion; Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.  The symbol indicates DC voltage.  RECYCLING This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.  To prevent possible hearing damage, do not listen at high volume levels for long periods.	EN Name: Wireless Earphones Model: ES603 H-Headphone Weight: 3.7 g Case Weight: 34.9 g Product Weight: 42.3 g Headphone Size: 17 × 15 × 13 mm Case Size: 56.5 × 50 × 24.5 mm Case Battery Capacity: 34 mAh Base Battery Capacity: 440 mAh Headphone Charging Time: 70 mins Case Charging Time (with cable): 85 mins Fully Charged (with cable): ANC On Headphone: 5 hours Headphones + Case: 20 hours Fully Charged Playtime (ANC Off) Headphone: 6 hours Headphones + Case: 24 hours Headphone playtime (BLE): 8 hours Impedance: 32 Ω Wireless Range: 10 m Bluetooth: Bluetooth® 5.2 Bluetooth Protocol: HFP / A2DP / AVRCP Input: 5V=1A Working Temperature: 0 °C ~ 45 °C Frequency Band: 2.400 GHz ~ 2.4835 GHz * The specifications are acquired from laboratory tested data. * The playtime, tested under the laboratory condition of AAC format and 50% volume, may vary with different device setting, environments, usage and other factors. Manufacturer: Tinlab Corporation Add: No. 8333, Luxian Avenue, Tower A, 35th Floor, Tangliang City, Nanshan District, Shenzhen, China Product information can be found at www.1more.com

