

To active the keyboard, please refer to the method described as below:

1. press connect key in the receiver, LEDs turn on
2. click any key in the keyboard, LEDs turn off
3. at this time,you can use the keyboard just as usual

keyboard sending data to receiver just when you press any key.