


<div data-bbox="919 383 1082 416"> <h2>Quick Start Guide</h2> <p>Smart Battery Doorbell Camera</p> </div> <div data-bbox="958 457 1040 677"> </div> <div data-bbox="964 723 1034 733"> <p>Model: E93G</p> </div>	<div data-bbox="1167 375 1242 387"> <h2>Welcome</h2> </div> <div data-bbox="1167 399 1363 422"> <p>Thank you for choosing our smart camera. Getting started is easy.</p> </div> <div data-bbox="1167 437 1264 449"> <h3>What's Included</h3> </div> <div data-bbox="1167 462 1400 756"> <div> <p>Video Doorbell</p> </div> <div> <p>Back Veneror</p> </div> <div> <p>Power Adapter</p> </div> <div> <p>USB Cable</p> </div> <div> <p>Wall Mount Screw Sets</p> </div> <div> <p>Quick Start Guide</p> </div> <div> <p>USB Chime or DC Chime</p> </div> <div> <p>3M Tape</p> </div> <div> <p>Spinner</p> </div> </div>	<div data-bbox="1445 375 1539 387"> <h2>Product Details</h2> </div> <div data-bbox="1436 426 1629 592"> <div> <p>Doorbell Front View</p> </div> <div> <p>Doorbell Rear View</p> </div> </div> <div data-bbox="1430 625 1684 729"> <div> <p>Doorbell Bottom View</p> </div> <div> <p>Chime</p> </div> </div>	<div data-bbox="1726 375 1871 385"> <h3>1. Connection Preparation</h3> </div> <div data-bbox="1726 393 1944 418"> <p>Bring the doorbell and phone within 1 to 3 feet (30 to 100 centimeters) of the router.</p> </div> <div data-bbox="1744 441 1950 520"> </div> <div data-bbox="1726 536 1950 590"> <p>Note: Make sure smart phone is connected with your wireless router. Please note the doorbell is only working under 2.4G Wi-Fi, not support 5G Wi-Fi.</p> </div> <div data-bbox="1726 611 1877 623"> <h3>2. Get the APP and Account</h3> </div> <div data-bbox="1726 631 1953 685"> <p>For the best experience, please download the "Tuya smart" APP to your smartphone from App Store or Google Play, or you can also scan the QR code below, the APP icon will be displayed after installed successfully.</p> </div>	<div data-bbox="2004 375 2228 493"> </div> <div data-bbox="2004 524 2234 547"> <p>Launch the app from your smartphone and click the Sign Up button. Follow the on-screen instructions.</p> </div> <div data-bbox="2004 567 2150 578"> <h3>3. Insert the Micro SD card</h3> </div> <div data-bbox="2004 586 2234 594"> <p>Insert the Micro SD card gently on the side edge of doorbell.</p> </div> <div data-bbox="2065 629 2168 739"> </div>
--	--	---	--	--

成品尺寸: 77*120mm 展开尺寸: 385*120mm

尺寸公差			要求		品名	IPC_E93G_中性_折页_说明书		比例	1:1	日期 DATE	2022.09.06
位数	尺寸	角度	128g铜版纸, 单黑色两面印刷, RoHS								
x/x.x	±1mm	±1°					料号	40610E93G0002	设计 DESIGNED	夏媛媛	审核 CHECKED
		±1°			版本 FORMAT	A					
							深圳奥尼电子股份有限公司 SHENZHEN AONI ELECTRONIC CO., LTD				
记 事			变更NO.	年/月/日							