## Conference Speakerphone



User Manual

## What's in the box




Wireless Speakerphone X 1



USB Cable X 1

User Manual X 1

## Overview



## Easy Set-up

### 1. On/off

Long press ON/OFF **O** for 2s, device will be turn on/off, with beep notice.

## 2. Connect to speak 100 USB & BT

2.1 Connect by Bluetooth Long press Bluetooth button for 2 seconds to start pairing mode, then turn on Bluetooth of mobile phone or computer and select device Speak 100 USB & BT to connect. When connection is completed, the lamp ring will be fully on in blue, with voice notice.







2.2 Connect by USB Connect Speak 100 USB & BT with computer by USB cable. After connection, the green circle light will increase clockwise one by one showing charging status. Green circle light will be on in full when charging completed.



# 3. Audio source switching function

When device is connected by Bluetooth and USB simultaneously, short press / tap the Bluetooth button to switch between Bluetooth and USB transmission.

## 4. Answer /end calls

Press 🕵 button to answer calls, press 🕵 button to end calls.

## 5. Volume increase/decrease

When volume increase + /decrease - , the green lights will on/off one by one. When adjustment completed, lights will off after 4s.

6.1 Press Mute 🌋 , microphone audio input will stop.

6.2 Long press the mute key 🌠 for about 2s to switch VoiceCap mode. The Voicecap function is for eliminating surrounding noise automatically and only voice within radius range of 1.5 meters will be picked up and transmited. Also speaker volumn will be adjusted automatically according to surrounding noise. VoiceCap model is only suggested in open space. Please disable this function when in conference rooms.

## 7. Auto Power Of

When device is not connected by Bluetooth or USB in 15mins, it will shut down automatically.

## 8. Power indicator

When device is not connected by USB, short press / tap power button  ${\Large \bigodot}$  , the green circle light will indicate power condition.

### FCC Statement

FCC Statement

This device complex will Part 1 of the TCD robe. Operation is audior to be
the device must accept any in dender reprint class is small statement, and other
the device must accept any interference instance, including interference and other
cases included operation.

In the device must accept any interference included, including interference and other
acceptance in the statement of the CCD statement of the statement of the device of the complex of the device of

Radiation Exposure Statement
This device complies with RF radiation exposure limits set forth for an
uncontrolled environment. This transmitter must not be co-located or operating in
conjunction with any other antenna or transmitter.