

# 9折页说明书 80\*80mm





# (1) Short press the action button to check the current Wi-Fi status. If the sensor is paired with a network. the Wi-Fi indicator light will flash once, and the data will be synced to the app. Conversely, if the sensor is not paired with a network, the Wi-Fi indicator light will flash and enter the pairing state. 2) Long press the action button to reset the Wi-Fi of the sensor and pair the network with Wi-Fi. 2 Technical Specifications

#### -20°C~60°C (-4°F~140°F) Measurement Range Typical: ±0.3°C/±0.5°F Temperature Accuracy Max: ±0.5°C/±0.9°F 0%RH~99%RH Humidity Range Typical: ±3%RH Humidity Accuracy (25°C/77°F, 20%~80%RH) Max: ±4.5%RH Typical: ±4.5%RH RH Humidity Accuracy (25°C/77°F, 0%~100%RH) Max: ±7.5%RH 10min. 30min. 60min (default), 120min, 180mi Data Recording Interval 240min (The longer the interval, the longer the battery life.) Sampling Interval Max: ±7.5%RH Warranty 1 Year

## **3 APP Connection**

## 3.1 Download the INKBIRD App



Search the INKBIRD App from Google Play or App Store to get it for free, or you can scan the left QR code to download it directly.

1. Your iOS devices must be running iOS 10.0 or above to download the app smoothly.

2. Your Android devices must be running Android 4.4

or above to download the app smoothly.

3. The device supports a 2.4GHz Wi-Fi router only.

## 3.2 Registration

- 3.2.1 Open the app. select your Country/Region, and a verification code will be sent to you.
- 3.2.2 Enter the verification code to confirm your identity, and the registration is complete.
- 3.2.3 Registering an account is necessary before using the INKBIRD app for the first time.

### 3.3 Connect to Your Phone



3.3.1 Open the app and click "+" in the upper right corner to choose IBS-TH3 to start the connection.




Books

3.3.2 Please make sure installed correctly. When

3.3.3 Please select the


Plant solut Book Systems to thyse, do not have a password, year form, and an old it. Hereses


Wi-Fi network you want to connect to and enter the password, then click "Next Step" to continue.




244










#### 3.5 Main Interface of INKBIRD App Enter the setting interface ✓ IBS-TH3 ് ca.41 : Battery Level



## 4 Safeguards

- 1. Please do not disassemble the product if you are not a professional. 2. Be sure that the sensor is not covered with dust as
- dust may lead to inaccurate measurements.
- 3. Do not use alcohol to clean the sensor.

## 5 Product Warranty

This item carries a 1-year warranty against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of INKBIRD, be either repaired or replaced without charge.

## 6 FCC Requirement

## subject to the following two conditions: (1) this device may not cause harmful interference,

Changes or modifications not expressly approved by

the party responsible for compliance could void the

user's authority to operate the equipment. This device

complies with Part 15 of the FCC Rules. Operation is

- (2) this device must accept any interference received.
- including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

is no guarantee that interference will not occur in a

particular installation. If this equipment does cause

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## **INKBIRD TECH.C.L**

support@inkbird.com

Factory address: 6th Floor, Building 713, Pengji Liantang Industrial Area, NO.2 Pengxing Road, Luohu Disctrict, Shenzhen, China

Office address: Room 1803, Guowei Building, NO.68 Guowei Road, Xianhu Community, Liantang, Luohu District.Shenzhen, China















