



## 802.11g CHANNEL 2, CARRIER LEVEL




## 802.11g CHANNEL 2, BAND EDGE



## 802.11g CHANNEL 8, CARRIER LEVEL




## 802.11g CHANNEL 8, BAND EDGE



## 802.11g CHANNEL 9, CARRIER LEVEL




## 802.11g CHANNEL 9, BAND EDGE



## 802.11g CHANNEL 10, CARRIER LEVEL




## 802.11g CHANNEL 10, BAND EDGE




## 802.11g CHANNEL 11, CARRIER LEVEL



## 802.11g CHANNEL 11, BAND EDGE




## 802.11n-20 MHz CHANNEL 1, CARRIER LEVEL



## 802.11n-20 MHz CHANNEL 1, BAND EDGE




## 802.11n-20 MHz CHANNEL 2, CARRIER LEVEL




## 802.11n-20 MHz CHANNEL 2, BAND EDGE




## 802.11n-20 MHz CHANNEL 8, CARRIER LEVEL




## 802.11n-20 MHz CHANNEL 8, BAND EDGE



## 802.11n-20 MHz CHANNEL 9, CARRIER LEVEL




## 802.11n-20 MHz CHANNEL 9, BAND EDGE




## 802.11n-20 MHz CHANNEL 10, CARRIER LEVEL




## 802.11n-20 MHz CHANNEL 10, BAND EDGE




## 802.11n-20 MHz CHANNEL 11, CARRIER LEVEL



## 802.11n-20 MHz CHANNEL 11, BAND EDGE




## 802.11n-40 MHz CHANNEL 3, CARRIER LEVEL




## 802.11n-40 MHz CHANNEL 3, BAND EDGE




## 802.11n-40 MHz CHANNEL 4, CARRIER LEVEL




## 802.11n-40 MHz CHANNEL 4, BAND EDGE




## 802.11n-40 MHz CHANNEL 5, CARRIER LEVEL




## 802.11n-40 MHz CHANNEL 5, BAND EDGE




## 802.11n-40 MHz CHANNEL 7, CARRIER LEVEL




## 802.11n-40 MHz CHANNEL 7, BAND EDGE




## 802.11n-40 MHz CHANNEL 8, CARRIER LEVEL




## 802.11n-40 MHz CHANNEL 8, BAND EDGE




## 802.11n-40 MHz CHANNEL 9, CARRIER LEVEL



## 802.11n-40 MHz CHANNEL 9, BAND EDGE




## VHT-20 MHz CHANNEL 1, CARRIER LEVEL




## VHT-20 MHz CHANNEL 1, BAND EDGE




## VHT-20 MHz CHANNEL 2, CARRIER LEVEL




## VHT-20 MHz CHANNEL 2, BAND EDGE




## VHT-20 MHz CHANNEL 8, CARRIER LEVEL




## VHT-20 MHz CHANNEL 8, BAND EDGE




## VHT-20 MHz CHANNEL 9, CARRIER LEVEL




## VHT-20 MHz CHANNEL 9, BAND EDGE




## VHT-20 MHz CHANNEL 10, CARRIER LEVEL




## VHT-20 MHz CHANNEL 10, BAND EDGE




## VHT-20 MHz CHANNEL 11, CARRIER LEVEL



## VHT-20 MHz CHANNEL 11, BAND EDGE




## VHT-40 MHz CHANNEL 3, CARRIER LEVEL




## VHT-40 MHz CHANNEL 3, BAND EDGE




## VHT-40 MHz CHANNEL 4, CARRIER LEVEL




## VHT-40 MHz CHANNEL 4, BAND EDGE




## VHT-40 MHz CHANNEL 5, CARRIER LEVEL




## VHT-40 MHz CHANNEL 5, BAND EDGE




## VHT-40 MHz CHANNEL 7, CARRIER LEVEL




## VHT-40 MHz CHANNEL 7, BAND EDGE



## VHT-40 MHz CHANNEL 8, CARRIER LEVEL




## VHT-40 MHz CHANNEL 8, BAND EDGE



## VHT-40 MHz CHANNEL 9, CARRIER LEVEL



## VHT-40 MHz CHANNEL 9, BAND EDGE




## 802.11ax-20 MHz(SU) CHANNEL 1, CARRIER LEVEL




## 802.11ax-20 MHz(SU) CHANNEL 1, BAND EDGE



## 802.11ax-20 MHz(SU) CHANNEL 2, CARRIER LEVEL



## 802.11ax-20 MHz(SU) CHANNEL 2, BAND EDGE




## 802.11ax-20 MHz(SU) CHANNEL 3, CARRIER LEVEL




## 802.11ax-20 MHz(SU) CHANNEL 3, BAND EDGE



## 802.11ax-20 MHz(SU) CHANNEL 8, CARRIER LEVEL




## 802.11ax-20 MHz(SU) CHANNEL 8, BAND EDGE




## 802.11ax-20 MHz(SU) CHANNEL 9, CARRIER LEVEL




## 802.11ax-20 MHz(SU) CHANNEL 9, BAND EDGE




## 802.11ax-20 MHz(SU) CHANNEL 10, CARRIER LEVEL




## 802.11ax-20 MHz(SU) CHANNEL 10, BAND EDGE




## 802.11ax-20 MHz(SU) CHANNEL 11, CARRIER LEVEL



## 802.11ax-20 MHz(SU) CHANNEL 11 BAND EDGE




## 802.11ax-40 MHz(SU) CHANNEL 3, CARRIER LEVEL




## 802.11ax-40 MHz(SU) CHANNEL 3, BAND EDGE




## 802.11ax-40 MHz(SU) CHANNEL 4, CARRIER LEVEL




## 802.11ax-40 MHz(SU) CHANNEL 4, BAND EDGE




## 802.11ax-40 MHz(SU) CHANNEL 5, CARRIER LEVEL




## 802.11ax-40 MHz(SU) CHANNEL 5, BAND EDGE



## 802.11ax-40 MHz(SU) CHANNEL 7, CARRIER LEVEL




## 802.11ax-40 MHz(SU) CHANNEL 7, BAND EDGE




## 802.11ax-40 MHz(SU) CHANNEL 8, CARRIER LEVEL




## 802.11ax-40 MHz(SU) CHANNEL 8, BAND EDGE



## 802.11ax-40 MHz(SU) CHANNEL 9, CARRIER LEVEL



## 802.11ax-40 MHz(SU) CHANNEL 9, BAND EDGE



## MIMO-Aux. Antenna

## 802.11b CHANNEL 1, CARRIER LEVEL




## 802.11b CHANNEL 1, BAND EDGE




## 802.11b CHANNEL 11, CARRIER LEVEL



## 802.11b CHANNEL 11, BAND EDGE




## 802.11g CHANNEL 1, CARRIER LEVEL




## 802.11g CHANNEL 1, BAND EDGE




## 802.11g CHANNEL 2, CARRIER LEVEL




## 802.11g CHANNEL 2, BAND EDGE




## 802.11g CHANNEL 8, CARRIER LEVEL




## 802.11g CHANNEL 8, BAND EDGE




## 802.11g CHANNEL 9, CARRIER LEVEL




## 802.11g CHANNEL 9, BAND EDGE




## 802.11g CHANNEL 10, CARRIER LEVEL




## 802.11g CHANNEL 10, BAND EDGE




## 802.11g CHANNEL 11, CARRIER LEVEL



## 802.11g CHANNEL 11, BAND EDGE



## 802.11n-20 MHz CHANNEL 1, CARRIER LEVEL



## 802.11n-20 MHz CHANNEL 1, BAND EDGE

