

TPMS User Manual



INSTRUCTIONS TO TRAIN TPMS:

NOTE: read the instructions completely before attempting. Be sure to complete steps 1-7 as quickly and smoothly as possibly.

1. Insert key into the ignition and turn to the OFF position
2. Press and release the brake pedal
3. Turn the ignition from OFF to RUN 3 times, ending in RUN
4. Press and release the brake pedal
5. Turn the ignition to the OFF position
6. Turn the ignition from OFF to RUN 3 times, ending in RUN
7. At this time the horn will honk 3 times and a message will flash in the dash
8. Training mode is now active.
9. Starting at the LEFT FRONT wheel place the training tool at the base of the valve stem.
10. Press and release the sensor training tool learn button. The vehicle's horn will sound when the TPMS is successfully trained. It can take up to 10 seconds for the TPMS to be recognized and trained.
11. Repeat steps 9 and 10 for the remaining sensors in this order RIGHT FRONT, RIGHT REAR, LEFT REAR. Training mode remains active for 2 minutes between each successful training.
12. Turn the ignition to the OFF position to exit training mode.

Vehicles without message center: If the vehicle horn DOES NOT sound (when ignition is turned to OFF position) this indicates training was successful. If the horn sounds TWICE this indicates training was unsuccessful.

Vehicles with message center: TIRE TRAINING COMPLETE will display if successful

FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.