

1. Change Description

1) Changed Antenna

Previous Version	New Version	Remark
		Antenna pattern changed.

2) Changed MP3 KEY

Previous Version	New Version	Remark
		Touch pad module → push type like that main key
		Touch pad module → push type like that main key