



READY TO GET STARTED?

We hope you're all set to get started. Take your new earbuds out of the charging case and make the primary device your earbuds connect to.

MOD 180

- Place earbuds back in the charging case and the LED will flash. Remove them from the case again.
- Open Bluetooth settings on your phone. Select "MOD 180" from the list of available devices.
- Accept any PTT or PTC prompts. Your earbuds will connect to your device. They are now ready to use.

POWER ON / OFF

Remove the earbuds from the case to power ON your earbuds. Place the earbuds in the case to power OFF your earbuds. Press and hold the touch surface for 3 seconds to power ON your earbuds. Press and hold the touch surface for 3 seconds to power OFF your earbuds.

POWER ON / OFF

- POWER ON / OFF**
 - Touch: Power
 - Press: Power
 - Press: Power
 - Press: Power
- POWER AND HOLD 1 SECOND**
 - Volume Up
 - Volume Down
- POWER 2 TIMES**
 - Next Track
- POWER 3 TIMES**
 - Next Track
- POWER AND HOLD 3 SECONDS**
 - Pair New Device

HAVING TROUBLE?

If you're having trouble with your earbuds, check the following steps to troubleshoot and fix the issue.

PAIRING AUDIO BY ONE EARBUDD

Let's re-pair your earbuds. Place them in the charging case and ensure both LEDs turn white. When removed, your earbuds should flash white. If you want the earbuds to be used as a stereo pair again:

- On your device, open Bluetooth settings and turn Bluetooth OFF.
- Remove both earbuds from the charging case. Make sure they are both powered ON.
- Press BOTH earbuds 3 times. The LEDs will flash white on the earbuds in pairs, once removed from earbuds. If both LEDs together flash.
- On your device, turn your Bluetooth back ON and select "MOD 180" in your paired list. If you see two devices, select the one you want to pair.
- LEDs on both earbuds will flash 3 times and a voice prompt will indicate when the earbuds have successfully paired.

FULL RESET TO FIX PAIRING ISSUES

- On your device, open your Bluetooth settings and remove "MOD 180" from your paired devices. Then turn Bluetooth OFF.
- Remove both earbuds from the case. Press and hold the touch surface on both earbuds for 3 seconds.
- Both earbuds will flash red and blue 3 times. A voice prompt will indicate a successful reset and your earbuds will enter pairing mode.
- On your device, open Bluetooth settings and turn Bluetooth ON. Select "MOD 180" and accept any PTT or PTC prompts to complete pairing.

For more help, visit our support center at www.skullcandy.com/support/mod180.

PRÊT À COMMENCER?

Voilà, vous êtes prêts à commencer. Sortez vos écouteurs de la boîte de charge et connectez-les à votre appareil. Sélectionnez "MOD 180" dans la liste des appareils Bluetooth disponibles.

MOD 180

- Placez les écouteurs dans la boîte de charge et l'LED clignotera. Retirez-les de la boîte de charge.
- Ouvrez les paramètres Bluetooth sur votre appareil. Sélectionnez "MOD 180" dans la liste des appareils Bluetooth disponibles.
- Acceptez toute demande de connexion. Vos écouteurs seront connectés à votre appareil. Ils sont prêts à être utilisés.

COMMANDE AVEC LES BOUTONS

Retirez les écouteurs de la boîte de charge pour les allumer. Placez les écouteurs dans la boîte de charge pour les éteindre. Appuyez et maintenez le bouton tactile pendant 3 secondes pour allumer les écouteurs. Appuyez et maintenez le bouton tactile pendant 3 secondes pour éteindre les écouteurs.

COMMANDE AVEC LES BOUTONS

- APPUYEZ 1 FOIS**
 - Volume Up
 - Volume Down
- APPUYEZ ET MAINTENEZ PENDANT 1 SECONDE**
 - Next Track
- APPUYEZ 2 FOIS**
 - Next Track
- APPUYEZ 3 FOIS**
 - Next Track
- APPUYEZ AND HOLD 3 SECONDS**
 - Pair New Device

AVOIR DES PROBLÈMES?

Cela arrive, mais ne vous inquiétez pas. Voici quelques étapes à suivre pour résoudre les problèmes de connexion et de charge.

AUDIO MANQUANT DANS UN COULEUR

Si vous ne pouvez pas entendre les deux écouteurs Bluetooth, vérifiez les paramètres de votre appareil. Assurez-vous que les deux écouteurs sont connectés à votre appareil. Si vous ne pouvez pas entendre les deux écouteurs, vérifiez les paramètres de votre appareil. Assurez-vous que les deux écouteurs sont connectés à votre appareil.

LES VOSPER LED DES DEUX ÉCOUTEURS CLIGNOTENT EN BLEU

Les voyants LED des deux écouteurs clignotent en bleu. Cela indique que les deux écouteurs ne sont pas connectés à votre appareil.

FULL RESET TO FIX PROBLEMS D'APPARIEMENT

- Sur votre appareil, allez dans les paramètres Bluetooth et supprimez "MOD 180" de votre liste d'appareils Bluetooth.
- Retirez les deux écouteurs de la boîte de charge. Appuyez et maintenez le bouton tactile pendant 3 secondes.
- Appuyez et maintenez les deux écouteurs pendant 3 secondes.
- Les deux écouteurs clignotent en rouge et en bleu 3 fois. Un signal sonore indiquera une réinitialisation réussie. Vos écouteurs sont maintenant prêts à être utilisés.
- Sur votre appareil, allez dans les paramètres Bluetooth et sélectionnez "MOD 180" et acceptez toute demande de connexion.

For more help, visit our support center at www.skullcandy.com/support/mod180.