4.07.03.01.00958MiLi Mag-Soundmate 英文说明书60x40mm HD-M12-128g双铜单色正反印刷风琴折V2

•Recharge your speaker.

•Adjust volume on this product.

•Adjust volume on the connected

Make sure that your Bluetooth device

is within the effective operational

- 10 -

No sound

device.

range.

Mag-SoundMate Mini MagSafe Bluetooth Speaker	Thank You for Choosing MiLi! It's a great pleasure to share with you the conveniences and benefits brought by MiLi smart lifestyle gadgets. With the prevalence of mobile devices in everyday life.MiLi will adopt the latest charging technol- ogy to power your life.Don't forget to register your product on www.mymi- li.com to activate your warranty! Please read the instructions and warnings carefully before using the product. Misuse harms the product and hurts people. The manual contains the correct usage and neces- sary safe use information. Please read carefully. The product and accessory pictures are just for reference. Please refer to the actual ones. Important Safety Information -01-	 Please comply with following basic safety instructions to guarantee safe and reliable use of the product. Comply with all warnings and guide information marked on the product. Please use charging equipment that can supply 5V of output voltage to avoid damage to the equipment. The product adopts built-in polymer lithium battery,please shut down when not in use. <u>A</u> Caution Removal of the built-in battery invalidates the warranty and may destroy the product. <u>Note</u> Rechargeable batteries have a limited number of charge cycles vary by -02- 	use and settings. Warning • Never operate when the product is wet, or dropor spill any liquid on the product. • Never place the product close to high temperature heat source, or dry or blow the product at high temperature. • Never apply great pressure on the product. Product Specification Product Model : HD-M12 Bluetooth version : 5.0+EDR Input : 5V=1A Loudspeaker : 3W Wireless Bluetooth Range : 10m Time of use : 6~8hours Charging time : 1.Shours Case material : ABS+PC Capacity : 420mAh Weight : 80g -03-	What's in the box Mag-SoundMate*1 Steel ring*2 USB-C Cable*1 User manual*1 Product Configuration Dust-proof mesh cloth cover Silicone plug Lithium polymer Silicone plug Lithium polymer Non-slip silicone pad -04 -	How to Use This Product Type-C Power button/indicator • Charge the built-in battery The speaker is powered by a built-in rechargeable battery. Note: • Before use, Please fully charge the built-in battery. • while power on, if Bluetooth is interrupted or disconnected for 5 minutes, the device will power off automatically. - 05 -	 Keep pressing the power button for 3s to turn on and off the device, followed by a voice alert, and the same operation for the Bluetooth connection and disconnection. While music playing, press the power button once to pause/play; After the Bluetooth connection succeeds, the device's power status will display on your phone's screen. How to get into TWS mode for 2 Speakers? Power on one Speaker and get it connected with your phone via Bluetooth. 	2. Power on the other one, then double-click it to get into(or out off) TWS mode. Note: in TWS mode, your phone only need to connect one Speaker via Bluetooth. Tips: If you power on two Speakers simultaneously before Bluetooth connected properly, please power off one Speaker first and follow the operation instruction above to get into TWS mode Note: When the device's power is drained below 10%, the indicator will spark blue and will shut down automatically later on, followed by a "power off" voice alert. -07-
Use Bluetooth Devices With the speaker, you can listen to audio from a player and make a call through Bluetooth. Note: • The operational range between this product and a Bluetooth device is approximately 10 meters (30 feet). • Any obstacle between this product and a Bluetooth device can reduce the operational range. • Keep away from any other electronic device that may cause	•On your device, disable the Bluetooth connection with this speaker. •The speaker prompt with a voice Bluetooth Exit when is disconnected. Note: Before connecting another Bluetooth device, disconnect the current device first. Reconnect a device For a paired Bluetooth device on which the automatic reconnection is enabled, this product reconnects	Trouble Shooting Note: To keep the warranty valid, never try to repair the product yourself. If you encounter problems when using this device, check following points before requesting service. If this not help, you can choose to replace or repair after the failure (not caused by human) is inspected and confirmed. No power	No response from the speaker •Restart the speaker. •Apply a needle into the microphone to reset the speaker About Bluetooth device The audio quality is poor after connec- tion Move the device closer to this product or remove any obstacle between them. Cannot connect with the device	Magnetic adsorption Used as a stand	MiLi Manufacturer's Product Warranty MiLi 1 Year Limited Warranty Hali-Power's warranty obligations for MiLi products are limited to the terms set forth below: Shenzhen Hali-Power Industrial Co., Ltd. ("MiLi") warrants MiLi products against defects in materials and workmanship for a period of 1 year from the date of original purchase("Warranty Period"). All products must be registered	 (2) Exchange the product with another new product. (3) The freight arose from goods return will be shared by MiLi and Customer together. (customer will have to bear the freight to factory, while, MiLi will bear the freight to customer). For any mainte- nance and repairs out of service range, customer will have to bear the freight and any relevant charges. 	technology to power your life. Don' t forget to register your product on www.mymili.com to activate your warranty! Please read the instruc- tions and warnings carefully before using the product. Misuse harms the product and hurts people. The manual contains the correct usage and necessary safe use information. Please read carefully. The product and accessory pictures are just for reference. Please refer to the actual

Note:

the box.

The non-magnetic phone or non-me-

tallic objects can be attached to the

Speaker with a steel ring packed in

- 12 -

ones.

er.com

Contact us!

If you have any questions or

problems with your product, please

Customer Support: cs@hali-pow-

- 15 -

don't hesitate to reach us at:

Website: www.mymili.com

Exclusions and Limitations

It's a great pleasure to share with

vou the conveniences and benefits

brought by MiLi wireless charging

technology. With the prevalence of

mobile devices in everyday life, MiLi

will adopt the latest charging

- 14 -

online within 90 days from the

purchase date to qualify 1 year

warranty. If a defect arises and a valid

claim are received by MiLi within the

Warranty Period, at an option, MiLi

(1) Repair the product freely, using

new or refurbished replacement

- 13 -

will

parts.

Cannot connect with the device

another Bluetooth device.

again.

This product has connected with

Disconnect that device and then try

- 11 -

interference. Connect a device

•On your device, search for Bluetooth devices.In the device list, select MiLi SoundMate. The speaker prompt with a voice. •Connecting is ok when connection is established.

with it once it is detected. For a

paired Bluetooth device that does

not support the automatic reconnec-

tion, reconnect it with this product

Note: If there is an incoming call on

the connected mobile phone, music

- 09 -

Play audio via Bluetooth

manually.

play pauses.

Disconnect a device - 08 -

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference.(2)This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or mod

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequence energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an autlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The devicecan be used in portable exposure condition without restriction.