



Label



Label Location

back view



Label Area:

The label is visible to user at the point of sale prior to fitting it to the notebook computer FZ-55.

The label is affixed to the host device using strong adhesive on its backside