


100\*117.7\*38.1mm



## 70mm\*100mm折页

### 手机无线智能遥控器 JX-06

摄像头或阅读器插上电源线，点击更灵敏

#### 使用指南

操作如下手机型号: iPhone X, XS(2.4.0)

长按开机键开机，蓝色指示灯闪烁，在手机蓝牙中搜索，显示设备名称: JX-06，与手机蓝牙配对成功，进入编辑APP，选择编辑APP为默认，按下「摄像按钮」或「摄像按钮」，按下「摄像按钮」即可实现上下左右移动拍摄功能，详细教程请见说明书。

关于苹果手机:

修改苹果手机设置，请注意以下几点:

1. 确保手机OS版本为14.0以上
2. 辅助触控功能必须打开
3. iOS14.0以上版本按键方可使用，设置如下:设置->辅助功能->触控->触控->打开，关闭触点不在屏幕上，勾选轻点模式，设置如下:

以上步骤完成后OK，若还不能正常使用请打开手机蓝牙并打开4.打开辅助触控，点击右上角，大的圆点可以移动，小的圆点有办法移动，不能控制时请重试，安卓手机需要完成以下步骤:

1. 手机OS版本不低于安卓10.0，不能刷机，请保持触控开关打开后才能正常使用

加入会员后请关机，拿起设备进行充电，充电时触点不在屏幕上，可参考图2。

提示:如因OS系统升级造成本产品不能使用，属不可抗力。

微信扫描二维码进入JX-06视频教程

### 合格证

型号: \_\_\_\_\_

检验员: \_\_\_\_\_

出厂日期: \_\_\_\_\_

### Mobile phone wireless smart remote control JX-06

insert the power cord into the page flipping or reading device, and click more sensitively

#### Button function description

Figure 1

1. Hold down to power on the device and click Start
2. Hold down the number plus and click the number minus

Function description 4 parts

In the first part, as shown in Figure 1, the product uses the JX slider to turn on the phone, adjust the number of clicks, and click the number minus (the remote control can be used to control, and the device can be connected to each other and cannot be connected to the phone's Bluetooth). If the problem is solved, you can click at an adjustable slow speed, read/Talk (see the recommended to be used 4 times to 18 times per second, and Talk (see the recommended to be used 2 times to 8 times per second). The maximum number of clicks that each mobile phone can accept is different, which can be adjusted freely, and 90 clicks can be accepted at all.

The second part is the JX 06, which is powered on separately and connected to Bluetooth to operate the mobile phone for taking videos and flipping P pages, as shown in Figure 2. (The JX slider cannot be turned on, and the connection between the two cases, JX 06 is not able to be used to control video flipping.)

The third part is about using Kindle. The two will automatically connect when opened. The JX slider will turn on and turn off the screen. The JX slider will be clipped into the Kindle's back, and plug the remote control, each button can be clicked to turn pages.

The fourth part is to connect the JX slider separately to the phone's Bluetooth for use. (JX 06). Click the slider into a Kindle or other e-book, and use the first key to set the video, and after a few seconds, automatically click video page flipping, then press the first key to start.

#### Certificate of conformity

Model: \_\_\_\_\_

Inspector: \_\_\_\_\_

Date of manufacture: \_\_\_\_\_