

4. Type Label Location

The location of the type label information is on the bottom of the unit, see Figure 1.

