

GOOSENECK BLUETOOTH® FM TRANSMITTER

USER'S MANUAL

Model: VM-208

thank you for choosing VM-207 Bluetooth FM Transmitter. This product is designed and built with high-performance Bluetooth module and audio decoding chip. Not only it can connect the music from the mobile phone to the car stereo through Bluetooth, it can also play music files in U disk and transmit it to the car stereo wirelessly. Built in hands-free phone calls system switches between music and incoming calls seamlessly and enables you talk on the phone freely during your driving. What's more, this Smart FM transmitter is equipped with multi-functions which are controlled by an APP, here are what you could do with this APP: 1. Set frequency to match with the radio 2. Monitor the battery voltage of your car 3. Automatically record where your car is parked and help you locate your car. This product works by means of wireless transmissions, so you can keep the original classic setting of your car and still enjoy music on the road.

Safety Guide

- (1). Do not drop, puncture or disassemble this product;
- (2). This product is not waterproof, please do not expose it to rain or water splashing;
- (3). For safety, do not prolong exposure to direct sunlight;
- (4). Do not place this product in an open flame that may cause an explosion;
- (5). Clean with a clean soft cloth and do not use any corrosive cleaning agent;
- (6). Drive safely. Do not operate this product while driving.

Features

- (1). This device has a car battery voltage display function;
- (2). Support Bluetooth hands-free calling, built-in microphone;
- (3). Support mobile phone A2DP function, directly play high quality music after connecting to Bluetooth;
- (4). Automatically enter the pairing state and connect with your phone after power-on;
- (5). Support U disk to play MP3/WMA/WAV/ FLAC/APE format music;
- (6). Equipped with car charger, output 5V-2.4A.


Descriptions

- ① Function Button
- ② Phone Answering Button
- ③ Pause/Play
- ④ TF Card Slot
- ⑤ Last Track/Next Track
- ⑥ U Disk Slot (Support USB Charging 5V-1A)
- ⑦ AUX Audio Port
- ⑧ LED Display
- ⑨ Microphone
- ⑩ Gooseneck
- ⑪ USB Charging Port 5V-2.4A
- ⑫ Car Charging Adapter
- ⑬ 3.5mm Aux In Cable

Instructions

Insert the product into the car cigarette lighter and start the car engine, it will be powered on automatically.

Press and hold the "CH" button to enter the frequency setting interface. The last track and next track buttons can be used to set the frequency.

<p>Enable Bluetooth on your smartphone and search for available Bluetooth devices, select "VM-208" and connect. The Bluetooth indicating light changes from flashing to long on when the Bluetooth is connected.</p>  <p>When AUX/U Disk/TF Card is inserted, the mode will automatically switch to it. Press "CH" button to switch between Bluetooth, AUX, U Disk and TF modes.</p> <p>Note: You will only be able to switch between the play modes when AUX/U Disk/TF Card is inserted and recognized. In AUX mode, Previous Track and Next Track functions are unavailable, you are able to mute/play the music.</p>	<table border="1"> <tr> <td>Pause/Play</td><td>Press "▶ "</td></tr> <tr> <td>Previous Track/Next Track</td><td>Press "◀◀"/"▶▶"</td></tr> <tr> <td>Clear Bluetooth Connection</td><td>Long Press "◀◀" Last Track Button to Clear the Current Bluetooth Pairing</td></tr> <tr> <td>Switch Mode</td><td>Press "CH" Button to switch to Bluetooth/AUX/U Disk/TF Card Mode</td></tr> </table> <p>Hands-free Phone Calls</p> <p>When the VM-208 Gooseneck Bluetooth FM Transmitter is successfully connected to your smartphone, you can enjoy convenient hands-free phone calls.</p> <table border="1"> <tr> <td>Answer/End</td><td>📞 * Press to Answer/Press to End</td></tr> <tr> <td>Call Back the Last Call</td><td>Press "📞" * Twice</td></tr> </table> <p>Charging</p> <p>VM-208 Gooseneck Bluetooth FM Transmitter has two USB charging ports, one charges up to 5V-2.4A, the other is also used as U Disk slot.</p> <p>Specifications</p> <p>DC Input: 12V-24V DC 2A Output: 5V-2.4A Max Bluetooth Version: V5.0+EDR Audio Frequency: 20H-20KHZ Working Current: 60mA(Max)</p>	Pause/Play	Press "▶ "	Previous Track/Next Track	Press "◀◀"/"▶▶"	Clear Bluetooth Connection	Long Press "◀◀" Last Track Button to Clear the Current Bluetooth Pairing	Switch Mode	Press "CH" Button to switch to Bluetooth/AUX/U Disk/TF Card Mode	Answer/End	📞 * Press to Answer/Press to End	Call Back the Last Call	Press "📞" * Twice	<p>Stand-by Current: 25mA(Max) Bluetooth Working Frequency: 2402~2.480ghz Bluetooth Effective Distance: 32ft</p> <p>FM Emission Effective Distance: 6ft Sensitivity:-89dBm</p> <p>FM Frequency: 88.1MHz-107.9MHz</p> <p>FCC Compliance Statement</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p>	<p>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. <p>Walmart, Inc., Bentonville, AR72716 Walmart.com CUSTOMER SERVICE: support@meiditech.com</p> <p>What's in the Package</p> <ol style="list-style-type: none"> 1). VM-208 Gooseneck Bluetooth FM Transmitter 2). User's Manual 3). 3.5mm Aux In Cable <p>★ Please note product features will be upgraded without any notice.</p>
Pause/Play	Press "▶ "														
Previous Track/Next Track	Press "◀◀"/"▶▶"														
Clear Bluetooth Connection	Long Press "◀◀" Last Track Button to Clear the Current Bluetooth Pairing														
Switch Mode	Press "CH" Button to switch to Bluetooth/AUX/U Disk/TF Card Mode														
Answer/End	📞 * Press to Answer/Press to End														
Call Back the Last Call	Press "📞" * Twice														
<p>5</p>	<p>6</p>	<p>7</p>	<p>8</p>												