

THIM™

THE WEARABLE DEVICE FOR SLEEP.
REINVENTED.



SLEEP RETRAINING
Retrain your sleep behaviours to learn how to fall asleep faster.



POWER NAPPING
For the first time, take the perfectly timed power nap.




SMART ALARM
Wake up when it is best, feel refreshed and ready to start the day.



SLEEP TRACKING
Accurately track your sleep throughout the night.

Manufacturing Barcode


WWW.THIM.IO



Manufactured in Australia by: Maecenas faucibus mollis interdum.
Copyright 2017 Maecenas faucibus mollis interdum.


THIM™

QUICK REFERENCE



LED Indicator Color

- Start or end of features
- Asleep between 0-10 minutes
- Asleep between 11-20 minutes
- Awake for duration of sleep trial
- Feature cancelled



Finger Taps

- 1x** • In response to vibrations from THIM during sleep trials
- 2x** • Start a feature or sleep trial
• Acknowledge a vibration alarm
- 5x** • To cancel a feature



Vibration

- **Soft vibration**
During sleep trials
- **Pulse vibration**
During alerts
- **Ascending vibration**
During alarms

FCC ID: O4GTHIM0290

This device complies with part 15 of the FCC Rules. Operation is subject to the following conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTES:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE GRANTEE OF THIS DEVICE COULD VOID THE USER'S AUTHORITY TO OPERATE THE DEVICE.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio / TV technician for help.

The RF Exposure Compliance distance is 20 millimeters.

IC: 7666A-THIM0290

This device complies with Industry Canada RSS standard(s). Operation is subject to the following two conditions:
(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. CAN ICES-3(B)/NMB-3(B)

Le présent appareil est conforme aux CNR Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) il ne doit pas produire de brouillage et (2) l'utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif. CAN ICES-3(B)/NMB-3(B)

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 millimeters between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 millimètres entre le radiateur et votre corps.