


USER MANUAL



ATGSW6621
BLUETOOTH SPEAKER

FEATURES

Thanks for your purchase of our product. Please read through this manual before making connections and operating this product. Retain this manual for future reference.

- Bluetooth playback
- AUX input
- ●Power supply: DC-5V

Note: Ouse DC adapter or USB terminal to charge battery no matter the speaker power on or off

- •In low battery status, the red indicator flash twice every few seconds and it will switch off automatically if no charged in low battery status.
- •Speaker max output: 5W

ACCESSORY

- User manual
- USB cable
- Carabiner

-1-

PRECAUTION

- Do not drop any objects into the unit through the openings.
- •Do not spill or spray liquid of any kind on or in the unit. It may result in a fire or electric shock.
- Do not place anything heavy on the unit.
- To ensure proper ventilation and proper operation, never cover or block the slots and opening with a cloth or other materials.
- Keep the unit away from an open flame such as fire, candle, etc.
- Install the batteries correctly.
- Please dispose the batteries according to the local rule and law.
- ●The maximum working temperature is 35 degrees Celsius.
- •Only use attachments/accessories specified by the manufacturer.
- •Where the Mains plug is used as the disconnect device, the disconnect device shall remain readily operable.
- Rating label are on the bottom of the unit. WARNING: The batteries shall not be exposed to excessive heat such as sunshine, fire or the like. CAUTION: Danger of explosion if battery is incorrectly replaced.Replace only with the same or equivalent type.

-2-

PANEL



7.VOLUME+ 8.VOLUME-9.DC IN 5V


1. STANDBY

INDICATOR

2. CHARGING

10.AUX INPUT 11.SILICA GEL CAP (PULL UP)

12.MICRÓPHONE



STANDBY/TWS

• Press and hold this button to switch on the speaker, press this button again to switch off the speaker.

TWS

 Press this button to connect or disconnect the speaker bluetooth connection with the other of the same.

VOLUME+

- •When the speaker is in working mode, press to turn up the volume.
- •You will hear the beep sound when you turn up to the maximum volume.

VOLUME-

- •When the speaker is in working mode, press to turn down the volume.
- ●You will hear the beep sound when you turn down to the minimum volume.

PLAY/PAUSE/HANDS FREE/BLUETOOTH

When the speaker is in working mode.

- Press to temporarily pause a playback; press it again to resume the playback.
- Press this button to answer the phone call in hands free when there is a phone call in.
- Press and hold this button to disconnect the bluetooth connections, the speaker will turn to pairing other matching bluetooth device when you hear the short beep sound.


LED INDICATOR STATUS

- When charging your speaker:
 Solid red LED means charging.
 Red LED OFF means charging complete.
- When pairing bluetooth devices:
 Quick flashing blue LED means bluetooth not connected ,ready to pair.
 Solid blue LED means bluetooth connected.
- ●When connected via AUX IN: Solid green LED means connected.

CHARGING

This speaker has a built-in rechargeable Lilon battery. Full charge the speaker before first use. Charge the battery as follows:

- Connect one end of the included USB charging cable to the charging port on your speaker. Then plug the other end of the USB charging cable into a suitable port on your computer or 5V/1A power adapter (sold separately).
- ●The red LED light will turn ON. When the charge is complete the red LED light will turn OFF.



AUX IN

- This speaker has an extra group of audio input terminals. You can input the analogue stereo audio signals from extra devices such as mobile phone, computer, MP3 player, etc.
- Use the audio cable to connect the audio output terminals of mobile phone, computer, MP3 player to the audio input terminal (AUX IN) of this speaker.
- •When the speaker connect the AUX input terminal and the green indicator of AUX keep solid, the speaker will disconnect the bluetooth connection automatically.
- •When the speaker disconnect the AUX input terminal, the speaker will return to the previous bluetooth connnection.



7

-4-

-5-


BLUETOOTH CONNECTION

- The bluetooth pairing model of the speaker is ATGSW6621, power on the speaker by pressing and holding the STANDBY button, the blue indicator flashing, the speaker is in searching bluetooth signal status, the unit will synchronize to play songs on your smart phone while the blue indicator keep solid blue means bluetooth was connected successfully.
- ●The speaker need to input the password 0000 when the matching bluetooth device under version 2.1.
- ●The bluetooth will turn to standby mode after 10 minutes without connections, at this time, press and hold [STANDBY] button to wakes up the speaker.
- When the operation too frequently or other reason to disturb the bluetooth reconnected, please use manually connect on the bluetooth device.
- ●The bluetooth is connected to your smart phone successfully for the first time, disconnect the bluetooth on your smart phone then reconnected it, the speaker will memories your smart phone and repaired automatically.Press [PLAY/PAUSE] to

resume the playback.

Note:

- •Bluetooth connection range in 10 meters;
- ●The model ATGSW6621 in your device was not deleted;
- After 10 minutes without connections, the speaker go to dormant status and you need to press and hold [STANDBY] button to wake up the speaker.



TWS CONNECTION

- ●This TWS(TRUE WIRELESS STEREO) bluetooth connection only use between the same two speakers.
- ●Power on both speakers, the blue LED will begin to flash, press the TWS button on both speakers simultaneously, wait a few seconds to pair automatically, once connected successfully, the blue indicator keep flashing is configured as the master, the blue indicator keep solid blue is configured as the slave.
- Enable your bluetooth device and make sure it is in searching mode.
- Select "ATGSW6621" from the list of discovered devices and connect to it.
- ●The master speaker will act as the left channel during TWS and will receive the bluetooth signal, the other speaker will act as the right channel.
- If you use AUX IN mode to connect and play music with external device, only connect the master to play music.

FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

-8-

-9-

FCC STATEMENT

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct theinterference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

-12- R&D
DISTRIBUTING
WWW.teamprogressive.com

-10-

-11-

-11-