

Date: 23 JAN 2024  
Product: EP-0706 IM

Portable Charging Case  
Front



Size: 222.75(W) x 105(H)mm

## FRONT SIDE

Thank you for purchasing the Chic True Wireless Earbuds. This manual provides basic information about the wireless earbuds. Please read the instructions before using.

**Product Overview**

Earbuds

Instruction Manual

1. Touch Button  
2. Play/Pause Button  
3. Volume Up/Down Buttons  
4. USB Type-C Charging Port  
5. USB Type-C Charging Cable

Note: Remove the protective stickers upon first use.

**Package Contents**

1 Chic True Wireless Earbuds in 1 Case  
1 USB Type-C Charging Cable  
1 Instruction Manual

**Specifications**

Driver: 10mm  
Frequency: 20Hz - 20kHz  
Frequency Response: 20Hz - 20kHz  
Sensitivity: 98dB ± 3dB  
Battery Capacity: 100mAh  
Charging Time: 1.5h  
Charging Case Capacity: 1000mAh  
Charging Case Battery Life: 10h  
USB Type-C Charging Cable: 1m

**Power On/Off**

**Power On:**  
Press and hold the Power On button for 3 seconds and the LED will turn on.

**Power Off:**  
Press and hold the Power Off button for 3 seconds and the LED will turn off.

**Pair the wireless earbuds with your mobile device**

1. Keep the earbuds in the charging case with the lid open.
2. Turn on the Bluetooth function on your mobile device.
3. The earbuds will be in pairing mode. The earbuds will start flashing red and blue light. The earbuds will be in pairing mode for 3 to 5 minutes.
4. Select the earbuds from the list of devices.
5. After pairing is successful, the earbuds will start flashing blue light.

**Reconnect the wireless earbuds to your mobile device**

When powered on, the wireless earbuds will automatically connect with the last connected mobile device.

**Disconnect the wireless earbuds from your mobile device**

When off the mobile device, or  
When off the Bluetooth on your mobile phone, or  
When the earbuds are in pairing mode, the earbuds will be disconnected.

## BACK SIDE

**Accessories / Support & Us**

When using or off, press the Touch Button only to allow earbuds to connect to the case. Press the case normally to your mobile phone.

**Safe & Use**

To ensure safe use, please follow the following instructions:

**Functions**

Press the Touch Button: When the earbuds are in the charging case, the earbuds will be in pairing mode. Press the Touch Button to turn on the earbuds.

**Charging your Earbuds**

1. Turn the charging case on.
2. Press the earbuds into the charging case.
3. Press the earbuds into the charging case.
4. The earbuds will start charging automatically.
5. The earbuds will stop charging when the LED indicator light is off.

**Recharge Charging Case**

1. The earbuds will start charging when the LED indicator light is on.
2. The earbuds will stop charging when the LED indicator light is off.

**NOTE:**

1. The earbuds will start charging when the LED indicator light is on.
2. The earbuds will stop charging when the LED indicator light is off.

**FAQ**

**Q: The wireless earbuds cannot be paired with my device.**  
**A:** Please check the following:  
1. The earbuds are in pairing mode.  
2. The earbuds are in pairing mode.  
3. The earbuds are in pairing mode.  
4. The earbuds are in pairing mode.  
5. The earbuds are in pairing mode.  
6. The earbuds are in pairing mode.  
7. The earbuds are in pairing mode.  
8. The earbuds are in pairing mode.  
9. The earbuds are in pairing mode.  
10. The earbuds are in pairing mode.

**Q: The charging case cannot be recharged.**  
**A:** Please check the following:  
1. The charging case is in pairing mode.  
2. The charging case is in pairing mode.  
3. The charging case is in pairing mode.  
4. The charging case is in pairing mode.  
5. The charging case is in pairing mode.  
6. The charging case is in pairing mode.  
7. The charging case is in pairing mode.  
8. The charging case is in pairing mode.  
9. The charging case is in pairing mode.  
10. The charging case is in pairing mode.

**Q: The earbuds are not working properly.**  
**A:** Please check the following:  
1. The earbuds are in pairing mode.  
2. The earbuds are in pairing mode.  
3. The earbuds are in pairing mode.  
4. The earbuds are in pairing mode.  
5. The earbuds are in pairing mode.  
6. The earbuds are in pairing mode.  
7. The earbuds are in pairing mode.  
8. The earbuds are in pairing mode.  
9. The earbuds are in pairing mode.  
10. The earbuds are in pairing mode.

**FCC STATEMENT**

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference.  
(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Get warranty statement**

The device has been tested to meet FCC RF exposure requirements. The device can be used in portable equipment without restriction.

The device has been tested to meet FCC RF exposure requirements. The device can be used in portable equipment without restriction.

The device has been tested to meet FCC RF exposure requirements. The device can be used in portable equipment without restriction.

The device has been tested to meet FCC RF exposure requirements. The device can be used in portable equipment without restriction.

The device has been tested to meet FCC RF exposure requirements. The device can be used in portable equipment without restriction.

The device has been tested to meet FCC RF exposure requirements. The device can be used in portable equipment without restriction.

The device has been tested to meet FCC RF exposure requirements. The device can be used in portable equipment without restriction.

The device has been tested to meet FCC RF exposure requirements. The device can be used in portable equipment without restriction.

The device has been tested to meet FCC RF exposure requirements. The device can be used in portable equipment without restriction.

FCC ID: JADMS-EP-0706

ITEM EP-0706

Keep All Related Information For Future Reference

Manufactured by ZEEVA Inc.  
10000 Market Street, Suite 200  
Philadelphia, PA 19104  
Made in China