


BASE KEY

43-732 BASE KEY




NOTES

1. All resistance values are indicated in "ohm" (K=1000 ohm, M=1000 Kohm)
2. All capacitance values are indicated in "uF" (P=10E-6 uF)


BASE DSP & FLASH MEMORY

NOTES

1. All resistance values are indicated in "ohm" (K=1000 ohm, M=1000 Kohm)
2. All capacitance values are in "uF" (P=10E-6 uF)




43-732, BASE LINE INTERFACE & CP




NOTES


1. All resistance values are indicated in "ohm" (K=1000 ohm, M=1000 Kohm).
2. All capacitance values are indicated in "uF" (P=10E-6 uF).



BASERF



HANDSET MAIN



NOTES

1. All resistance values are indicated in "ohm" (K=1000 ohm, M=1000 Kohm) 2. All capacitance values are indicated in "uF" (P=10E-6 uF)