


|                          |   |
|--------------------------|---|
| EUT External.....        | 1 |
| I Code Antenna .....     | 5 |
| RI-Antenna-T01A-00 ..... | 6 |
| UHF Antenan #1 .....     | 7 |
| UHF Antenna #2 .....     | 8 |
| UHF Antenna #3 .....     | 9 |

## EUT External











## I Code Antenna



RI-Antenna-T01A-00



**UHF Antenan #1**



UHF Antenna #2





**UHF Antenna #3**



