

**jump<sup>2</sup>group**

Color Side 1:  
BLACK  
Color Side 2:  
BLACK

Flat size:  
6.44 x 12.5 in.  
Finished size:  
6.44 x 2.5 in.


Fold:  
5-panel  
accordion



**1 \***




**2**




**3**





- Erases on-screen objects when pressed.
  - Text selection tool.
  - أداة حذف الأشكال على الشاشة.
  - أداة اختيار الموجودة على الشاشة.
  - أداة حذف الأشكال.
  - Henghapus objek pada layar saat dibikin.
  - Alat pemilihan teks.
  - При натискане изтрива обекти на екрана.
  - Инструмент за избор на текст.
  - Při stisknutí vymazá objekty na obrazovce.
  - Nástroj pro výber textu.
  - Setter genantande på skärmen, när den trykkes på den.
  - Værktøj til redigeringsvalg.
  - Durch Drücken dieser Taste werden Objekte auf dem Bildschirm gelöscht.
  - Textauswahltool.
  - Elimina objetos en pantalla al presionarlos.
  - Herramienta de selección del texto.
  - Служебная кнопка для удаления объектов на экране.
  - Служебный инструмент для выделения текста.
  - Un apprendez à supprimer l'effacement des objets à l'écran.
  - Outil de sélection du texte.
  - Brise objets sur la zone où vous le poussez.
  - Alat za izbor teksta.
  - Quando premuto, cancella gli oggetti sullo schermo.
  - Strumento di selezione del testo.



- Інструмент, який видає звукові підказки.
  - Натисніть на це, щоб вибрати об'єкт.
  - Насподіт, що виберете об'єкт.
  - Текста атлантическі ріки.
  - Fægurður til hraðar er alve  
reikjum ogatil.
  - Використання панелей.
  - Є магніум-масажор та інші  
лікарські меблі.
  - Személykörhöz elszálló
  - Als u op deze knop drukt,  
wordt objecten op het  
scherm gewist.
  - Tekstbaseret hentzel.
  - Fjerner objekter på ukjørte  
mål som trykkes på.
  - Verstoy for bekostiging.
  - Po naciągnięciu wymazuje  
obiekty ekranowe.
  - Насподіт замазування тексту.
  - Apaga os objetos no ecrã  
quando premido.
  - Ferramenta de seleção de  
textos.
  - Apaga objetos na tela quando  
pressionado.
  - Ferramenta de seleção do  
texto.
  - Când este apăsat, stergă  
obiecte de pe ecran.
  - Instrument de sarcinare a  
textelor.
  - При нажатии стирает  
объекты на экране.
  - Инструмент выделения  
текста.
  - Po stisknutí vymaže objekty na  
obrazovce.
  - Настінна вибір тексту.
  - Če je pritomen, izbije  
objekte na zaslonu.
  - Очищує залишені об'єкти.
  - Поміщає панелька на панель  
найкращі контекст.
  - Поміщає панелька на панель  
найкращі контекст.



**Specifications**

Temperature, operating      Relative humidity  
0°C to 40°C      (noncondensing), operating  
(32°F to 104°F)      10% to 90%

**Regulatory information**

For regulatory identification purposes, your product is HSN-W004P. If required, regulatory markings for your country or region are located on the side of the product, on the packaging, or elsewhere in this document.

 **WARNING:** To reduce the risk of fire or burns, do not disassemble, crush, or puncture; do not short external contacts; do not dispose of in fire or water.

**RMN/型號/型号:** HSN-W004P

© Copyright 2021 HP Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: October 2021

PRINTER: Replace this box with Printed-in RI Statement(s) as per spec.  
NOTE: This box is simply a placeholder. If Statement(s) do not have to fit inside the box but should be placed in this area.



M96401-B21