
# USER MANUAL: Sterilizer with Wireless



Before using the Multifunction Sterilizer (hereinafter referred to as 'device', the following basic precautions must always be taken:

#### **General Safety information and instructions**

- Carefully read the instructions for use and store them in a safe location. If you give this device to other people, please also pass on this manual.
- Only use this device in accordance with instructions in this user manual. Failure to follow the instructions may result in electric shock, fire and/or serious injury.
- The device is intended for domestic and private use and its intended purpose only. The device is not intended for commercial use.
- Improper use of the device could damage the product.
- The device is not a toy. Keep it out of the reach of children and pets.
- Keep children under strict supervision to prevent them from using the device as a toy.
- Do not allow unsupervised children to clean or maintain this device.
- - WARNING! Do not leave packaging material lying around carelessly. This may become dangerous playing
  - material for children. Risk of suffocation!
  - Prior to use, check the device for visible external damage. Never operate the device if it is damaged.
  - Do not place the device under any mechanical stress.
  - Please handle the device carefully. Jolts, impacts or falls, even from a low height, can damage the device.
  - Do not use or store the device in an environment subject to strong static electricity or magnetic fields.
  - Do not expose the device to direct sunlight, heat sources, excessive humidity or corrosive environments.
  - Do not use the device near water.
  - Never immerse the device in water or any other liquid, to avoid the risk of electric shocks. Do not touch the device if it has fallen into water. Switch OFF the device, remove the power connector from the device and do not use it again.
  - The guarantee will expire immediately if the device is damaged as a result of not observing this user manual. The manufacturer accepts no liability for damage caused by non-compliance with the user manual, negligent use or use which does not comply with the conditions of this user manual.



#### Warnings and instructions

 Do not use the device if it has fallen into water or any other fluid; if liquid has been spilled or if it has been exposed to rain or moisture.



**WARNING!** To reduce the risk of fire or electric shock, protect the device against dripping or splashing water, and keep it away from objects filled with liquids. Such objects should not be placed on or near the device.

- Do not use the device if there are visible signs of damage.
- Do not use the device if it has been dropped or does not operate normally.
- Do not attempt to disassemble or repair the device or modify it in any manner.
- Only allow repairs to be carried out by a qualified service centre. Qualified service centre: after-sales
  department of the manufacturer or store, which is recognised and authorised to carry out such repairs,
  so that potential hazards can be prevented. If problems are encountered with the device, please
  return it to this department.

## **Electricity & heat**

- Never leave the device to charge unattended.
- Regularly check the power cord for damage.
- Do not use the device if the power cord shows signs of damage.
- Make sure the power cord cannot be trodden on or pinched.
- Do not allow the power cord to hang over sharp edges and keep it away from hot objects and naked flames.
- Do not use the device if it has a damaged power cord, if it has become faulty, or if it has fallen or become damaged in any way. Send the device to the manufacturer or the closest qualified service centre for inspection.
- Ensure that the device and power cord do not come into contact with heat sources, such as hotplates or naked flames.
- To reduce or prevent the risk of personal injury, electrical shock, fire or damage to the device, never insert metal objects in any opening of the USB charging port.
- WARNING! Do not open the casing as this may result in electric shock!
- Do not expose the device to excessive heat sources like fire or direct sunlight.
- Do not use or store the device in the immediate vicinity of heat sources such as naked flames.
- Do not crush, puncture or dismantle the device; this might damage the battery.
- WARNING! Damaging the casing and/or piercing the device, can lead to explosion or fire!

#### **Cleaning:**

- Before cleaning the device, always disconnect the device from the power cord.
- Do not use abrasive cleaning solvents to clean the device.
- Clean the exterior of the device with a damp cloth.

## 3) USING THE DEVICE

#### As a Sterilizer:

- It support sterilizing for Mobile phone (up to 6.5inch), Watch, Ornament, Makeup tools, etc.
- Put the device that needs to be sterilized into the sterilizer.
- When you open the lid of machine, it stops sterilizing automatically, and when you close the lid of machine, it resumes working automatically.
- When sterilizing, LED C lights up in Light Blue and you will hear a beep; when finish, it turns off, and you also will hear a beep.
- When sterilizing, LED D flashes Red, and you will hear a beep; when finish, it turns Green and you will also hear a beep.
- Sterilizing time: 10 minutes.

#### As a Wireless Charger:

 Just put the mobile phone upon the lid of the machine, and it will start to charge automatically. When charging, the LED E flashes Red, and when full charged, the LED lights up Green.

Note: Only the mobile phone which supports wireless charger can be used with this machine.

## As an Aromatherapy Diffuser:

- This machine is with Aromatherapy diffuser function.
- Working time: 10 minutes.

Note: Aromatherapy oil is not included in the package.

## 4) FEATURES AND PECIFICATIONS:

- Material: ABS
- UV Wave Length: 253.07nm & 185nm
- Input: 5V/2A; 9V/2A
- Output: 5V/1A; 9V/1.2A
- Sterilizing Power: 2W
- Disinfection Rate: up to 99%
- Size: 210\*129\*52mm
- Weight: 380g

All contents and specifications mentioned in this manual are subject to change without prior notice.

# INSTRUCTIONS FOR PROTECTING THE ENVIRONMENT

(WEEE, the waste electrical and electronic equipment directive)






Your product has been manufactured using high quality materials and components which can be recycled and used again. At the end of its service life, this product<u>cannot</u> be disposed of in normal domestic waste, but must be taken to a special collection point for recycling electrical and electronic equipment. This is indicated in the user manual and in the packaging by the waste container marked with a cross symbol. Used raw materials are suitable for recycling.

By recycling used appliances or raw materials, you are playing an important role in protecting our environment. You can ask your local council about the location of your nearest collection point.

Do not dispose of batteries in your household waste. Dispose of batteries by taking them to your local recycling station. Contact your local government offices for details.



 u
 7## k
 two conditions:

 (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

# **RF** Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter