

### Line description

After turning on the phone, turn on the Bluetooth of the mobile phone and search for the Bluetooth speaker. After the connection is successful, turn on the hand

Player to play music. When playing, you can press the key to switch the up and down music/volume up and down,

Or pause/play the song.

Insert the TF/USB to play the MP3 files in it, and press

Key to switch between up and down music/volume up and down, or pause/play a song.

Press mode plus and minus to switch to AUX mode, you can play external input audio source, play

You can press the button to increase or decrease the volume, or mute the speaker.

Press mode plus and minus to switch to FM mode, press the play button to close the station, and you can

Use the buttons to switch up and down/volume up and down.

Insert the charger to charge the machine, the red light will be on when charging. The red light is full.

1. BT IC: AB5365A
2. Crystal: 26MHz
3. Frequency Range: 2402~2480MHz