







802.11ax-20 CHANNEL 10, SPURIOUS
30 MHz ~ 3 GHz

802.11ax-20 CHANNEL 10, SPURIOUS
2 GHz ~ 25 GHz



802.11ax-20 CHANNEL 11 CARRIER LEVEL


802.11ax-20 CHANNEL 11, SPURIOUS
30 MHz ~ 3 GHz

802.11ax-20 CHANNEL 11, SPURIOUS
2 GHz ~ 25 GHz



802.11ax-40 CHANNEL 3 CARRIER LEVEL




802.11ax-40 CHANNEL 3, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 3, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 4 CARRIER LEVEL




802.11ax-40 CHANNEL 4, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 4, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 5 CARRIER LEVEL




802.11ax-40 CHANNEL 5, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 5, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 6 CARRIER LEVEL




802.11ax-40 CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 7 CARRIER LEVEL




802.11ax-40 CHANNEL 7, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 7, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 8 CARRIER LEVEL




802.11ax-40 CHANNEL 8, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 8, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-40 CHANNEL 9 CARRIER LEVEL



802.11ax-40 CHANNEL 9, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-40 CHANNEL 9, SPURIOUS 2 GHz ~ 25 GHz




MIMO-Aux. Antenna


802.11b CHANNEL 1 CARRIER LEVEL




802.11b CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 6 CARRIER LEVEL




802.11b CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 11 CARRIER LEVEL




802.11b CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 1 CARRIER LEVEL




802.11g CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 2 CARRIER LEVEL




802.11g CHANNEL 2, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 2, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 6 CARRIER LEVEL




802.11g CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 11 CARRIER LEVEL



802.11g CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz



802.11g CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz



802.11n-20 CHANNEL 1 CARRIER LEVEL

